




Catalogue

V I C T O R I A 8

Spare parts

V I C T O R I A 8

- FIG. 1 - PROJECTOR (operating side)
- FIG. 2 - PROJECTOR MECHANISM
- FIG. 3 - DRUM SHUTTER AND SHUTTER HOUSING
- FIG. 4 - INTERMITTENT UNIT
- FIG. 5 - GATE BRACKET AND GATE FRAME
- FIG. 6 - LENS TURRET
- FIG. 7 - 5" SINGLE LENS-HOLDER
- FIG. 8 - OPTICAL SOUNDHEAD
- FIG. 9 - MAGNETIC SOUNDHEAD
- FIG. 10 - AIR COOLING UNIT
- FIG. 11 - ARC BEAM
- FIG. 12 - STAND COLUMN
- FIG. 13 - TOP SPOOL-BOX, TOP AND BOTTOM FIRETRAPS ASSEMBLIES
- FIG. 14 - LOWER SPOOL-BOX
- FIG. 15 - TAKE-UP
- FIG. 16 - MOTOR
- FIG. 17 - PICTURE CHANGE OVER MECHANISM


FOR VICTORIA 8 - 70/35: see page 35 and following

The mark ° indicates 35mm parts only.

The mark °° indicates 35/70mm parts only.

The letter Z indicates a gear, figures show number of teeth.

PLEASE ALWAYS, WHEN ORDERING SPARES, QUOTE THE SERIAL NUMBER OF THE PROJECTOR







FIG. 1

FIG. 1 - PROJECTOR (Operating side)

- °001C - 16 teeth intermittent sprocket
- °005C - 32 teeth bottom sprocket
- °0031 - Roller spindle retaining washer
- 0032 - Upper oil sight window with bezel • c86 oil seal.
- 00115 - Roller arm locking screw
- °00337 - Plain roller (15mm O.D.)
- °00338 - Circlip retaining rollers (6mm I.D.)
- °00601 - Grooved roller (15mm O.D.)
- °00602 - Plain roller (20mm O.D.)
- 12 - Stripper and post (top, intermediate and bottom sprockets)
- 13 - Mascarini safety lever
- 14 - Disc with shaft (Top loop trip)
- 15 - Oil filter magnet
- °16 - 24 teeth intermediate and Top sprockets (144C)
- °17 - Top and intermediate sprocket roller arm assembly complete with mounting plate
- °18 - Bottom sprocket roller arm assembly complete with mounting plate
- °19 - Intermittent sprocket roller arm assembly complete
- °20 - Boss for bottom sprocket with washer and screws
- °21 - Washer for bottom sprocket
- 22 - Lower oil sight window with bezel
- °23 - Top sprocket roller arm assembly
- 24 - Pressure spring for top and bottom sprocket roller arm assemblies
- °25 - Sprocket roller arm setting screw
- °26 - Top sprocket roller arm only
- °27 - Roller arm support spindle
- °28 - Intermediate sprocket roller arm only
- 29 - Pressure spring for intermediate sprocket roller arm
- °30 - Intermediate sprocket roller arm assembly
- °31 - Grooved roller spindle
- 32 - Intermittent sprocket roller arm assembly
- °33 - Roller spindle retaining screw
- °34 - Intermittent sprocket roller arm only
- 35 - Intermittent sprocket roller arm spring
- 36 - Spring setting bush for intermittent sprocket roller assembly
- 37 - Screw for bush
- °38 - Plain roller spindle
- °39 - Grooved roller spindle
- °40 - Bottom sprocket roller arm assembly
- °41 - Bottom sprocket roller arm only

FIG. 2 - PROJECTOR MECHANISM

- 0092 - P.E.cell connector
- 00250 - Oil filler plug
- 00296 - Masking (framing) knob
- 51 - Oil filter body
- 52 - Oil filter
- 53 - Intermediate sprocket gear, Z.78
- 54 - Intermediate sprocket shaft
- 55 - Driving gear Z.89
- 56 - Spindle with screw for part no. 55 gear
- 57 - Spindle with screw for bevel gear
- 58 - Driving gear Z.90
- 59 - Spindle with screw for part no. 58 gear
- 60 - Intermittent unit driving gear, Z.54
- 61 - Spindle with screw for part no. 60 gear
- 62 - Framing shaft retaining screw
- 63 - Framing shaft gasket
- 64 - Top sprocket driving gear, Z.78
- 65 - Top sprocket shaft
- 66 - Mechanism cover gasket
- 67 - Mechanism cover
- 68 - Governor assembly
- 69 - Governor drive pinion, Z.17
- 70 - Governor spring
- 71 - Governor ball with arm
- 72 - Masking (framing) rack securing screw
- 73 - Masking (framing) rack
- 74 - Masking (framing) shaft
- 75 - Bottom sprocket driving gear, Z.104
- 76 - Ball race
- 77 - Oil seal
- 78 - Take up drive toothed belt
- 79 - Take up driving pinion, Z.17
- 80 - Oil draining tube with gasket
- 81 - Oil drain plug with gasket
- 82 - Driving mechanism toothed belt
(19mm wide - Type 075") till available
- 82bis - Driving mechanism toothed belt
(25,4mm wide - Type 100") from n. 8500
- 83 - Mechanism drive toothed pulley, Z.55 frequency 50 cycles
- 84 - Torque assembly disc
- 85 - Torque assembly spring
- 86 - Mechanism driving gear shaft
- 87 - Torque assembly gear Z.39
- 88 - Oil pump drive gear Z.24
- 89 - Spindle for no. 88 gear
- 90 - Oil pump complete assembly
- 91 - Oil pump driving gear, Z.24
- 92 - Bottom sprocket shaft




FIG. 2




FIG. 3




FIG. 4

FIG. 3 - DRUM SHUTTER AND SHUTTER HOUSING

- 101 - Shutter assembly complete
- 102 - Shutter bearing only
- 103 - Torque assembly spring
- 104 - Conical shutter only
- 105 - Matched bevel gears Z.38 and Z.26, pinion Z.19 and torque assembly
- 106 - Dog for shutter pinion torque assembly
- 107 - Spring for shutter pinion torque assembly
- 108 - Shutter shaft
- 109 - Circlip 16mm O.D.
- 110 - Shutter torque assembly
- 111 - Dog for shutter torque assembly
- 112 - Safety shutter lever
- 113 - Screw for safety shutter lever
- 114 - Safety shutter disc with lever
- 115 - Safety shutter disc only
- 116 - Change over lever
- 117 - Unlatching lever spring
- 118 - Mascarini contact, fixed
- 119 - Mascarini contact, moving
- 120 - Unlatching lever spindle
- 121 - Safety shutter unlatching lever
- 122 - Safety shutter knob
- 123 - Safety shutter opening shaft
- 124 - Top light shield
- 125 - Shutter case inspection window, glass only
- 126 - Safety shutter lever guide complete
- 127 - Corrugated heat shield, inside
- 128 - Corrugated heat shield, outside
- 129 - Bottom light shield
- 130 - Gate cooling water inlet pipe
- 131 - Gate cooling water outlet pipe
- 132 - Water pipe union

FIG. 4 - INTERMITTENT UNIT

- 0020 - Maltese cross with cam pin and roller
- 0024 - Screw and washer securing intermittent sprocket
- 0026 - Cam pin and roller
- 00253 - Plug for roller setting
- 00254 - Oil seal
- 151 - Intermittent unit complete less sprocket
- 152 - Flywheel with cam, shaft and cam pinion
- 153 - Cam pinion, Z.13
- 154 - Bush for intermittent unit securing screw
- 155 - Intermittent unit movement securing screw with washer
- 156 - Intermittent unit cover
- 157 - Intermittent sprocket shaft
- 158 - Eccentric sleeve for intermittent shaft
- 159 - Clutch disc
- 160 - Clutch disc spring
- 161 - Bush for adjusting clutch disc spring
- 162 - Intermittent sprocket roller arm stop collar
- 163 - Collar spring
- 164 - Circlip for collar

FIG. 5 - GATE BRACKET AND GATE FRAME

- °007 - Spring guide roller assembly
- 0040/9 - Insulating bushes
- 0057/2 - Framing lamp holder assembly
- °00214 - Double aperture plate (aspect ratios to be specified)
for 35mm
- 00279 - Adjusting screw for spring guide roller
- °181 - Gate bracket assembly complete
- 182 - Gate bracket only
- °183 - Pressure pads for top plates
- 184 - Framing lamp, 12 Volts - 5 Watts
- °185 - Bracket for No. 007 roller complete with screw
- 186 - Spring for gate plate locking screw
- 187 - Gate plate locking screw
- °188 - Upper pressure plate retaining screw
- 189 - Spring washer for no. 188
- 190 - Latch for aperture plate
- 191 - Spring for aperture plate latch
- °192 - Pressure pad control spring
- 193 - Air duct
- °194 - Corrugated shield
- °195 - Aperture plate removable guide
- 196 - Water pipe union
- 197 - Gate latch arm
- 198 - Gate latch lever
- °199 - Gate plate
- °199bis - Gate plate with velvet
- °200 - 35mm gate frame assembly complete
- °201 - 35mm gate frame only
- °202 - 35mm pair of pressure plates (4 pieces)
- 203 - Gate frame support spring retaining knob
- 204 - Gate frame support spring
- 205 - Gate frame support
- 206 - Gate frame opening knob spring
- °207 - Pressure pad control knob
- °208 - Pressure pad control knob spring
- °209 - Pressure pad for lower plates
- °210 - Spring for pressure pads
- 211 - Gate frame opening knob with retaining screw
- 212 - Gate frame closing lever spring
- 213 - Gate frame closing lever
- °214 - Gate frame cover




FIG. 5





FIG. 6 - LENS TURRET

- 221 - Three lens turret assembly complete
- 222 - Holding lens sleeve with focusing screw (62,5 mm)
- 222bis - Holding lens sleeve with focusing screw (70,6 mm)
- 223 - Focusing knob
- 224 - Eccentric sleeve dia. 70,6/62,5
- 224bis - Sleeve dia. 70,6/62,5
- 225 - Anamorphic lens holder - ring only
- 226 - Eccentric guide for holding lens sleeve
- 227 - Stop plate
- 228 - Stop lever
- 229 - Stop lever spring
- 230 - Stop for eccentric mount
- 231 - Spring for pivoting turret bracket
- 232 - Turret assembly support bracket
- 233 - Light shield
- 234 - Lever locking turret assembly
- 235 - Lever spring
- 236 - Spring plunger
- 237 - Bracket for anamorphic lens holder
- 238 - Spring plunger for no. 237

FIG. 7 - 5" SINGLE LENS-HOLDER

- 250 - 5" single lens holder assembly complete
- 251 - Lens sleeve guide shaft
- 252 - Knurled knob for locking lens sleeve
- 253 - Lens fixing screw
- 254 - 5" to 4" eccentric adaptor
- 255 - 4" to 70,6 adaptor
- 255/1 - 4" to 62,5 adaptor
- 255/2 - 4" to 52,5 adaptor
- 256 - Adaptor stop ring with screws
- 257 - Anamorphic lens-holder assembly
- 258 - Anamorphic lens stop ring
- 259 - Lens sleeve guide
- 260 - Spring plunger lever
- 261 - Plunger
- 262 - Plunger spring
- 263 - Lens sleeve stop ring
- 264 - Focusing screw bush
- 265 - Focusing screw
- 266 - Focusing knob
- 267 - Anamorphic lens holder only (anamorphic lens type to be specified)

up-to-date I/64

up-to-date IV/64

FIG. 8 - OPTICAL SOUNDHEAD

008	- Filter roller 15mm O.D.
0035	- Reproducer drum with shaft and cover screw
0040	- Exciter lamp assembly complete
0040/1	- Exciter lamp housing complete
0040/2	- Exciter lamp housing cover
0040/3	- Exciter lamp holder and support bracket assembly
0040/4	- Exciter lamp insulating bushes and washers
0040/6	- Exciter lamp bottom contact spring, complete
0040/9	- Insulating bushes for part No. 0040/6
0040/10	- Exciter lamp locating spring with stud
0040/13	- Spring washer
00261	- P.E. cell housing
00261bis	- Photojunction housing
00338	- Circlip securing rollers (6mm I.D.)
00339	- Circlip securing rollers (8mm I.D.)
0015	- Flanged roller (22mm O.D.)
00606	- Plain roller (19mm O.D.)
281	- Complete optical soundhead
282	- Lay on pressure roller arm and bracket assembly
283	- Lay on pressure roller arm
284	- Lay on pressure roller and arm complete
285	- Lay on pressure roller spindle
286	- Lay on pressure roller assembly pivot spindle
287	- Lay on pressure roller spring bush
288	- Lay on pressure roller spring
289	- Lay on pressure roller arm bracket
290	- Photocell bracket
291	- Flanged roller spindle
292	- Earth contact
293	- Flywheel housing cover with earth contact
294	- Spring washer
295	- Flywheel magnet
296	- Dash pot assembly complete
297	- Dash pot body
298	- Oil tank
299	- Dash pot roller spindle
300	- Flywheel housing
301	- Ball race
302	- Cover screw (for P.E. cell)
0080	- Exciter lamp
0081	- Objective lens




FIG. 8





FIG. 9 - MAGNETIC SOUNDHEAD

- 00339 - Circlip securing roller (8mm I.D.)
- 00604 - Lay on pressure roller for 35 mm
- 00606 - Plain roller (19mm O.D.)
- 00608 - Flanged roller (22mm O.D.)
- 00619 - Lay on pressure roller for 70 mm
- °321 - Complete magnetic soundhead for 70/35
- 322 - Lay on pressure roller spring housing
- 323 - Lay on pressure roller spring
- 324 - Lay on pressure roller arm
- 325 - Lay on pressure roller arm and bracket assembly
- 326 - Eccentric spindle
- 327 - Lay on pressure roller arm spring
- 328 - Lay on pressure roller arm knob
- 329 - Lay on pressure roller arm knob cover indicator
- 330 - Terminal board for 35mm sound track
- 331 - Terminal board for 70mm sound track
- 332 - Filter roller tension screw
- 333 - Filter roller spring
- 334 - Roller arm assembly complete
- 335 - Roller arm only
- 336 - Roller spindle o.d. 8mm
- 337 - Filter roller spindle
- 338 - Spindle for flanged rollers o.d. 8mm
- °339 - Base for 35mm cluster
- °339bis - Base for 70mm cluster
- °340 - 35mm magnetic cluster
- °340bis - 70mm magnetic cluster
- 341 - drum with shaft
- 342 - spring washer for flywheel
- 343 - Ball race
- 344 - Filter roller lever with ball race
- 345 - Oil container
- °346 - Complete magnetic soundhead for 35

FIG. 10 - AIR COOLING UNIT

- 00398 - Rubber sleeve
- 361 - Complete fan assembly (mains voltage and frequency to be specified)
- 362 - Fan housing
- 363 - Motor flange
- 364 - Air filter complete with cover and stud
- 365 - Air filter (spring and fabric)
- 366 - Knob securing filter cover
- 367 - Filter stud
- 368 - Filter cover
- 369 - Fan motor (mains voltage and frequency to be specified)
- 370 - Fan

FIG. 11 - ARC BEAM

- 381 - Beam complete with control panel and Mascarini safety device
- 382 - Control panel only
- 383 - Arc supply pilot lamp
- 384 - Main motor starter with resistors (value in ohms to be specified)
- 385 - Motor starter resistor (value in ohms to be specified)
- 386 - Bolts securing lamphouse
- 387 - Arc supply control switch
- 388 - Exciter lamp ammeter
- 389 - Mascarini master switch
- 390 - Exciter lamp rheostat with knob
- 391 - Handle for main motor switch
- 392 - Exciter lamp switch
- 393 - Framing lamp switch
- 394 - Terminal board cover

to serial number 8399

- 395 - Terminal board complete
- 396 - Arc Fuse (120 amp for Z/420 Arc - 150 amp for SZ/450 Arc)
- 397 - Porcelain 5 amp fuse
- 398 - Glass 1 amp fuse

from serial number 8400

- 399 - Terminal board complete
- 400 - Glass 5 amp fuse (for main motor and exciter lamp)
- 401 - Glass 1 amp fuse (for framing lamp)

FIG. 12 - STAND COLUMN

- 411 - Main motor support
- 412 - Mechanism beam
- 413 - Mechanism beam securing screws
- 414 - Motor terminal board
- 415 - Magnetic preamplifier terminal board
- 416 - D.C. power supply for exciter lamp (voltage to be advised)
- 417 - Base levelling screw with nut
- 418 - Belt cover securing screw
- 419 - Belt cover
- 420 - Tilting device complete
- 421 - Tilting screw
- 422 - Tilting screw bracket
- 423 - Terminal board
- 424 - Rear cover complete
- 425 - Square head screw for setting the beam




FIG. 11




FIG. 12




FIG. 13

FIG. 13 - TOP SPOOL-BOX, TOP AND BOTTOM FIRETRAPS
ASSEMBLIES
 (to serial number 8425)

- °0015 - Flanged roller (22mm O.D.)
- °0031 - Roller spindle retaining washer
- °0052/1 - Spool spindle with driving collar 9mm diameter
- °0052/3 - Clutch pressure plate
- °0052/5 - Clutch insert (leather)
- °0052/6 - Clutch spring
- °0053 - Clutch and shaft complete
- °0053/2 - Clutch disc, fixed
- °00332 - Firetrap roller spindle, hinged section
- °00333 - Firetrap roller spindle, fixed section
- °00333a - Top roller spindle, hinged section
- °00334 - Latch knob complete
- °00337 - Plain roller (15mm o.d.)
- °00338 - Circlip retaining roller
- °00505 - Cover for top fire trap
- 00509 - Inspection window, rear
- 00510 - Spool box catch bracket with spring
- °00512 - Spool box catch
- °00515 - Inspection window, front
- °431 - Clutch spring tension nut
- °432 - Ball race
- 433 - Lamp-holder
- 434 - Lamp
- °435 - Top firetrap complete
- °436 - Top firetrap, hinged section only
- °437 - Top firetrap, fixed section only

FIG. 13 - TOP SPOOL-BOX
 (from serial number 8426)

- °0045 - Spool drive collar
- 00117 - Roller lock screw
- °00337 - Plain roller (15mm o.d.)
- 00509 - Inspection window, rear
- 00510 - Latch bracket with spring
- °00512 - Spool-box catch
- 00520 - Clutch spring
- °441 - Top spool-box complete with clutch and shaft
- °442 - Clutch and shaft complete
- 443 - Clutch pressure plate
- 444 - Clutch insert (felt)
- 445 - Clutch disc, fixed
- 446 - Ball race
- 447 - Clutch spring tension nut
- °448 - Spool spindle with driving collar, 9mm diameter
- 449 - Inspection window, front
- °450 - Top firetrap, complete
- °451 - Top firetrap frame only
- °452 - Top firetrap safety plate
- °453 - Roller spindle
- °454 - Flanged roller spindle
- °455 - Flanged roller (30mm o.d.)

FIG. 14 - LOWER SPOOL-BOX
(to serial number 8425)

- °0015 - Flanged roller (22mm O.D.)
- °0031 - Roller spindle retaining washer
- °00243/2 - Bottom firetrap hinged section only
- °00332 - Firetrap spindle, hinged section
- °00333 - Firetrap roller spindle, fixed section
- °00333a - Bottom roller spindle, hinged section
- °00334 - Latch knob complete
- °00337 - Plain roller (15mm O.D.)
- °00338 - Circlip retaining roller
- °00506 - Cover for bottom firetrap
- 00510 - Spool box catch bracket with spring
- °00512 - Spool box catch
- °461 - Bottom firetrap, complete
- °462 - Bottom firetrap, fixed section only

FIG. 14 - LOWER SPOOL-BOX
(from serial number 8426)

- 00117 - Roller lock screw
- °00337 - Plain roller (15mm O.D.)
- 00510 - Spool-box latch bracket with spring
- °00512 - Spool-box catch
- °452 - Bottom firetrap safety plate
- °453 - Roller spindle
- °454 - Flanged roller spindle
- °455 - Flanged roller (30mm O.D.)
- °471 - Bottom spool-box complete, less take-up assembly
- °472 - Bottom firetrap complete
- °473 - Bottom firetrap frame only







FIG. 14




FIG. 15




FIG. 16




FIG. 17

FIG. 15 - TAKE-UP

- °0045 - Spool driving collar
- °00520 - Clutch spring
- 443 - Clutch pressure plate
- 444 - Clutch insert (felt)
- 446 - Ball race
- 447 - Clutch spring tension nut
- °491 - Take-up assembly complete
- °492 - Bush
- 493 - Take-up toothed pulley
- °494 - Spool spindle with driving collar assembly 9mm

FIG. 16 - MOTOR

- 00291 - Inching knob
- 511 - Projector drive motor (mains voltage and frequency to be specified)
- °512 - Motor toothed pulley for 35mm with screw
Z.18 50 cycles 24 pictures
- °512a - Motor toothed pulley for 35mm with screw
Z.19 50 cycles 25 pictures
- °°513 - Motor toothed pulley for 70/35mm with screw
Z.18 50 cycles 24 pictures
Z.22 50 cycles 30 pictures
- °°513a - Motor toothed pulley for 70/35mm with screw
Z.19 50 cycles 25 pictures
Z.22 50 cycles 30 pictures
- °°513b - Motor toothed pulley for 70/35mm with screw
Z.16 60 cycles 24 pictures
Z.20 60 cycles 30 pictures
- 514 - Pinion securing screw with washer

FIG.17 - PICTURE CHANGEOVER MECHANISM

- 521 - Complete change over mechanism no.116 lever
- 522 - Cover
- 523 - Microswitch for sound change over
- 524 - Microswitch for picture change over
- 525 - Solenoid assembly
- 526 - Three way terminal board
- 527 - Six way terminal board
- 528 - Cable form

FIG. 15 - TAKE-UP

- Spool driving collar	0045
- Clutch spring	00520
- Clutch pressure plate	443
- Clutch insert (felt)	444
- Ball race	446
- Clutch spring tension nut	447
- Take-up assembly complete	451
- Bush	452
- Take-up toothed pulley	453
- Spool spindle with driving collar assembly 9mm	454

FIG. 16 - MOTOR

- Inching knob	00291
- Projector drive motor (mains voltage and frequency to be specified)	511
- Motor toothed pulley for 35mm with screw	512
2.18 50 cycles 24 pictures	
- Motor toothed pulley for 35mm with screw	512a
2.19 50 cycles 25 pictures	
- Motor toothed pulley for 70/35mm with screw	513
2.18 50 cycles 24 pictures	
2.22 50 cycles 30 pictures	
- Motor toothed pulley for 70/35mm with screw	513a
2.19 50 cycles 25 pictures	
2.22 50 cycles 30 pictures	
- Motor toothed pulley for 70/35mm with screw	513b
2.18 50 cycles 24 pictures	
2.20 60 cycles 30 pictures	
- Pinion securing screw with washer	514

FIG. 17 - PICTURE CHANGEOVER MECHANISM

- Complete change over mechanism no. 116 lever	521
- Cover	522
- Microswitch for sound change over	523
- Microswitch for picture change over	524
- Solenoid assembly	525
- Three way terminal board	526
- Six way terminal board	527
- Cable form	528

FIG. 18 - COMANDO A DISTANZA - OBIETTIVO

10-1810	Comando obiettivo completo
10-1812	Motore 50 Hz
10-1816	(precisare tensione)
10-1818	Ingranaggio motore
10-1820	Ingranaggio condotto
10-1821	Bottoni regolazione
10-1822	Disco frizione
10-1823	Rosetta elastica

FIG. 18 - REMOTE FOCUS UNIT

10-1810	Remote focus assembly
10-1812	complete
10-1816	Motor 50 Hz
10-1818	(specify voltage)
10-1820	Motor gear
10-1821	Drive gear
10-1822	Knob
10-1823	Clutch insert
10-1824	Spring washer

FIG. 18 - COMMANDE FOYER A DISTANCE

10-1810	Comando foyer complet
10-1812	Moteur 50 Hz
10-1816	(préciser tension)
10-1818	Engrenage moteur
10-1820	Engrenage conduit
10-1821	Bouton
10-1822	Disque friction
10-1823	Rondelle elastique

FIG. 19 - COMANDO A DISTANZA QUADRO

8V-1830	Comando quadro completo
8V-1836	Ingranaggio motore
8V-1837	Ingranaggio condotto
8V-1838	Disco frizione
8V-1840	Rosetta elastica
8V-1842	Dado regolazione frizione
8V-1843	Prolunga
8V-1847	Motore 50 Hz
8V-1847	(precisare tensione)

FIG. 19 - REMOTE FRAMING UNIT

8V-1830	Remote framing assembly
8V-1836	complete
8V-1837	Motor gear
8V-1838	Drive gear
8V-1840	Clutch insert
8V-1842	Spring washer
8V-1843	Clutch tension nut
8V-1847	Extension shaft
8V-1847	Motor 50 Hz
8V-1847	(specify voltage)

FIG. 19 - COMMANDE CADRAGE A DISTANCE

8V-1830	Comando cadrage complet
8V-1836	Engrenage moteur
8V-1837	Engrenage conduit
8V-1838	Disque friction
8V-1840	Rondelle elastique
8V-1842	Ecrou réglage friction
8V-1843	Prolongation
8V-1847	Moteur 50 Hz
8V-1847	(préciser tension)

FIG. 18 - COMANDO A DISTANZA OBBIETTIVO

10-1810	Comando obbiettivo completo
10-1812	Motore 50 Hz (precisare tensione)
10-1816	Ingranaggio motore
10-1818	Ingranaggio condotto
10-1820	Bottone regolazione
10-1821	Disco frizione
10-1822	Rosetta elastica

FIG. 18 - COMMANDE FOYER A DISTANCE

10-1810	Commande foyer complet
10-1812	Moteur 50 Hz (préciser tension)
10-1816	Engrenage moteur
10-1818	Engrenage conduit
10-1820	Bouton
10-1821	Disque friction
10-1822	Rondelle elastique

FIG. 19 - COMANDO A DISTANZA QUADRO

8V-1830	Comando quadro completo
8V-1836	Ingranaggio motore
8V-1837	Ingranaggio condotto
8V-1838	Disco frizione
8V-1840	Rosetta elastica
8V-1842	Dado regolazione frizione
8V-1843	Prolunga
8V-1847	Motore 50 Hz (precisare tensione)

FIG. 19 - COMMANDE CADRAGE A DISTANCE

8V-1830	Commande cadrage complet
8V-1836	Engrenage moteur
8V-1837	Engrenage conduit
8V-1838	Disque friction
8V-1840	Rondelle elastique
8V-1842	Ecrou réglage friction
8V-1843	Prolongation
8V-1847	Moteur 50 Hz (préciser tension)

FIG. 18 - REMOTE FOCUS UNIT

10-1810	Remote focus assembly complete
10-1812	Motor 50 Hz (specify voltage)
10-1816	Motor gear
10-1818	Drive gear
10-1820	Knob
10-1821	Clutch insert
10-1822	Spring washer

FIG. 19 - REMOTE FRAMING UNIT

8V-1830	Remote framing assembly complete
8V-1836	Motor gear
8V-1837	Drive gear
8V-1838	Clutch insert
8V-1840	Spring washer
8V-1842	Clutch tension nut
8V-1843	Extension shaft
8V-1847	Motor 50 Hz (specify voltage)




FIG. 18




FIG. 19




FIG. 20

FIG. 20 - COMANDO CAMBIO IMMAGINE

8E-1560	Cambio immagine completo
8E-1563	Solenoid completo (precisare tensione)
8E-1563d	Asta con bottone
8E-1563f	Pomolo
8E-1563g	Raccordo flessibile
8E-1564	Nucleo
8E-1565	Prolunga nucleo
8E-1566	Tubo con flangia
8E-1568	Serranda
8E-1569	Attacco flessibile completo
8E-1570	Flessibile
8E-1573	Vite registro completa
8E-1573c	Molla registro
8E-1573d	Sfera
8E-1574	Rondella battuta
8E-1574a	Distanziale battuta
8E- 524	Condotto aria con guide
8E-1589	Bussola interruttore suono
8E-1590	Microinterruttore

FIG. 20 - CHANGE OVER CONTROL

8E-1560	Picture change over assembly complete
8E-1563	Solenoid coil assembly (please specify voltage)
8E-1563d	Guide rod with knob
8E-1563f	Knob
8E-1563g	Bowden wire connection
8E-1564	Core
8E-1565	Core extension rod
8E-1566	Tube with flange
8E-1568	Shutter (Picture change)
8E-1569	Bowden clamp assembly
8E-1570	Bowden wire
8E-1573	Set screw assembly
8E-1573c	Brake spring
8E-1573d	Brake ball
8E-1574	Stop washer
8E-1574a	Stop spacer
8E- 524	Air duct complete with shutter guides
8E-1589	Sound switch bush
8E-1590	Microswitch

FIG. 20 - COMMANDE CHANGE IMAGE

8E-1560	Change image complet
8E-1563	Solenoid complet (préciser tension)
8E-1563d	Tige avec bouton
8E-1563f	Poignée
8E-1563g	Raccord flexible
8E-1564	Noyau
8E-1565	Prolongation noyau
8E-1566	Tuyau avec bride
8E-1568	Serrande
8E-1569	Attache flexible complet
8E-1570	Flexible
8E-1573	Vis de réglage
8E-1573c	Ressort de réglage
8E-1573d	Bille
8E-1574	Rondelle butée
8E-1574a	Entretoise butée
8E- 524	Conduit d'air avec guides
8E-1589	Cage interrupteur son
8E-1590	Microinterruteur

FIG. 50 - COMANDO CAMBIO IMMAGINE

8E-1560	Cambio immagine completo
8E-1563	Solenoidi completo
8E-1563d	(prestare tensione)
8E-1563d	Asta con bottone
8E-1563f	Pomolo
8E-1563g	Raccordo flessibile
8E-1564	Molle
8E-1565	Prolunga molle
8E-1566	Tubo con flange
8E-1568	Serranda
8E-1569	Attacco flessibile completo
8E-1570	Flessibile
8E-1573	Vite registro completo
8E-1573c	Molla registro
8E-1573d	Stato
8E-1574	Rondelle lussate
8E-1574g	Distanziale battute
8E-1574h	Conduttore aria con guida
8E-1589	Fusola interruttore suono
8E-1590	Microinterruttore

FIG. 50 - CHANGE OVER CONTROL

8E-1560	Picture change over
8E-1563	assembly complete
8E-1563d	Solenoid coil assembly
8E-1563d	(please specify voltage)
8E-1563d	Guide rod with knob
8E-1563f	Knob
8E-1563g	Bowden wire connection
8E-1564	Core
8E-1565	Core extension rod
8E-1566	Tube with flange
8E-1568	Shutter (Picture change)
8E-1569	Bowden clamp assembly
8E-1570	Bowden wire
8E-1573	Set screw assembly
8E-1573c	Brake spring
8E-1573d	Brake ball
8E-1574	Stop washer
8E-1574g	Stop spacer
8E-1574h	Air duct complete with
8E-1574h	shutter guides
8E-1589	Sound switch push
8E-1590	Microswitch

FIG. 50 - COMMANDO CHARGE IMAGE

8E-1560	Change image complete
8E-1563	Solenoid complete
8E-1563d	(prestare tensione)
8E-1563d	Tige avec bouton
8E-1563f	Pomolo
8E-1563g	Raccord flexible
8E-1564	Molle
8E-1565	Prolunga molle
8E-1566	Tubo con flange
8E-1568	Serranda
8E-1569	Attacco flessibile completo
8E-1570	Flessibile
8E-1573	Vite de réglage
8E-1573c	Ressort de réglage
8E-1573d	Bille
8E-1574	Rondelle lussée
8E-1574g	Entretour lussée
8E-1574h	Conduit d'air avec
8E-1589	Cage interrupteur son
8E-1590	Microinterrupteur

VICTORIA 8 - FOR 70/35 TYPE ONLY

FIG. 25	-	PROJECTOR (operating side)
FIG. 26	-	GATE BRACKET AND GATE FRAME
FIG. 27	-	TOP SPOOL-BOX, TOP AND BOTTOM FIRETRAPS
FIG. 28	-	TOP CLUTCH
FIG. 29	-	FIRETRAPS
FIG. 30	-	BOTTOM SPOOL-BOX
FIG. 31	-	TAKE-UP

Catalogue

V I C T O R I A 8

Spare parts

FOR 70/35 TYPE ONLY

The mark "°" indicates 35mm parts only.
The mark "°°" indicates 35/30mm parts only.
The letter "Z" indicates a gear, figures show number of teeth.

PLEASE ALWAYS, WHEN ORDERING SPARES, QUOTE THE SERIAL NUMBER OF THE PROJECTOR


VICTORIA 8 - FOR 70/35 TYPE ONLY

- FIG. 25 - PROJECTOR (operating side)
- FIG. 26 - GATE BRACKET AND GATE FRAME
- FIG. 27 - TOP SPOOL-BOX, TOP AND BOTTOM FIRETRAPS
- FIG. 28 - TOP CLUTCH
- FIG. 29 - FIRETRAPS
- FIG. 30 - BOTTOM SPOOL-BOX
- FIG. 31 - TAKE-UP

The mark ° indicates 35mm parts only.
The mark °° indicates 35/70mm parts only.
The letter Z indicates a gear, figures show number of teeth.

PLEASE ALWAYS, WHEN ORDERING SPARES, QUOTE THE SERIAL NUMBER
OF THE PROJECTOR

VARIANTI 70/35







FIG. 25

FIG. 25 - PROJECTOR (operating side)

- 0011 - Grooved roller (15mm O.D.)
- 00115 - Roller arm locking screw
- 00339 - Circlip securing rollers (8mm I.D.)
- °°00605 - Grooved roller (14,5mm O.D.)
- °°00606 - Plain roller (19mm O.D.)
- 24 - Pressure spring for top and bottom sprocket roller arm
- 29 - Pressure spring for intermediate sprocket roller arm
- 32 - Intermediate sprocket roller arm spindle assembly
- 35 - Intermediate sprocket roller arm spring
- 36 - Spring setting bush for the intermittent sprocket roller assembly
- 37 - Screw for bush
- 327 - Sprocket roller arm knob spring
- 328 - Sprocket roller arm knob
- 329 - Sprocket roller arm knob cover indicator
- °°701 - Top and intermediate sprocket roller arm assembly complete with mounting plate
- °°702 - Top and intermediate sprocket, 30-24 teeth (146)
- °°703 - Bottom sprocket roller arm assembly complete with mounting plate
- °°704 - Bottom sprocket, 40-32 teeth (108)
- °°705 - Intermittent sprocket roller arm assembly complete with mounting plate
- °°706 - Intermittent sprocket, 20-16 teeth (424)
- °°707 - Top sprocket roller arm assembly
- °°708 - Top sprocket roller arm only
- °°709 - Sprocket roller arm setting screw
- °°710 - Roller arm support spindle
- °°711 - Intermediate sprocket roller arm assembly
- °°712 - Intermediate sprocket roller arm only
- °°713 - Roller eccentric shaft
- °°714 - Intermittent sprocket roller arm only
- °°715 - Spindle for plain roller 00606
- °°716 - 35mm film guide shaft
- °°717 - 35mm film guide
- °°718 - Bottom sprocket roller arm assembly
- °°719 - Bottom sprocket roller arm only
- °°720 - Sprocket arm bush retaining screw
- °°721 - Sprocket arm bush
- °°722 - Spindle for grooved roller 0011
- °°724 - Steel intermittent sprocket, 20 teeth (425)
- °°725 - Grooved roller (14,8mm O.D.)

FIG. 26 - GATE BRACKET AND GATE FRAME

- 0040/9 - Insulating bush
- 0057/2 - Framing lamp holder assembly
- 00279 - Adjusting screw for spring guide roller
- °°00607 - Spring guide roller assembly
- 182 - Gate bracket only
- 184 - Framing lamp 12 Volts - 5 Watts
- 186 - Spring for gate plate locking screw
- 187 - Gate plate locking screw
- 189 - Spring washer for part 742
- 190 - Latch for aperture plate
- 191 - Spring for aperture plate latch
- 193 - Air duct
- 196 - Water pipe union
- 197 - Gate latch arm
- 198 - Gate latch lever
- 203 - Gate frame support spring retaining knob
- 204 - Gate frame support spring
- 205 - Gate frame support
- 206 - Gate frame opening knob spring
- 211 - Gate frame opening knob with retaining screw
- 212 - Gate frame closing lever spring
- 213 - Gate frame closing lever
- °°741 - Gate bracket assembly complete
- °°742 - Upper pressure plate retaining screw
- °°743 - 70mm standard aperture plate (47x20)
- °°743bis - 70mm undersized aperture plate (43x16)
- °°744 - Bracket for no. 00607 roller complete with screws
- °°745 - Gate plate
- °°745bis - Gate plate with velvet
- °°746 - 70mm gate frame assembly complete
- °°747 - 70mm gate frame only
- °°748 - 70mm pair of pressure plates (4 pieces)
- °°749 - Pressure pads spring bush
- °°750 - Pressure pads spring
- °°751 - Pressure pads spring knob
- °°752 - Pressure pads assembly




FIG. 26




FIG. 27




FIG. 28




FIG. 29

FIG. 27 - TOP SPOOL-BOX, TOP AND BOTTOM FIRETRAPS
(till serial number 8425)

- 00509 - Inspection window, rear
- 00510 - Spool-box catch bracket with spring
- 449 - Inspection window, front
- °°771 - Spool-box catch
- °°772 - Cover for top firetrap

FIG. 27 - TOP SPOOL-BOX
(from serial number 8426)

- 00509 - Inspection window, rear
- 00510 - Spool-box catch bracket with spring
- 449 - Inspection window, front
- °°771 - Spool-box catch
- °°781 - Top spool-box complete, less clutch and shaft
- °°782 - Cover for top firetrap

FIG. 28 - TOP CLUTCH

- 00520 - Clutch spring
- 443 - Clutch pressure plate
- 444 - Clutch insert (felt)
- 445 - Clutch disc, fixed
- 446 - Ball race
- 447 - Clutch spring tension nut
- °°821 - Clutch and shaft complete
- °°822 - Spool spindle with driving collar 12,7mm diameter
- °°823 - Spool drive collar
- °°824 - Double sneck assembly
- °°825 - 35mm spool spacer

FIG. 29 - FIRETRAPS

- 00115 - Small roller securing screws
- 00117 - Large roller securing screw
- °°00606 - Plain roller (19mm O.D.)
- °°00611 - Flanged roller (18,5mm O.D.)
- °°851 - Top and bottom firetrap assembly complete
- °°852 - Firetrap frame only
- °°853 - Large roller without ball race
- °°854 - Circlip for large roller (30mm O.D.)
- °°855 - Spindle for plain roller 00606
- °°856 - Spindle for flanged roller 00611
- °°857 - Firetraps safety plate
- °°858 - Ball race
- °°859 - Large roller spindle

FIG. 30 - BOTTOM SPOOL-BOX
(till serial number 8425)

- 00510 - Spool box catch bracket with spring
- °°771 - Spool box catch
- °°791 - Cover for bottom fire-trap

FIG. 30 - BOTTOM SPOOL-BOX
(from serial number 8426)

- 00510 - Spool box catch bracket with spring
- °°771 - Spool box catch
- °°801 - Bottom spool box complete, less clutch and shaft
- °°802 - Cover for bottom firetrap

FIG. 31 - TAKE-UP

- 00520 - Clutch spring
- 443 - Clutch pressure plate
- 444 - Clutch insert (felt)
- 446 - Ball race
- 447 - Clutch spring tension nut
- 493 - Take-up toothed pulley
- °°823 - Spool drive collar
- °°824 - Double snek assembly
- °°825 - 35mm spools spacer
- °°831 - Take-up assembly complete
- °°832 - Bush
- °°833 - Spool spindle with driving collar, 12,7mm




FIG. 30





FIG. 31

VICTORIA 8-70/35 PROJECTORHow to interchange from 70 to 35 mm and vice-versaInterchange from 70 to 35 mm.

The sketch represents the mechanism ready for 70 mm film threading.



After the interchange has been performed, carefully control that:
all the two-coloured knobs present the red up and
all the screws  have been duly tightened

Interchange from 35 to 70

Perform same operations vice-versa, i.e.: unloose the screws , rotate all the two-coloured knobs and the magnetic cluster in order that they present the yellow up. Remove the gate frame, the gate plate, the mask plate guide, and the corrugated frame. Insert the gate plate, the gate frame and the 70 mask plate. Mount the wanted lens. Change speed if required. Switch the magnetic preamplifier from 35 to 70. Take away the spacers from the spools spindles.

After the interchange has been performed, carefully control that:
all the two-coloured knobs present the yellow up and
all the screws  have been duly tightened.

VICTORIA 8-10/35 PROJECTOR

How to interchange from 70 to 35 mm and vice-versa

Interchange from 70 to 35 mm.

The sketch represents the mechanism ready for 70 mm film threading.

- 1 - Unscrew the screw of the two colored knobs to allow their free rotation.

- 2 - Turn half a turn the pressure roller knob of the magnetic head drum.

- 3 - Turn half a turn the roller arm knob of the upper and intermediate sprockets.

- 4 - Unscrew the two knurled knobs of the magnetic cylinder, turn half a turn the magnetic cylinder, screw again the two knobs.

- 5 - Remove the 70 gate frame, the gate plate and the mask plate and insert the 35 corrugated frame, the gate plate and the 35 magnetic mask plate.

- 6 - Mount the wanted lens.

- 7 - Turn a quarter of turn the roller arm knob of the intermediate sprocket.


- 8 - Turn half a turn the roller arm knob of the bottom sprocket.

- 9 - Reverse the motor pinion to obtain 35 frames per second (only 11 frames projector was running at 30 frames per second).

- 10 - Switch the magnetic pressurizer from 70 to 35.

- 11 - Insert the spacers in the spools spindles.

- 12 - Tighten the screws to block the two colored knobs.



After the interchange has been performed, carefully control that all the two-colored knobs present the red up and all the screws ⑤ have been duly tightened.

Interchange from 35 to 70

Perform same operations vice-versa, i.e.: unscrew the screws ⑤, rotate all the two-colored knobs and the magnetic cylinder in order that they present the yellow up. Remove the gate frame, the gate plate, the mask plate and the 35 corrugated frame. Insert the gate plate, the gate frame and the 70 mask plate. Mount the wanted lens. Change spool 11 regulated. Switch the magnetic pressurizer from 35 to 70. Take away the spacers from the spool spindles.

After the interchange has been performed, carefully control that all the two-colored knobs present the yellow up and all the screws ⑤ have been duly tightened.

Undersize Mask Plate Apertures

Undersize mask apertures are supplied for 35mm. ratios so that corrections can be made after the projectors have been correctly set in position and the position of the screen finalised, curtains arranged, which should all be carried out using test film.

With the film correctly focussed on the screen (it is the film which is focussed and not the outline of the mask aperture), arrangements can be made to file the mask plates to compensate for any keystone of the image which may occur due to projection angles on the vertical side lines of the mask aperture and any curvature distortion which may occur on the horizontal lines due to the use of curved screens.

Careful adjustment of the mask plates by filing will enable a completely uniform frame to be projected.

Frame dimensions for different ratios are as follows:

Aspect	Ratio	Film		Mask Plates	
		width	height	width	height
Normal	1.37:1	20.96	15.24	20.5	14.8
Wide screen	1.66:1	20.96	12.62	20.5	12.3
	1.75:1	20.96	12	20.5	11.7
	1.85:1	20.96	11.33	20.5	11
CinemaScope	2.35:1	21.37	18.16	20.8	17.5
	2.55:1	23.16	18.16	22.5	17.5
70mm. Film	2.2:1	48.56	22	47	20
				43	16

Change over Control (Fig. 18 - 19 - 20)

To change over picture and sound from one machine to the other, lift the safety dowser (19B) which will operate two micro-switches. One micro-switch (19A) will change over the picture and cause the safety dowser to drop on the outgoing projector, the other (19C) will change over the sound by operating the relay fitted in the change over box.

For projectors supplied with change over control (ZIPPER) (Fig. 20) to change over from one machine to the other, lift the safety dowser (19B) and push the button (20H) which will operate the Solenoid (20F) lift the safety dowser (20G) and operate the sound micro-switch (20E) fitted in the change over box.

The external control knobs are only used in case of an emergency. After making a changeover, check that picture and sound are satisfactory, close lamphouse dowser on outgoing projector and switch off.

ADJUSTMENTS

Adjustments to be carried out are the same both for 35mm. and 70mm. projection.

Pads Pressure (Fig. 16)

All pressure applied to the film should be kept to an absolute minimum and should not exceed that necessary to keep a steady picture.

For 35 mm. Film

On the 35mm. gate, screw (16D) adjusts the pressure of the four gate runners onto the film, Turning this screw clock-wise will increase pressure. The engraved numbers are only used as references.

For 70mm. Film

The 70mm. gate knurled nuts (16G-H) adjust the spring tension applied to the pressure pads.
The top knurled nut (16G) adjusts the runners controlling the film entering the gate.

Optical and Magnetic Damper (Fig. 23)

Whilst running projector check loops are as for Diagrams shown (Fig. 23).

Optical

Rotate screw (22R) until the lower edge of the damper cone (23P) is in line with the top of the gauge (23 I).

Magnetic

Adjust the control knob (23B) until the axis of the roller (23A) is in line with the red spot (23C).

Sound Synchronisation

35mm. Optical Film

The synchronisation distance between picture and sound is 20 frames. The sound preceeding the picture.

35mm. Magnetic Film

The picture to sound synchronisation distance is 28 frames.
The sound following the picture.

70mm. Film

The picture to sound synchronisation distance is 24 frames.
The sound following the picture.

The sound synchronisation roller (10F) on the magnetic soundhead permits the synchronisation distance to be adjusted.
Loosening the screw the roller arm assembly can be rotated to shorten or lengthen the film path. The film can be laced also as marked on the soundhead cover to secure standard synchronisation.

DEFECTS - CAUSES

Projector motor does not start

- Master switch open
- Safety device open
- Motor starter contacts are dirty or defective
- Starter fuses blown or resistances burnt out

Film breakage or damage

- Upper clutch to be adjusted
- Bottom clutch to be adjusted
- Entrance and output gate loops too short
- Incorrect film threading
- Locked rollers and roller arm assemblies without clearance
- Defective or incorrectly aligned film sprockets
- Unsuitable spool hub

Lack of sound synchronisation

- Incorrect film threading
- Film lacing on the magnetic soundhead to be adjusted with the 2 roller arm assemblies

Sound flutter

- Varying film speed
- Oil dampers out of adjustment or lacking oil
- Soundhead flywheel does not turn regularly
- Pressure pads to be checked
- Optical soundhead objective lens to be cleaned

Noisy film operation

- Gate entry and lower loop to be corrected
- Gate pressure plates to be adjusted or to be cleaned

Noisy projector operation

- Lubrication to be checked
- Slack screws on the covers
- Belt mis-aligned

Safety device does not close

- Lamphouse dowsers left open
- Pieces of film have jammed the lever

REPLACEMENT OF THE INTERMITTENT UNIT (Fig. 25)

In the unlikely event that it should prove necessary to replace an Intermittent Unit, the instructions set out herewith, if followed closely, will enable an exchange to be carried out quickly and efficiently.

First, remove the Gate Bracket and the Gate Plate. Turn the Projector slowly by hand until the Intermittent Sprocket is in the 'locked' position and then remove it from the spindle. Remove the Intermittent Sprocket Roller Arm Assembly (25M), Steel Circlip for Collar (25L), the Roller Arm Stop Collar (25G), Clutch Spring Bush (25H), Clutch Spring and Plate (25F) the Screw Cover (25D) and the Holding Screw (25E) with washer.

If fitted, remove the Magnetic Preamplifier which in turn will allow the rear Main Cover of the Projector to be removed complete with Blower Motor Assembly.

Slacken off the Screw Locating the Racking Shaft (25B) and draw this forward until the end of the Shaft disengages with the rear Bearing inside the Projector housing. When carrying out this operation note the position of the red marker dot (25A).

Rotate the Intermittent Unit until this is clear of the Gear Train then withdraw from the mechanism body.

The replacement Intermittent Unit must first be set so that the Intermittent Sprocket Spindle is in the "locked" position and should then be inserted into the main casting turned until such time as the drive gear is meshed with the driving gear. The unit may then be locked with Screw (25E). Re-set the Framing Control Spindle, then the Clutch Disc (25F) ensuring that the red spot on the disc and the red spot on the Main Casting are in line. Re-place the spring and the spring bush (25H) which should be screwed up tightly then unscrewed $1/4$ of a turn.

Without running the projector, check the Framing Movement, operating this to the extreme Full Rack Top Position and the Extreme Full Rack Bottom Position, rotating the mechanism by using the Inching Knob on the Motor whilst this Rack check is being carried out to ensure that the mechanism rotates freely, irrespective of the position of the Racking Movement.

Re-assemble the screw cap (25D) the Roller Arm Assembly Spring, the Stop Collar with Ring, the Roller Arm Assembly (25M), re-adjusting the tension on the roller arm. Replace the Intermittent Sprocket. Locate the Key Washer in the groove cut in the Sprocket Spindle and lock with the Fixing Screw.

Replace the rear Cover of the Projector and if fitted the Magnetic Preamplifier Assembly.

Should the Shutter be out of Phase, rotate the Intermittent Sprocket until the point is reached when the movement of the film is about to commence. Slacken the Shutter Holding Screws (18P) and move the Shutter Blade round to a position to correspond with the Bottom line of the Aperture (18N) and lock the screws.

The Shutter rotates clockwise when viewed from the Lamphouse position. When running a test film, (for instance C.T.C.) should travel 'ghost' appear on the top of the picture, move the shutter forward in a clock-wise direction. If Shutter travel 'ghost' appears on the bottom, move the Shutter anti-clockwise.




FIG. 21




FIG. 22




FIG. 23

