

SUBJECT TO 20% INCREASE.

J. FRANK BROCKLISS, LTD.,

58, GREAT MARLBOROUGH STREET, LONDON, W.1.

TELEphone : GERRARD 2911 - 2912 - 2913.
grams : " Stafilm, Wesdo, London.

HALL & CONNOLLY H.C. 4 LAMP. REPLACEMENT PARTS.

BURNER PARTS.

								£	s.	d.
H.C.	1	Lamp Frame	...	...	...	...	...	2	5	0
H.C.	2	Lamp Feed Frame	...	...	...	...	...	2	10	0
H.C.	3	Positive Carbon Guide Head 11 m/m or 13.6 m/m	...	...	...	...	...	1	2	6
H.C.	4	Contact Shoe 11 m/m or 13.6 m/m	...	...	...	...	...	0	2	6
H.C.	5	Positive Contact Spring	...	...	...	...	...	0	2	6
H.C.	6	Positive Contact Shunt...	...	...	...	...	...	0	2	6
H.C.	7	Screws for H.C. 1 and H.C. 2	...	...	...	...	...	0	0	5
H.C.	8	Shunt Nut for H.C. 6 on H. C. 1	...	...	...	...	...	0	0	5
H.C.	9	Lamp Support Screw	...	...	...	...	...	0	0	5
H.C.	10	Brass Washer for H.C. 70	...	...	...	...	...	0	0	3
H.C.	11	Mica Washer for H.C. 70	...	...	...	...	...	0	1	0
H.C.	12	Mica Bushings for H.C. 67	...	...	...	...	...	0	1	0
H.C.	13	Contact Lever	...	...	...	...	...	0	10	0
H.C.	14	Contact Lever Pivot	...	...	...	...	...	0	1	6
H.C.	15	Shunt Screw Washer	...	...	...	...	...	0	0	3
H.C.	17	Positive Flame Shield Screw	...	...	...	...	...	0	0	3
H.C.	18	Double Positive Flame Shield (new style)	...	...	...	...	...	1	0	0
H.C.	19	Negative Spring Bracket Screw	...	...	...	...	...	0	0	3
H.C.	20	Negative Tension Spring	...	...	...	...	...	0	2	6
H.C.	21	Negative Tension Spring Bracket	...	...	...	...	...	0	2	6
H.C.	22	Negative Spring Adjusting Screw	...	...	...	...	...	0	0	9
H.C.	23	Negative Spring Adjusting Screw Nut	...	...	...	...	...	0	0	3
H.C.	24	Negative Spur Gear	...	...	...	...	...	0	7	6
H.C.	25	Negative Pinion and Shaft	...	...	...	...	...	0	10	6
H.C.	26	Negative Pinion Shaft Collar Cotter Pin	...	...	...	...	...	0	0	3
H.C.	27	Negative Pinion Shaft Collar	...	...	...	...	...	0	2	0
H.C.	28	Connecting Rod Casting	...	...	...	...	...	0	6	6
H.C.	28A	Connecting Rod Complete	...	...	...	...	...	1	0	0
H.C.	29	Positive Gear Collar	...	...	...	...	...	0	3	6
H.C.	30	Positive Gear Collar Set Screw	...	...	...	...	...	0	0	4
H.C.	31	Spline Shaft	...	...	...	...	...	0	11	6
H.C.	32	Positive Feed Worm Bearing	...	...	...	...	...	0	2	6
H.C.	33	Set Screw for H.C. 32	...	...	...	...	...	0	0	3
H.C.	34	Insulating Coupling Complete	...	...	...	...	...	0	11	6
H.C.	34A	Insulating Coupling and Shaft Complete	...	...	...	...	...	1	5	0
H.C.	34O	Mica for Insulating Coupling	...	...	...	...	...	0	2	6
H.C.	34P	Mica Holder for Insulating Coupling...	...	...	...	...	...	0	1	0
H.C.	34H	Pin for Mica for Coupling	...	...	...	...	...	0	0	3
H.C.	34B	Taper Pin for Insulating Coupling	...	...	...	...	...	0	0	3
H.C.	34C	Insulating Coupling Universal Joint	...	...	...	...	...	0	10	0
H.C.	34D	Insulating Coupling Cotter Pin	...	...	...	...	...	0	0	3
H.C.	35	Positive Feed Worm	...	...	...	...	...	1	7	6
H.C.	36	Positive Feed Worm Jaw and Locking Weight	...	...	...	...	...	0	10	6
		Assembled	...	...	...	...	...	0	10	6
H.C.	37	Positive Feed Pilot	...	...	...	...	...	0	0	9

			£	s.	d.
H.C.	38	Positive Feed Worm Thrust Collar ...	...	0	1 6
H.C.	39A	Positive Carbon Holder Carriage Assembled	...	2	5 0
H.C.	39	Positive Carbon Holder Carriage ...	...	1	5 0
H.C.	40	Rotating Gear (lower) ...	...	0	7 6
H.C.	41	Rotating Gear (upper) ...	...	0	14 0
H.C.	43	Positive Carbon Holder 11 m/m or 13.6 m/m	...	0	8 0
H.C.	44	Positive Carbon Holder Set Screw ...	...	0	2 0
H.C.	45	Negative Feed Worm Bearing ...	...	0	2 6
H.C.	46	Negative Feed Worm ...	...	0	10 6
H.C.	47	Negative Feed Worm Releasing Spring ...	...	0	1 3
H.C.	48	Negative Feed Worm Releasing Collar ...	...	0	1 0
H.C.	49	Negative Feed Worm Collar and Cotter Pin	...	0	1 6
H.C.	50	Connecting Rod Brass Washer ...	...	0	0 3
H.C.	51	Negative Feed Pilot ...	...	0	0 9
H.C.	52	Negative Cross Head ...	...	0	14 0
H.C.	53	Positive and Negative Feed Pilot Set Screw	...	0	0 3
H.C.	54	Connecting Rod Lug Screw and Nut ...	...	0	0 3
H.C.	55	Connecting Rod Insulating Bushing ...	...	0	0 9
H.C.	56	Connecting Rod Insulating Washer ...	...	0	0 6
H.C.	57	Connecting Rod Nut ...	...	0	0 4
H.C.	58A	Connecting Rod Lower ...	...	0	5 0
H.C.	58B	Connecting Rod Upper ...	...	0	5 0
H.C.	58C	Lower Connecting Rod Cotter Pin ...	...	0	0 2
H.C.	59	Negative Carriage ...	...	0	11 6
H.C.	61	Washer for H.C. 64 ...	...	0	0 2
H.C.	62	Negative Carbon Holder Screw ...	...	0	0 5
H.C.	64	Negative Carbon Clamp Screw ...	...	0	2 6
H.C.	65	Negative Carriage Shunt ...	...	0	3 6
H.C.	66	Positive Shunt Screw ...	...	0	1 6
H.C.	67	Negative Guide Head ...	...	1	17 6
H.C.	67A	Negative Guide Head Complete ...	...	3	10 0
H.C.	68	Negative Terminal Extension Bracket ...	...	0	12 6
H.C.	70	Screws for H.C. 67 ...	...	0	0 9
H.C.	71	Negative Shunt Screw H.C. 65—H.C. 67	...	0	1 3
H.C.	72	Negative Shunt Screw H.C. 60—H.C. 65	...	0	0 9
H.C.	75	Lamp Terminal Screw ...	...	0	0 6
H.C.	76	Lamp Terminal Clamp ...	...	0	3 9
H.C.	80	Positive and Negative Rotating Shaft ...	...	0	3 0
H.C.	81	Rotating Shaft ...	...	0	3 0
H.C.	82	Cotter Pins for Shafts H.C. 80—H.C. 81	...	0	0 2
H.C.	85	Negative Head Mica Plate ...	...	0	3 0
H.C.	86	Main Lead Assembled ...	...	1	0 0
H.C.	87	Main Lead Lug ...	...	0	1 6
H.C.	92	Lamp Support Screw Insulating Bush ...	...	0	0 9
H.C.	93	Lamp Support Screw Washer ...	...	0	0 2
H.C.	94	Lamp Support Screw Insulating Washer ...	...	0	0 9
H.C.	95	Lamp Frame Asbestos Insulating Plate ...	...	0	3 6
H.C.	95B	Lamp Frame Mica Insulating Plate ...	...	0	1 6
H.C.	99	Open End Wrench 1/4 X 1/6 ...	...	0	2 0
H.C.	160	Negative Carbon Holder ...	...	0	17 6
H.C.	163	Negative Carbon Clamp ...	...	0	6 0
H.C.	169	Negative Clamp Pin ...	...	0	1 0
H.C.	120	Negative Flame Shield ...	...	0	6 6
H.C.	201	Focussing Carriage ...	...	1	5 0
H.C.	202	Swivel Stand ...	...	0	12 6
H.C.	203	Lamp Bracket ...	...	0	10 0
H.C.	204	Swivel Stand Screw ...	...	0	3 6
H.C.	205	Focussing Pilot Screw ...	...		
H.C.	206	Focussing Pilot Screw Nut ...	pr.	0	2 3

							£	s.	d.
H.C.	207	Slide Adjusting Screw	...	...	...	...	0	7	6
H.C.	208	Universal Sleeve	...	...	...	...	0	1	3
H.C.	209	Universal Sleeve Cotter Pin	...	...	...	...	0	0	2
H.C.	210	Vertical Adjusting Screw	...	...	...	...	0	3	3
H.C.	211	Lamp Bracket Pivot Screw	...	...	...	...	0	1	9
H.C.	212	Vertical Adjusting Screw Stop Nut and Set Screw	...	...	...	...	0	2	3
H.C.	308	Lamphouse Cleaning Box	...	...	...	...	0	2	9

CONTROL UNIT PARTS.

							£	s.	d.
H.C.	400A	Control Unit Assembled (less motor) includes							
		Mechanism Plate Assembled	...	...	...	...	15	0	0
H.C.	401	Control Mounting Plate	...	...	...	...	0	17	6
H.C.	404	Carbon Tube	...	...	...	...	0	3	0
H.C.	407A	Positive Feed Handle Assembled	...	...	...	...	0	12	6
H.C.	407S	Positive Feed Handle	...	...	...	...	0	7	6
H.C.	407O	Positive Feed Handle Knob Set Screw	...	...	...	...	0	0	3
H.C.	408	Positive Feed Handle Set Screw	...	...	...	...	0	0	3
H.C.	409	Negative Feed Handle Knob	...	...	...	...	0	2	6
H.C.	409B	Negative Feed Handle Knob Screw	...	...	...	...	0	0	3
H.C.	409C	Negative Feed Handle Knob Nut	...	...	...	...	0	0	3
H.C.	410A	Negative Feed Handle Assembled	...	...	...	...	0	15	6
H.C.	410B	Negative Feed Handle Set Screw	...	...	...	...	0	0	3
H.C.	410H	Negative Feed Handle	...	...	...	...	0	15	0
H.C.	410.O	Negative Feed Handle Knob Set Screw	...	...	...	...	0	0	6
H.C.	456A	Motor Armature Assembled	...	...	...	...	2	10	0
H.C.	456C	Motor Armature Plain Bearing (commutator end)	...	...	...	...	0	3	0
H.C.	456G	Motor Armature Grooved Bearing (gear end)	...	...	...	...	0	3	0
H.C.	456S	Motor Armature Thrust Washers	...	...	...	...	0	0	3
H.C.	457A	Motor Brush and Spring Assembled	...	...	...	...	0	1	6
H.C.	457B	Motor Brush	...	...	...	...	0	1	0
H.C.	457S	Motor Brush Spring	...	...	...	...	0	0	9
H.C.	459	Motor Terminal Insulating Sleeve	...	...	...	...	0	0	9
H.C.	460	Motor Brush Cap	...	...	...	...	0	1	0
H.C.	460L	Motor Lubricator	...	...	...	...	0	1	6
H.C.	464	Worm	...	...	...	...	0	15	0
H.C.	465	Worm Fastening Pin	...	...	...	...	0	0	3
H.C.	466	Worm Gear	...	...	...	...	0	12	6
H.C.	466S	Worm Gear Fastening Pin	...	...	...	...	0	0	6
H.C.	467	Worm Gear Shaft	...	...	...	...	0	2	6
H.C.	468	Worm Gear Shaft Sprocket	...	...	...	...	0	10	6
H.C.	468S	Worm Gear Shaft Sprocket Pin	...	...	...	...	0	0	3
H.C.	485A	Upper Mechanism Cover	...	...	...	...	0	12	6
H.C.	485B	Lower Mechanism Cover	...	...	...	...	0	10	0
H.C.	486	Mechanism Cover Screw	...	...	...	...	0	0	3
H.C.	487	Carbon Tube Clamp	...	...	...	...	0	1	6
H.C.	488	Carbon Tube Clamp Screw	...	...	...	...	0	0	3
H.C.	489A	Feed Handle Plunger	...	...	...	...	0	3	6

MOTOR AND CONTROL MECHANISM PARTS.

							£	s.	d.
H.C.	402A	Control Mechanism Assembled	...	...	...	...	6	0	0
H.C.	402	Mechanism Plate...	...	...	...	...	2	10	0
H.C.	403	Mechanism Plate Fastening Screw	...	...	...	...	0	0	3
H.C.	403B	Mechanism Plate Fastening Screw Lock Washer	...	...	...	...	0	0	3
H.C.	425	Rotating Chain Guide Bracket	...	...	...	...	0	8	6
H.C.	425B	Rotating Chain Guide	...	...	...	...	0	10	6
H.C.	426	Motor Chain	...	...	...	...	0	18	6

								£	s.	d.
H.C.	427	Rotating Sprocket (small)	...	...	...	...	...	0	6	0
H.C.	428	Motor Sprocket (large)	...	...	...	...	...	0	10	6
H.C.	429	Rotating Chain Guide Bracket Fastening Screw	...	...	...	...	...	0	0	3
H.C.	433	Positive Handle Spur Gear	...	...	...	...	...	0	10	6
H.C.	434	Positive Feed Spur Gear	...	...	...	...	...	0	7	0
H.C.	435	Negative Handle Spur Gear	...	...	...	...	...	0	10	6
H.C.	436	Negative Feed Spur Gear	...	...	...	...	...	0	7	0
H.C.	437	Rotating Chain Guide Fastening Screw	...	...	...	...	...	0	1	3
H.C.	438	Rotating Sprocket (large)	...	...	...	...	...	0	12	0
H.C.	439	Rotating Chain	...	...	...	...	...	0	14	0
H.C.	440	Taper Pin for H.C. 427...	...	...	...	...	...	0	0	2
H.C.	441	Taper Pin for H.C. 434 and H.C. 436	...	...	...	...	...	0	0	2
H.C.	451A	Motor Unit Complete with Gears and Mounting Plate	...	...	...	...	...	8	0	0
H.C.	451	Motor Mounting Plate	...	...	...	...	...	0	11	6
H.C.	453	Motor Fastening Screw	...	...	...	...	...	0	0	4
H.C.	454	Motor Fastening Screw Washer	...	...	...	...	...	0	0	2
H.C.	455A	Motor Complete with Gears	...	...	...	...	...	7	10	0
H.C.	455	Motor (only)	...	...	...	...	...	5	0	0
H.C.	461	Gear Case	...	...	...	...	...	2	10	0
H.C.	461B	Gear Case Fastening Screws	...	...	...	...	...	0	0	3
H.C.	461C	Gear Case Fastening Screw Nut	...	...	...	...	...	0	0	3
H.C.	462	Gear Case Cover	...	...	...	...	...	0	7	6
H.C.	463	Gear Case Cover Screw	...	...	...	...	...	0	0	3
H.C.	471A	Pawl Carriage Assembled	...	...	...	...	...	1	5	0
H.C.	471	Pawl Carriage	...	...	...	...	...	0	13	0
H.C.	472	Positive Pawl	...	...	...	...	...	0	5	0
H.C.	472S	Positive Pawl Stop	...	...	...	...	...	0	1	6
H.C.	472P	Positive Pawl Shaft Cotter Pin	...	...	...	...	...	0	0	2
H.C.	473	Negative Pawl	...	...	...	...	...	0	5	0
H.C.	473S	Negative Pawl Stop	...	...	...	...	...	0	1	6
H.C.	473P	Negative Pawl Cotter Pin	...	...	...	...	...	0	0	2
H.C.	474	Pawl Spring	...	...	...	...	...	0	1	0
H.C.	475	Pawl Adjusting Spring	...	...	...	...	...	0	0	9
H.C.	475B	Pawl Adjusting Screw	...	...	...	...	...	0	0	3
H.C.	476A	Positive Feed Ratchet	...	...	...	...	...	0	5	6
H.C.	477A	Negative Feed Ratchet	...	...	...	...	...	0	5	6
H.C.	478	Feed Ratchet Washer	...	...	...	...	...	0	0	2
H.C.	479	Feed Ratchet Collar	...	...	...	...	...	0	1	3
H.C.	480	Feed Ratchet Cotter Pin	...	...	...	...	...	0	0	2
H.C.	481A	Feed Drive Crank	...	...	...	...	...	0	10	6
H.C.	482	Ratchet Brake Spring	...	...	...	...	...	0	1	0
H.C.	483	Screw and Washer for H.C. 482	...	...	...	...	...	0	0	4

POTENTIOMETER PARTS.

								£	s.	d.
H.C.	412L	Potentiometer Mounting Bracket	...	...	...	...	...	0	10	0
H.C.	412M	Potentiometer Mounting Bracket Screw and Nut	...	...	...	...	...	0	0	2
H.C.	413A	Potentiometer Assembled	...	...	...	...	...	2	5	0
H.C.	413B	Potentiometer Fix Screw	...	...	...	...	...	0	0	3
H.C.	413C	Potentiometer Fix Nuts	...	...	...	...	...	0	0	3
H.C.	414	Potentiometer Porcelain Base	...	...	...	...	...	0	7	6
H.C.	415	Potentiometer Metal Cover	...	...	...	...	...	0	3	6
H.C.	416	Potentiometer Regulating Knob	...	...	...	...	...	0	2	6
H.C.	416B	Potentiometer Regulating Knob Set Screw	...	...	...	...	...	0	0	3
H.C.	417	Potentiometer Resistance Unit	...	...	...	...	...	0	15	0
H.C.	417B	Potentiometer Resistance Unit Fix Screw	...	...	...	...	...	0	0	2
H.C.	417C	Potentiometer Resistance Unit Fix Screw Nut	...	...	...	...	...	0	0	2

							£	s.	d.
H.C.	418	Potentiometer Contact Roller	...	...	...	...	0	2	6
H.C.	430	Potentiometer Contact Yoke ...	...	...	...	...	0	0	6
H.C.	431	Potentiometer Contact Spring	...	...	...	...	0	1	0
H.C.	432	Potentiometer Terminal Clamp Washer	...	...	...	...	0	0	2
H.C.	432B	Potentiometer Terminal Screw	...	...	...	...	0	0	6
H.C.	432C	Potentiometer Terminal Lock Nut	...	...	...	...	0	0	2
H.C.	432D	Potentiometer Terminal Screw Clip	...	...	...	...	0	0	2
H.C.	444	Potentiometer Scale	...	...	...	...	0	3	0
H.C.	445	Potentiometer Scale Pointer	...	...	...	...	0	1	6

FLEXIBLE CABLE AND CABLE ARMOURING.

							£	s.	d.
H.C.	419	Flexible Cable from Main Line to Potentiometer					0	5	6
H.C.	419B	Armouring for Flexible Cable	...	...	...	...	0	2	0
H.C.	420	Flexible Cable from Motor to Potentiometer	...				0	5	0
H.C.	420B	Armouring for Flexible Cable	...	...	...	...	0	1	0
H.C.	420C	Flexible Cable Spade Terminals	...	...	...	...	0	0	4
H.C.	421M	Half Elbow for Cable Armouring	...	...	...	...	0	2	0
H.C.	423	Clip for Cable Armouring	...	...	...	...	0	0	9
H.C.	424	Clip Fastening Screw and Nut	...	...	...	...	0	0	2
H.C.	1821L	Elbow for Cable Armouring	...	...	...	...	0	1	6
H.C.	1466	Pilot Lamp Holder	...	...	...	...	0	6	0
H.C.	1467B	Elbow for Cable Armouring	...	...	...	...	0	2	3
H.C.	1467F	Connector for Cable Armouring	...	...	...	...	0	3	0
H.C.	1467G	Flexible Armouring	...	...	...	...	0	2	6
H.C.	1467H	Flexible Cable for Pilot Lamp	...	...	...	...	0	1	6

ARCSCOPE PARTS.

							£	s.	d.
H.C.	1000A	Arcscope Assembled	...	...	...	...	0	17	6
H.C.	1001	Arcscope Plate	...	...	...	...	0	4	6
H.C.	1002	Arcscope Plate Screw	...	...	...	...	0	0	3
H.C.	1003	Arcscope Casting	...	...	...	...	0	2	9
H.C.	1005	Arcscope Lens	...	...	...	...	0	2	6
H.C.	1006	Arcscope Lens Retaining Ring	...	...	...	...	0	0	6
H.C.	1007	Arcscope Mirror Mounting	...	...	...	...	0	4	6
H.C.	1008	Arcscope Mirror	...	...	...	...	0	1	3
H.C.	1010	Arcscope Casting Lock Nut	...	...	...	...	0	0	9

LAMPHOUSE PARTS.

							£	s.	d.
H.C.	1402	Lamphouse Base Casting	...	...	...	...	3	10	0
H.C.	1403	Lamphouse Door (left)...	...	...	...	...	1	5	0
H.C.	1404	Lamphouse Door Hinge Pin	...	...	...	...	0	1	0
H.C.	1405	Lamphouse Door (right)	...	...	...	...	1	5	0
H.C.	1406	Lamphouse Hood Baffle Plate	...	...	...	...	0	5	0
H.C.	1406B	Lamphouse Hood Baffle Plate Screw	...	...	...	...	0	0	2
H.C.	1406C	Lamphouse Hood Baffle Plate Nut	...	...	...	...	0	0	2
H.C.	1414	Lamphouse Base Insulating Plate	...	...	...	...	0	2	0
H.C.	1415	Lamphouse Box Insulating Plate	...	...	...	...	0	1	0
H.C.	1417	Lamphouse 6 in Damper Assembled	...	...	...	...	0	7	6
H.C.	1419A	Door Stop Links Assembled	...	...	...	...	0	5	6
H.C.	1419C	Door Stop Fastening Screw	...	...	...	...	0	0	2
H.C.	1419D	Door Stop Fastening Screw Nut	...	...	...	...	0	0	2
H.C.	1424	Focussing Guide Bracket Screw	...	...	...	...	0	0	2
H.C.	1434	Lamp Base Vent Screen	...	...	...	...	0	7	6
H.C.	1445	Lamphouse Door Catch (left hand)	...	...	...	...	0	3	0
H.C.	1446	Lamphouse Door Catch (right hand)	...	...	...	...	0	3	0

							£	s.	d.
H.C.	1449	Lamphouse Door Catch Screw	...	...	...	...	0	0	6
H.C.	1449C	Lamphouse Door Catch Screw Nut	...	...	...	...	0	0	3
H.C.	1450	Inside Dowser Handle	...	...	...	...	0	5	0
H.C.	1452	Inside Dowser Handle Knob	...	...	...	...	0	1	9
H.C.	1455	Inside Dowser Shaft	...	...	...	...	0	0	6
H.C.	1456	Inside Dowser Bracket	...	...	...	...	0	15	0
H.C.	1458	Inside Dowser Bracket Insulating Plate	...	...	...	...	0	0	6
H.C.	1459	Inside Dowser Arm	...	...	...	...	0	8	6
H.C.	1460	Inside Dowser Arm Insulating Bush	...	...	...	...	0	0	6
H.C.	1461	Inside Dowser Arm Insulating Washer	...	...	...	...	0	0	2
H.C.	1462	Inside Dowser Arm Brass Washer	...	...	...	...	0	0	2
H.C.	1463	Inside Dowser Arm Screw	...	...	...	...	0	0	6
H.C.	1464A	Inside Dowser Assembled	...	...	...	...	1	5	0
H.C.	1464	Inside Dowser	...	...	...	...	0	10	6
H.C.	1470	Condenser Holder Frame Casting	...	...	...	...	0	18	0
H.C.	1480A	Condenser Holder Assembled with Rings	...	...	...	...	2	10	0
H.C.	1480	6 inch Condenser Ring	...	...	...	...	0	7	6
H.C.	1481A	Condenser Spacing Ring (B. & L Condenser)	...	...	...	...	0	5	0
H.C.	1481B	Condenser Spacing Ring (6 inch X 9 inch Condenser)	...	...	...	...	0	5	0
H.C.	1482	Condenser Holder Cap	...	...	...	...	0	10	6
H.C.	1483	Cap Fastening Stud	...	...	...	...	0	1	0
H.C.	1484	Cap Fastening Stud Pivot Screw	...	...	...	...	0	0	2
H.C.	1485	Cap Fastening Stud Nut	...	...	...	...	0	0	6
H.C.	1488	Lamphouse Cone	...	...	...	...	0	3	0
H.C.	1489	Lamphouse Cone Retaining Screw	...	...	...	...	0	0	2
H.C.	1490	Outside Dowser Bracket	...	...	...	...	0	2	0
H.C.	1491	Outside Dowser Bracket Fastening Screw	...	...	...	...	0	0	2
H.C.	1492	Outside Dowser Bracket Fastening Screw Nut	...	...	...	...	0	0	6
H.C.	1493A	Outside Dowser Disc Assembled	...	...	...	...	0	5	6
H.C.	1493S	Outside Dowser Disc (only)	...	...	...	...	0	2	6
H.C.	14930	Outside Dowser Casting	...	...	...	...	0	5	0
H.C.	1495	Outside Dowser Disc Handle Screw	...	...	...	...	0	0	6
H.C.	1496	Outside Dowser Disc Pivot Screw	...	...	...	...	0	0	6
H.C.	1497	Outside Dowser Disc Pivot Screw Nut	...	...	...	...	0	0	6
H.C.	1499	Outside Dowser Disc Pivot Screw Washer	...	...	...	...	0	0	3
H.C.	1944	Outside Dowser Disc Handle	...	...	...	...	0	1	0
H.C.	4026	Outside Dowser Pivot Screw Spring	...	...	...	...	0	0	6
H.C.	4015	Lamphouse Door Latch Nut	...	...	...	...	0	0	6
H.C.	1907	Peep Sight Frame (outside)	...	...	...	...	0	2	0
H.C.	1909	Peep Sight Frame (inside)	...	...	...	...	0	1	6
H.C.	1911	Peep Sight Glass	...	...	...	...	0	0	6
H.C.	1912	Peep Sight Wire Mesh	...	...	...	...	0	0	2
H.C.	1918A	Focussing Guide Unit	...	...	...	...	0	3	6
H.C.	1918	Focussing Guide Rod	...	...	...	...	0	1	0
H.C.	1920	Focussing Rod Collar	...	...	...	...	0	1	0
H.C.	1922	Focussing Guide Bracket Front	...	...	...	...	0	2	6
H.C.	1923	Focussing Guide Bracket Rear	...	...	...	...	0	2	6
H.C.	1926	Focussing Rod	...	...	...	...	0	5	6
H.C.	1941	Lamphouse Door Latch Pin Holder	...	...	...	...	0	4	0
H.C.	1942	Lamphouse Door Latch Pin Casting	...	...	...	...	0	2	0
H.C.	1943	Lamphouse Door Latch Pin	...	...	...	...	0	1	0
H.C.	407S	Focussing Rod Handle	...	...	...	...	0	4	6
H.C.	4015	Tie Rod Nut	...	...	...	...	0	0	4
H.C.	308	Lamphouse Cleaning Box	...	...	...	...	0	1	6

Prices subject to Alteration.