


# PARTS LIST

Supplement  
to Catalog No. L-45

**Conversion Kits & Parts  
For CinemaScope Installations**

**Aperture Plates For  
Standard & Wide Screen  
Presentations**



Products of

**LAVEZZI MACHINE WORKS**

4635 WEST LAKE ST.  
CHICAGO 44, ILL., U.S.A.



# CINEMASCOPE CONVERSION KITS & PARTS

## **CS-1000      CinemaScope Conversion Kit for Regular or Super Simplex Mechanism**

BB-42-C      Intermittent Sprocket  
W-145-DC      Upper Sprocket  
W-146-DC      Lower Sprocket  
P-102-CC      Pad Roller (3)  
E-3-C      Tension Shoe  
P-672-E-10      Aperture Plate

## **CS-1010      CinemaScope Conversion Kit for E-7 Mechanism**

BB-47-C      Intermittent Sprocket  
S-1283-CC      Upper Sprocket  
S-1284-CC      Lower Sprocket  
P-102-CC      Pad Roller (2)  
E-73-C      Tension Shoe  
E-72-10      Aperture Plate

## **CS-1015      CinemaScope Conversion Kit for X-L Mechanism**

G-2330      Intermittent Sprocket  
G-2332      Upper and Lower Sprocket (2)  
P-3085      Pad Roller (4)

## **CS-1020      CinemaScope Conversion Kit for Century "C" and "CC" Mechanism**

SK-102-BBC      Intermittent Sprocket  
SK-11-DC      Upper Sprocket  
SK-12-DC      Lower Sprocket  
RO-15-CC      Pad Roller (2)  
PE-5-E-10      Aperture Plate

## **CS-1030      CinemaScope Conversion Kit for RCA Models 1050, 1060, 9030 and 9050**

23681-C      Constant Speed Sprocket  
21432-C      Take-up Sprocket  
21507-C      Pad Roller (3)

## **CS-1040      CinemaScope Conversion Kit for RCA Model 1040**

23681-C      Constant Speed Sprocket  
21432-C      Take-up Sprocket  
21507-C      Pad Roller (2)

## **CS-1050      CinemaScope Conversion Kit for RCA Model PS-24**

25550-C      Constant Speed Sprocket  
21432-C      Take-up Sprocket  
21507-C      Pad Roller (2)

## **CS-1060      CinemaScope Conversion Kit for Western Electric Models 206 and 208**

TA-7393-C      Sound Sprocket  
TA-7318-C      Hold-back Sprocket  
ASL-6923-C      Pad Roller (2)

## **CS-1070      CinemaScope Conversion Kit for Western Electric Model TA-7400**

ASL-6922-C      Feed Sprocket  
ASL-6925-C      Hold-Back Sprocket  
ASL-6923-C      Pad Roller (2)

## **CS-1080      CinemaScope Conversion Kit for 4-Star Model SH-1000**

SN-122-C      Sound Sprocket  
SN-123-C      Hold-Back Sprocket  
SN-130-C      Pad Roller (3)

## **CS-1090      CinemaScope Conversion Kit for Soundmaster**

500-HC      Sound Sprocket (2)  
P-102-CC      Pad Roller (2) (7/32 bore)

SK-967      CinemaScope Sound Sprocket for Century Sound Reproducer  
375-35-32-C      Special CinemaScope Sound Sprocket, 32 teeth,  $\frac{3}{8}$ " bore  
500-35-32-C      Special CinemaScope Sound Sprocket, 32 teeth,  $\frac{1}{2}$ " bore



# REPLACE APERTURES QUICKLY with the **NEW** *LaVeZZi* SPRING LOADED

## APERTURE PLATE!



Remove one aspect ratio plate and replace with another—zip-zip—that quick! The blue tempered spring steel wedge holds plate firmly in place and the new finger grip facilitates rapid removal. Eliminates the P-445-E Sliding Piece.

At your Theatre Equipment Dealers Now

MANUFACTURED BY

**LaVeZZi MACHINE WORKS**

4635 WEST LAKE ST.

CHICAGO 44, ILL.

**SUPER-**  
*LaVeZZi*  
**SERVICE**  
REG.U.S.PAT.OFF.

The list of apertures below covers such a wide range of sizes that laborious filing from blanks is no longer a necessity. All LaVeZZi plates are made to closest tolerances, with all openings accurately positioned and sized. Each plate is stamped with the opening size or ratio and is individually packaged at the factory.

The following tools are made available specifically for filing of keystone corrections wherever necessary:

AF-13	Flat file
AFC-15	Half-round file

## APERTURE PLATES

For Regular or Super Simplex	For Regular Simplex	For E-7 Projectors	For Century Projectors
Regular Plate	Springloaded Plate		

The following are for Regular projection with Single Optical Sound Track.

Ratio	Size	Part No.	Part No.	Part No.	Part No.
1.33:1	Standard	P-672-E	SP-672-E	E-72	PE-5-E
	Undersize	P-672-E-0	SP-672-E-0	E-72-0	PE-5-E-0
1.66:1	Standard	P-672-E-1	SP-672-E-1	E-72-1	PE-5-E-1
	Undersize	P-672-E-2	SP-672-E-2	E-72-2	PE-5-E-2
1.85:1	Standard	P-672-E-3	SP-672-E-3	E-72-3	PE-5-E-3
	Undersize	P-672-E-4	SP-672-E-4	E-72-4	PE-5-E-4
1.75:1	Standard	P-672-E-5	SP-672-E-5	E-72-5	PE-5-E-5
	Undersize	P-672-E-6	SP-672-E-6	E-72-6	PE-5-E-6
2:1	Standard	P-672-E-7	SP-672-E-7	E-72-7	PE-5-E-7
	Undersize	P-672-E-8	SP-672-E-8	E-72-8	PE-5-E-8

The following are for Anamorphic projection with Magnetic Sound.

2.55:1	Undersize	.650 x .850	P-672-E-10	SP-672-E-10	E-72-10	PE-5-E-10
2:1	Undersize	.650 x .650	P-672-E-12	SP-672-E-12	E-72-12	PE-5-E-12

The following are for Anamorphic projection with Single Optical Sound Track.

2.33:1	Standard	.715 x .839	P-672-E-13	SP-672-E-13	E-72-13	PE-5-E-13
	Undersize	.650 x .775	P-672-E-14	SP-672-E-14	E-72-14	PE-5-E-14
2:1	Standard	.715 x .715	P-672-E-15	SP-672-E-15	E-72-15	PE-5-E-15
	Undersize	.715 x .650	P-672-E-16	SP-672-E-16	E-72-16	PE-5-E-16
	Undersize	.650 x .650	P-672-E-17	SP-672-E-17	E-72-17	PE-5-E-17

P-445-E Aperture Plate Sliding Piece, for use with P-672-E Series of aperture plates only, on regular or Super Simplex Projectors—New design with curved finger grip to facilitate rapid removal of the aperture plate.



# SUPPORT BRACKETS FOR B&L ANAMORPHIC LENS

AB-1	Support Bracket Assembly for Series I Lens, for Super Simplex or E-7 Projectors (Illustrated on front cover)
AB-2	Support Bracket Assembly for Series II Lens, for Super Simplex or E-7 Projectors
AB-3	Support Bracket Assembly for Series I Lens, for X-L Projector
AB-4	Support Bracket Assembly for Series II Lens, for X-L Projector

## PROJECTOR SUB-ASSEMBLIES WITH CINEMASCOPE PARTS

BB-33-C	Starwheel Shaft and Sprocket Assembly—Same as BB-33 except with CinemaScope Sprocket BB-42-C
BB-66-C	Complete Intermittent Movement Assembly for Regular Simplex Projector — Same as BB-66 except with CinemaScope Sprocket BB-47-C
BB-77-C	Complete Intermittent Movement Assembly for Super Simplex Projector—Same as BB-77 except with CinemaScope Sprocket BB-47-C
E-78-L-C	Removeable Film Trap Door Assembly for Regular Simplex—Same as E-78-L except with CinemaScope Tension Shoe E-73-C
E-78-LS-C	Removeable Film Trap Door Assembly for Super Simplex—Same as E-78-LS except with CinemaScope Tension Shoe E-73-C
RK-102-C	Intermittent Movement Repair Kit—Same as RK-102 except with BB-42-C Intermittent Sprocket for CinemaScope
RK-103-C	Intermittent Movement Repair Kit—Same as RK-103 except with BB-47-C Intermittent Sprocket for CinemaScope
SCS-2-C	Intermittent Movement Repair Kit—Same as SCS-2 except with BB-42-C Intermittent Sprocket for CinemaScope
SCSB-3-C	Intermittent Movement Repair Kit—Same as SCSB-3 except with BB-47-C Intermittent Sprocket for CinemaScope
A-8-L	Focusing Pinion Knob Assembly — This is a new assembly for use on Regular Simplex where a Penthouse Soundhead or other unit has been installed making a longer knob necessary — The knob is 3-1/16" high overall, and has a 6" focusing rod.