

# PARTS LIST

FOR



**CENTURY PROJECTOR CORPORATION**

729 SEVENTH AVENUE • NEW YORK, N. Y.



THE LIBRARY

OF



1900

UNIVERSITY OF MICHIGAN

ANN ARBOR, MICHIGAN



## THE CENTURY PROJECTOR CORPORATION

729 - 7th Ave.  
New York City  
U. S. A.

This catalogue represents only a portion of the products manufactured by the Century Projector Corporation, including only those replacement parts made expressly for the Century Model "K" (Kaplan) Standard and Super Type mechanisms.

Our parts are manufactured in a modern American factory, on precision machines, by highly skilled workmen. After twenty-five years experience in the manufacture of our parts, a standard of uniformity and accuracy has been attained which assures interchangeability and perfect operating results.

Wherever necessary our parts are hardened by modern scientific processes, machined and ground to an accuracy of 0.0001 of an inch, giving improved screen reproduction and favorable audience acceptance.

Our parts are distributed in every country of the World and they are used exclusively in the United States by leading repair shops and service organizations for the rebuilding and repair of projector mechanisms.

WHEN PLACING ORDERS FOR THESE PARTS IT WILL AVOID CONFUSION AND ASSURE MORE PROMPT SHIPMENT, IF EACH ITEM IS IDENTIFIED BY PART NUMBER AS INDICATED IN THIS CATALOGUE.


In addition to the manufacture of these replacement parts, the Century Projector Corporation also produces and enjoys world wide distribution of its well known Century Model "C" Single Shutter and Model "CC" Double Shutter projector mechanisms which have become a standard of precision for the reproduction of motion pictures in leading theaters thruout the United States and the World.




## C O N T E N T S

| GROUP                                                      | PAGE     |
|------------------------------------------------------------|----------|
| Main Drive Shaft, Oil Tubes, Framing Cam.....              | 9        |
| Lens Holders, Lens Focus.....                              | 9        |
| Main Frame, Base and Assemblies.....                       | 10       |
| Single Bearing Intermittent Movement & Assemblies.....     | 10       |
| Double Bearing Intermittent Movement & Assemblies.....     | 11-12    |
| Upper and Lower Pad Roller Arms and Assemblies.....        | 13       |
| Upper Roller Holder, Governor Lifts, Gate Trip Levers..... | 14       |
| Doors and Covers, Governor Weights.....                    | 15-16    |
| Upper and Lower Sprockets, Front Shutters and Spiders      | 17-22    |
| Rear Shutter Attachment and Assemblies.....                | 19-20-21 |
| Film Gates, Holder, and Fire Shutter.....                  | 23-25    |
| Lateral Guide Rollers.....                                 | 24       |
| Film Traps, Apertures, Shoes and Assemblies.....           | 24-25    |
| Intermediate Shaft and Gears.....                          | 27       |
| Shutter Gear Bracket and Assemblies.....                   | 27       |
| Vertical Shaft & Gears—Sprocket Shafts and Gears.....      | 28       |
| Main Drive Gears, Framing Assemblies.....                  | 29       |
| Super Type Parts.....                                      | 30-31-32 |
| Parts Price List.....                                      | 33       |































# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                                                  |
|-------------|----------------------------------------------------------------------------------------------|
| <b>A-1</b>  | <b>HANDLE SHAFT AND COLLAR</b>                                                               |
| C-126-A     | Main Drive Gear Clutch                                                                       |
| C-189-A     | Handle Shaft Driving Collar                                                                  |
| P-115-A     | Handle Shaft Driving Collar Pin (2)                                                          |
| S-287-A     | Handle Shaft *                                                                               |
| <b>A-2</b>  | <b>SHUTTER ADJUSTING SCREW AND KNOB</b>                                                      |
| K-120-A     | Shutter Adjusting Screw Knob                                                                 |
| S-125-B     | Shutter Adjusting Screw Knob Set Screw                                                       |
| S-252-A     | Shutter Adjusting Screw                                                                      |
| <b>A-4</b>  | <b>LENS HOLDER AND SLIDE</b>                                                                 |
| C-38        | Lens Holder Clamp Knob and Screw                                                             |
| H-149-A     | Lens Holder (includes P-124-A and C-38)                                                      |
| P-124-A     | Focusing Slide Gib Pin                                                                       |
| R-150-A     | Lens Holder Slide Guide Rod (2)                                                              |
| S-161-E     | Lens Holder Slide Stop Screw (2)                                                             |
| S-322-A     | Lens Holder Slide                                                                            |
| S-342-A     | Lens Holder Slide Guide Rod Spring (2)                                                       |
| W-118-A     | Lens Holder Slide Guide Rod Washer (2)                                                       |
| <b>A-5</b>  | <b>HANDLE SHAFT OIL TUBE AND WIRE</b>                                                        |
| <b>A-6</b>  | <b>LOWER SPROCKET SHAFT OIL TUBE AND WIRE</b>                                                |
| <b>A-7</b>  | <b>FRAMING CAM, ARM AND PIN</b><br>(DESIGNATE IF FOR USE ON D-90 MECHANISM OR FRONT SHUTTER) |
| <b>A-8</b>  | <b>FOCUSING PINION KNOB</b>                                                                  |
| K-131-A     | Focusing Pinion Knob                                                                         |
| R-178-A     | Focusing Pinion Rod                                                                          |
| S-141-A     | Focusing Pinion Knob Set Screw                                                               |
| S-756-A     | Focusing Pinion Clamp Screw                                                                  |
| <b>A-9</b>  | <b>LENS HOLDER AND SLIDE (MASS. REQUIREMENTS)</b>                                            |
| C-38        | Lens Holder Clamp Knob and Screw                                                             |
| H-149-A     | Lens Holder (includes P-124-A and C-38)                                                      |
| P-124-A     | Focusing Slide Gib Pin                                                                       |
| R-150-A     | Lens Holder Slide Guide Rod (2)                                                              |
| S-161-E     | Lens Holder Slide Stop Screw (2)                                                             |
| S-342-A     | Lens Holder Slide Guide Rod Spring (2)                                                       |
| S-494-A     | Focusing Rack Arm Fastening Screw                                                            |
| S-772-A     | Lens Holder Slide *                                                                          |
| S-783-A     | Lens Holder Slide Stop Screw (2)                                                             |
| W-118-A     | Lens Holder Slide Guide Rod Washer (2)                                                       |
| <b>A-24</b> | <b>PROJECTING LENS FOCUSING DEVICE</b>                                                       |
| B-342-A     | Focusing Device Bracket                                                                      |
| C-382-A     | Adjusting Knob Collar (2)                                                                    |
| G-228-A     | Focusing Gear                                                                                |
| K-136-A     | Adjusting Knob                                                                               |
| S-141-A     | Focusing Gear Screw                                                                          |
| S-885-A     | Adjusting Knob Fastening Screw (3)                                                           |
| S-1048-A    | Focusing Device Bracket Screw (2)                                                            |
| W-235-A     | Focusing Device Worm                                                                         |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

## PART NO.

## DESCRIPTION

### "A" PARTS

|         |                                               |
|---------|-----------------------------------------------|
| A-131-A | Focusing Rack Arm                             |
| B-127-A | Vertical Shaft Bracket                        |
| B-198-A | Centre Frame Base (New Style)                 |
| B-198-A | Centre Frame Base (Old style with boss)       |
| G-121-A | Focusing Slide Gib                            |
| L-130-A | Slide Stop Screw Lock                         |
| N-118-A | Picture Framing Handle Pivot Nut              |
| P-123-A | Adjusting Screw Lock Nut                      |
| P-106-A | Base Dowel Pin                                |
| P-167-A | Shutter Adjusting Slide Stop Pin              |
| P-188-A | Vertical Shaft Bracket Pin                    |
| P-189-A | Focusing Pinion                               |
| P-196-A | Picture Framing Handle Pivot                  |
| R-133-A | Framing Cam Adjusting Ring                    |
| S-115-A | Centre Frame Base Screw                       |
| S-118-L | Motor Drive Pinion Set Screw                  |
| S-143-A | Framing Cam Adjusting Ring Screw              |
| S-231-A | Centre Frame Base Oil Retaining Screw         |
| S-248-A | Roller Holder Screw                           |
| S-253-A | Shutter Adjusting Slide Lock Screw            |
| S-278-A | Pad Roller Arm Tension Spring Fastening Screw |
| S-283-A | Vertical Shaft Bracket Screw                  |
| S-323-A | Shutter Adjusting Slide                       |
| S-340-A | Lower Sprocket Roller Arm Spring, (Old Style) |
| S-343-A | Rack Arm Friction Spring                      |
| S-353-A | Upper Sprocket Roller Arm Spring, (Old Style) |
| S-386-A | Oil Tube Support                              |
| S-494-A | Focusing Rack Retaining Screw                 |
| S-569-A | Lower Sprocket Roller Arm Spring              |
| S-570-A | Upper Sprocket Roller Arm Spring              |

### "B"

### SINGLE BEARING INTERMITTENT MOVEMENT COMPLETE

#### B-1

#### INTERMITTENT CASE AND OIL TUBES

|         |                                 |
|---------|---------------------------------|
| C-120-B | Oil Tube Clamp                  |
| C-230-B | Intermittent Case *             |
| S-106-D | Oil Tube Clamp Screw            |
| T-106-B | Intermittent Case Oil Tube      |
| T-107-B | Flywheel and Cam Shaft Oil Tube |

#### B-4

#### ECCENTRIC BUSHING AND SLEEVE

#### B-8

#### INTERMITTENT CASE COVER AND CLAMPS

|          |                                        |
|----------|----------------------------------------|
| C-148-B  | Intermittent Case Cover *              |
| C-294-BB | Intermittent Case Cover Clamp (2)      |
| P-347-B  | Intermittent Case Cover Pin (2)        |
| S-125-B  | Eccentric Bushing Screw (2)            |
| S-157-B  | Intermittent Case Cover Lock Screw (2) |

#### B-9

#### STARWHEEL, SPROCKET AND BUSHING

|         |                                     |
|---------|-------------------------------------|
| B-4     | Eccentric Bushing                   |
| P-153-B | Intermittent Sprocket Taper Pin (2) |
| S-551-B | Starwheel and Shaft                 |
| W-131-B | Intermittent Sprocket               |

\*Parts Not Sold Separately



| PART NO.     | DESCRIPTION                                          |
|--------------|------------------------------------------------------|
| <b>B-14</b>  | <b>FLYWHEEL AND GEAR</b>                             |
| G-148-B      | Flywheel Gear                                        |
| S-692-B      | Flywheel Set Screw                                   |
| S-693-B      | Flywheel Set Screw Shoe                              |
| W-152-B      | Flywheel                                             |
| <b>B-15</b>  | <b>FLYWHEEL SHAFT AND GEAR</b>                       |
| G-105-B      | Flywheel Shaft Gear                                  |
| S-454-B      | Flywheel Shaft                                       |
| <b>B-16</b>  | <b>INTERMITTENT CAM COMPLETE</b>                     |
| BB-39        | Cam Shaft Lock Nut                                   |
| C-225-B      | Intermittent Cam *                                   |
| G-118-B      | Intermittent Cam Gear                                |
| P-279-B      | Intermittent Cam Pin                                 |
| W-122-B      | Intermittent Cam Washer                              |
| <b>B-32</b>  | <b>SINGLE BEARING SPROCKET PIN EJECTOR</b>           |
| W-105-B      | Flywheel Washer (Regular or oversize)                |
| <b>"BB"</b>  | <b>DOUBLE BEARING INTERMITTENT MOVEMENT COMPLETE</b> |
| <b>"BBB"</b> | <b>SUPER INTERMITTENT MOVEMENT COMPLETE</b>          |
| <b>BB-21</b> | <b>INTERMITTENT CASE ASSEMBLY</b>                    |
| C-293-BB     | Intermittent Oil Cup                                 |
| C-374-BB     | Intermittent Case *                                  |
| P-121-C      | Intermittent Adjusting Pivot                         |
| <b>BB-22</b> | <b>INTERMITTENT CASE COVER AND ARM COMPLETE</b>      |
| BB-40        | Intermittent Case Cover and Arm                      |
| B-248-BB     | Starwheel Shaft Inner Bearing                        |
| B-482-BB     | Starwheel Shaft Outer Bearing (oilless type)         |
| P-353-BB     | Case Retaining Clamp Pivot (2)                       |
| S-432-E      | Stripper Screw (2)                                   |
| S-724-BB     | Bearing Screw (6)                                    |
| S-731-BB     | Intermittent Film Stripper                           |
| <b>BB-26</b> | <b>STARWHEEL SHAFT AND SPROCKET ASSEMBLY</b>         |
| P-350-BB     | Intermittent Sprocket Pin (2)                        |
| S-730-BB     | Starwheel and Shaft (Hardened)                       |
| S-750-BB     | Intermittent Sprocket (Hardened)                     |
| <b>BB-27</b> | <b>FLYWHEEL SHAFT AND GEAR COMPLETE</b>              |
| G-187-BB     | Flywheel Shaft Gear                                  |
| S-726-BB     | Flywheel Shaft                                       |
| <b>BB-28</b> | <b>FLYWHEEL AND GEAR COMPLETE</b>                    |
| G-185-BB     | Flywheel Gear (includes W-232-BB)                    |
| W-191-BB     | Flywheel                                             |
| *            |                                                      |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.     | DESCRIPTION                                                                 |
|--------------|-----------------------------------------------------------------------------|
| <b>BB-30</b> | <b>FLYWHEEL LOCK NUT COMPLETE</b>                                           |
| K-130-BB     | Flywheel Lock Key                                                           |
| N-171-BB     | Flywheel Lock Nut                                                           |
| S-725-BB     | Flywheel Lock Nut Screw                                                     |
| <b>BB-31</b> | <b>OUTER BEARING OIL CUP COMPLETE</b>                                       |
| <b>BB-32</b> | <b>TAPER PIN EJECTOR</b>                                                    |
| B-254-BB     | Intermittent Sprocket Taper Pin Ejector Block                               |
| S-757-BB     | Intermittent Sprocket Taper Pin Ejector Screw                               |
| <b>BB-33</b> | <b>STARWHEEL SHAFT AND SPROCKET</b>                                         |
| P-350-BB     | Intermittent Sprocket Pin (2)                                               |
| S-750-BB     | Intermittent Sprocket (Hardened)                                            |
| S-951-BB     | Starwheel and Shaft (Hardened)                                              |
| <b>BB-34</b> | <b>INTERMITTENT CASE COVER AND ARM ASSEMBLY COMPLETE</b>                    |
| BB-52        | Intermittent Case Cover and Bearings Complete                               |
| BB-42        | Sprocket (Hardened and Ground) (includes 2 P-350-BB)                        |
| C-295-BB     | Starwheel Shaft Collar                                                      |
| S-177-E      | Collar Set Screw (2)                                                        |
| S-951-BB     | Starwheel and Shaft                                                         |
| <b>BB-38</b> | <b>INTERMITTENT CAM COMPLETE</b>                                            |
| BB-39        | Cam Shaft Lock Nut                                                          |
| C-301-BB     | Intermittent Cam *                                                          |
| G-186-BB     | Intermittent Cam Gear                                                       |
| P-360-BB     | Intermittent Cam Pin                                                        |
| <b>BB-39</b> | <b>CAM SHAFT LOCK NUT</b>                                                   |
| CL-306-BB    | Cam Shaft Lock Nut *                                                        |
| PG-301-BB    | Cam Shaft Lock Nut Plug *                                                   |
| SC-309-BB    | Cam Shaft Lock Nut Screw                                                    |
| <b>BB-40</b> | <b>INTERMITTENT CASE COVER AND ARM</b>                                      |
| A-192-BB     | Intermittent Case Cover and Arm *                                           |
| BB-31        | Outer Bearing Oil Cup                                                       |
| G-225-BB     | Oil Sight Gasket (Large) (4)                                                |
| G-226-BB     | Oil Sight Glass (Large) (2)                                                 |
| N-204-BB     | Oil Sight Glass Nut (Large) (2)                                             |
| P-353-BB     | Case Retaining Clamp Pivot Pin (2)                                          |
| <b>BB-42</b> | <b>INTERMITTENT SPROCKET (HARDENED AND GROUND)</b><br>(Includes 2 P-350-BB) |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.                   | DESCRIPTION                                          |
|----------------------------|------------------------------------------------------|
| <b>BB-52</b>               | <b>INTERMITTENT CASE COVER AND BEARINGS COMPLETE</b> |
| BB-40                      | Intermittent Case Cover and Arm                      |
| B-323-BB                   | Starwheel Shaft Inner Bearing                        |
| B-482-BB                   | Starwheel Shaft Outer Bearing (Oilless Type)         |
| S-432-E                    | Stripper Screws (2)                                  |
| S-724-BB                   | Bearing Screws (6)                                   |
| S-731-BB                   | Intermittent Sprocket Stripper                       |
| B-246-BB                   | Flywheel Shaft Bearing                               |
| B-247-BB                   | Cam Shaft Bearing (Old Style)                        |
| B-248-BB                   | Starwheel Shaft Inner Bearing (used with S-730-BB)   |
| B-484-BB                   | Cam Shaft Bearing (New Style)                        |
| C-294-BB                   | Case Retaining Clamp                                 |
| C-295-BB                   | Starwheel Shaft Collar                               |
| C-483-BB                   | Cam Shaft Bearing Collar (New Style)                 |
| D-130-BB                   | Oil Deflector                                        |
| G-188-BB                   | Oil Gasket                                           |
| G-189-BB                   | Case Cover Glass (Left) (Old Style)                  |
| G-195-BB                   | Case Cover Glass (Right) (Old Style)                 |
| G-225-BB                   | Oil Sight Glass Gasket (small)                       |
| G-226-BB                   | Oil Sight Glass (small)                              |
| G-241-BB                   | Oil Sight Gauge (Old Style)                          |
| S-177-E                    | Collar Set Screw                                     |
| S-724-BB                   | Bearing Screw                                        |
| S-728-BB                   | Case Clamp Screw                                     |
| S-729-BB                   | Case Cover Screw                                     |
| S-765-BB                   | Oil Deflector Screw                                  |
| W-227-BB                   | Cam Shaft Bearing Oil Retaining Washer (felt)        |
| W-228-BB                   | Oil Sight Washer (Steel) (small)                     |
| W-232-BB                   | Flywheel Gear Retaining Washer (felt)                |
| WA-12-BB                   | Oil Drain Screw Washer                               |
| <br>R-52                   | <br>Oil Drain Tube and Plug                          |
| <b>C-2 1/2</b>             | <b>UPPER PAD ROLLER ARM (OLD STYLE)</b>              |
| C-1                        | Upper Pad Roller Arm *                               |
| C-12                       | Pad Roller Stud and Knob                             |
| P-149-C                    | Pad Roller Arm Pin                                   |
| S-194-C                    | Pad Roller Arm Screw                                 |
| S-248-A                    | Pad Roller Stud and Knob Holding Screw               |
| N-115-C                    | Pad Roller Arm Nut                                   |
| <br><b>C-3 1/2</b>         | <br><b>LOWER SINGLE PAD ROLLER ARM (OLD STYLE)</b>   |
| A-115-C                    | Lower Pad Roller Arm *                               |
| N-115-C                    | Lower Pad Roller Arm Nut                             |
| P-149-C                    | Lower Pad Roller Arm Pin                             |
| S-194-C                    | Lower Pad Roller Arm Screw                           |
| S-217-C                    | Pad Roller Screw                                     |
| S-376-C                    | Lower Pad Roller Arm Stud *                          |
| <br><b>C-4</b>             | <br><b>FILM TRAP DOOR TRIP LEVER</b>                 |
| L-103-C                    | Film Trap Door Trip Lever *                          |
| S-102-C                    | Film Trap Door Trip Lever Spring Screw               |
| S-329-C                    | Film Trap Door Trip Lever Spring                     |
| *Parts Not Sold Separately |                                                      |



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                          |
|-------------|----------------------------------------------------------------------|
| <b>C-5½</b> | <b>LOWER DOUBLE PAD ROLLER ARM COMPLETE WITH ROLLERS (OLD STYLE)</b> |
| AR-304-C    | Lower Pad Roller Arm *                                               |
| C-12        | Pad Roller Stud and Knob (2)                                         |
| N-115-C     | Pad Roller Arm Nut                                                   |
| P-102-C     | Pad Roller (2)                                                       |
| P-149-C     | Pad Roller Arm Pin                                                   |
| S-194-C     | Roller Arm Screw                                                     |
| S-248-A     | Roller Stud and Knob Holding Screw (2)                               |
| <b>C-8</b>  | <b>UPPER MAGAZINE ROLLER HOLDER COMPLETE</b>                         |
| H-130-C     | Upper Magazine Roller Holder                                         |
| R-160-C     | Small Magazine Roller (2)                                            |
| R-161-C     | Large Magazine Roller                                                |
| S-485-C     | Magazine Roller Screw (6)                                            |
| <b>C-9</b>  | <b>GOVERNOR LIFT LEVER LINK ASSEMBLY</b>                             |
| L-110-C     | Governor Lift Lever Link                                             |
| L-111-C     | Governor Lift Lever Connect Link                                     |
| S-101-C     | Governor Lift Lever Connect Link Screw                               |
| <b>C-12</b> | <b>PAD ROLLER STUD AND KNOB</b>                                      |
| <b>C-14</b> | <b>FILM TRAP DOOR TRIP LEVER (MASS. REQUIREMENTS)</b>                |
| L-158-C     | Film Trap Door Trip Lever *                                          |
| S-102-E     | Trip Lever Spring Screw                                              |
| S-329-C     | Trip Lever Spring                                                    |
| <b>C-21</b> | <b>LOWER PAD ROLLER ARM COMPLETE</b>                                 |
| A-137-C     | Lower Pad Roller Arm                                                 |
| C-12        | Pad Roller Stud and Knob (2)                                         |
| N-166-C     | Pad Roller Arm Nut                                                   |
| P-102-C     | Pad Roller (2)                                                       |
| S-165-C     | Pad Roller Arm Stud Washer Screw                                     |
| S-248-C     | Pad Roller Stud and Knob Holding Screw (2)                           |
| S-567-C     | Pad Roller Arm Stud                                                  |
| S-706-C     | Pad Roller Arm Screw                                                 |
| W-160-C     | Pad Roller Arm Stud Washer                                           |
| <b>C-25</b> | <b>FILM TRAP GATE TRIP LEVER (LONG TYPE)</b>                         |
| L-161-C     | Trip Lever                                                           |
| S-866-C     | Trip Lever Spring                                                    |
| S-873-C     | Trip Lever Spring Fastening Screw (2)                                |
| <b>C-38</b> | <b>LENS HOLDER CLAMP KNOB AND SCREW</b>                              |
| K-149-C     | Lens Holder Clamp Knob *                                             |
| P-350-BB    | Lens Holder Clamp Knob Pin                                           |
| S-1091-C    | Lens Holder Clamp Knob Screw *                                       |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                          |
|-------------|----------------------------------------------------------------------|
| <b>C-53</b> | <b>UPPER PAD ROLLER ARM COMPLETE</b>                                 |
| A-136-C     | Upper Pad Roller Arm                                                 |
| C-12        | Pad Roller Stud and Knob                                             |
| N-166-C     | Pad Roller Arm Nut                                                   |
| P-102-C     | Pad Roller                                                           |
| S-165-C     | Pad Roller Arm Stud Washer Screw                                     |
| S-248-A     | Pad Roller Stud and Knob Holding Screw                               |
| S-567-C     | Pad Roller Arm Stud                                                  |
| S-706-C     | Pad Roller Arm Screw                                                 |
| W-160-C     | Pad Roller Arm Stud Washer                                           |
| <b>C-62</b> | <b>LENS HOLDER AND RIGHT FRONT COVER ASSEMBLY FOR F-2.0 LENS</b>     |
| A-104-C     | Projecting Lens Adapter                                              |
| C-157-C     | Right Cover (Old Style) (Stationery Type)                            |
| C-286-C     | Right Front Cover                                                    |
| E-100-C     | Large Escutcheon                                                     |
| E-101-C     | Medium Escutcheon                                                    |
| P-102-C     | Pad Roller                                                           |
| P-121-C     | Film Trap Locating Pin                                               |
| P-289-C     | Roller Arm Stop Pin                                                  |
| R-227-C     | Magazine Roller (Mass. Requirements)                                 |
| S-101-C     | Automatic Shutter Link Hinge Screw                                   |
| S-102-C     | Automatic Fire Shutter Lift Link Retaining Screw                     |
| S-122-C     | Cover Screw                                                          |
| S-133-C     | Film Trap Screw                                                      |
| S-137-C     | Film Trap Door Trip Lever Pivot Screw (For C-4 Type)                 |
| S-150-C     | Governor Lift Lever Pivot Screw                                      |
| S-165-C     | Right Cover Fastening Screw                                          |
| S-193-C     | Upper and Lower Sprocket Arm Pivot Screw (Old Style)                 |
| S-248-A     | Roller Holder Screw                                                  |
| S-278-A     | Sprocket Stripper and Stud Fastening Screw                           |
| S-300-C     | Movietone Stud                                                       |
| S-514-C     | Automatic Fire Shutter Lifting Stud                                  |
| S-567-C     | Pad Roller Arm Stud                                                  |
| S-572-C     | Upper and Lower Sprocket Film Stripper                               |
| S-573-C     | Upper and Lower Sprocket Film Stripper Stud                          |
| S-573 1/2-C | Sprocket Stripper Stud (For Old Style Frame)                         |
| S-775-C     | Upper Magazine Arm Screw (Mass. Requirements)                        |
| S-776-C     | Upper Roller Holder Side Plates Fastening Screw (Mass. Requirements) |
| S-782-C     | Film Trap Gate Trip Lever Pivot Screw (For C-14 Type)                |
| S-874-C     | Film Trap Gate Trip Lever Pivot Screw (For C-25 Type)                |
| W-160-C     | Pad Roller Arm Washer                                                |
| W-255-C     | Sprocket Stripper Stud Washer (For Old Style Frame)                  |
| <b>D-1</b>  | <b>DRIVING HANDLE COMPLETE</b>                                       |
| A-108-D     | Driving Arm *                                                        |
| H-109-D     | Driving Handle *                                                     |
| P-209-D     | Driving Handle Retaining Plug                                        |
| S-124-D     | Driving Arm Screw                                                    |
| S-366-D     | Driving Arm Stud *                                                   |
| W-103-D     | Driving Handle Retaining Washer *                                    |
| <b>D-2</b>  | <b>GOVERNOR LIFT LEVER AND SCREW</b>                                 |
| L-105-D     | Governor Lift Lever                                                  |
| S-493-D     | Governor Lift Lever Screw                                            |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                       |
|-------------|---------------------------------------------------|
| <b>D-3</b>  | <b>GOVERNOR WEIGHTS AND LINKS (SET ONLY)</b>      |
| L-112-D     | Governor Weight Link (2)                          |
| S-100-E     | Governor Weight Link Screw (2)                    |
| W-126-D     | Governor Weight (2) *                             |
| <b>D-4</b>  | <b>OPERATING SIDE DOOR AND HINGE</b>              |
| D-17        | Operating Side Door Hinge                         |
| D-128-D     | Operating Side Door                               |
| S-192-D     | Operating Side Door Hinge Fastening Screw (5)     |
| <b>D-5</b>  | <b>OPERATING SIDE DOOR AND KNOB</b>               |
| D-4         | Operating Side Door and Hinge                     |
| K-132-D     | Operating Side Door Knob                          |
| S-246-D     | Door Knob Fastening Screw (2)                     |
| <b>D-6</b>  | <b>OPERATING SIDE DOOR LOCK SPRING AND BUTTON</b> |
| <b>D-7</b>  | <b>RIGHT BACK COVER HINGE</b>                     |
| <b>D-9</b>  | <b>RIGHT BACK DRUM COVER</b>                      |
| C-285-D     | Right Back Cover                                  |
| D-7         | Right Back Cover Hinge                            |
| R-162-D     | Right Back Cover Stripper Roller                  |
| S-106-D     | Right Back Cover Hinge Screw (3)                  |
| S-185-D     | Operating Side Door Lock Stop Screw               |
| S-771-D     | Stripper Roller Screw (2)                         |
| <b>D-11</b> | <b>UPPER LEFT DOOR AND KNOB</b>                   |
| D-18        | Upper Left Door Hinge                             |
| D-108-D     | Upper Left Door                                   |
| K-106-D     | Left Door Knob                                    |
| S-178-D     | Left Door Knob Screw (2)                          |
| S-192-D     | Upper Left Door Hinge Screw (5)                   |
| <b>D-12</b> | <b>LOWER LEFT DOOR AND HINGE</b>                  |
| D-19        | Lower Left Door Hinge                             |
| D-105-D     | Lower Left Door                                   |
| S-192-D     | Lower Left Door Hinge Screw (2)                   |
| <b>D-13</b> | <b>SHUTTER SPIDER COMPLETE</b>                    |
| S-165-C     | Shutter Spider Screw (2)                          |
| S-566-D     | Shutter Spider *                                  |
| <b>D-14</b> | <b>THREE WING FRONT SHUTTER AND SPIDER</b>        |
| D-13        | Shutter Spider                                    |
| D-27        | Three Wing Shutter                                |
| S-106-D     | Shutter Screw (5)                                 |
| <b>D-16</b> | <b>TOP PLATE ASSEMBLY</b>                         |
| L-113-D     | Left Door Stop Link                               |
| P-207-D     | Top Plate                                         |
| S-191-D     | Left Door Stop Link Screw                         |
| S-189-W     | Upper Magazine Fastening Screw (2)                |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO. | DESCRIPTION                                                |
|----------|------------------------------------------------------------|
| D-17     | OPERATING SIDE DOOR HINGE COMPLETE                         |
| D-18     | UPPER LEFT DOOR HINGE COMPLETE                             |
| D-19     | LOWER LEFT DOOR HINGE COMPLETE                             |
| D-22     | TWO WING FRONT SHUTTER                                     |
| D-23     | TWO WING FRONT SHUTTER AND SPIDER                          |
| D-13     | Shutter Spider                                             |
| D-22     | Two Wing Front Shutter                                     |
| S-106-D  | Shutter Screws (5)                                         |
| D-33     | TWO WING FRONT SHUTTER FOR #-2 LENS                        |
| D-34     | THREE WING FRONT SHUTTER FOR #-2 LENS                      |
| D-49     | TWO WING FRONT SHUTTER AND SPIDER FOR #-2 LENS             |
| D-13     | Shutter Spider                                             |
| D-33     | Two Wing Front Shutter for #-2 Lens                        |
| S-106-D  | Shutter Screws (5)                                         |
| D-50     | THREE WING FRONT SHUTTER AND SPIDER FOR #-2 LENS           |
| D-13     | Shutter Spider                                             |
| D-34     | Three Wing Front Shutter for #-2 Lens                      |
| S-106-D  | Shutter Screw (5)                                          |
| D-65     | PILOT LAMP AND TUBE ASSEMBLY COMPLETE                      |
| D-66     | Pilot Lamp Tube                                            |
| D-85-AA  | Pilot Lamp, Socket, Switch and Cable                       |
| S-106-D  | Pilot Lamp Assembly Fastening Screw (To Shutter Guard) (2) |
| S-972-D  | Pilot Lamp Adapter Fastening Screw                         |
| D-66     | PILOT LAMP TUBE ASSEMBLY                                   |
| D-67     | SPOT SIGHT BOX ONLY                                        |
| B-317-D  | Spot Sight Box Bottom *                                    |
| B-318-D  | Spot Sight Box Top *                                       |
| B-319-D  | Spot Sight Box Center *                                    |
| S-248-A  | Front Plate Fastening Screw (Long)                         |
| S-278-A  | Front Plate Fastening Screw (Short) (3)                    |
| D-74     | SHUTTER GUARD (FRONT)                                      |
| DD-4     | Spot Sight Box Mount                                       |
| C-219-D  | Front Shutter Guard                                        |
| P-562-D  | Shutter Guard Holding Support Plate (3)                    |
| S-885-D  | Support Plate Fastening Screw (6)                          |
| S-966-D  | Shutter Guard Holding Support (3)                          |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.       | DESCRIPTION                                                |
|----------------|------------------------------------------------------------|
| <b>D-75</b>    | <b>SHUTTER GUARD (REAR)</b>                                |
| G-218-D        | Rear Shutter Guard                                         |
| P-562-D        | Shutter Guard Holding Support Plate (3)                    |
| S-885-A        | Support Plate Fastening Screw (6)                          |
| S-966-D        | Shutter Guard Holding Support (3)                          |
| <b>D-76</b>    | <b>SHUTTER GUARD (FRONT) STERIO</b>                        |
| DD-4           | Spot Sight Box Mount Assembly                              |
| G-217-D        | Shutter Guard (front) Sterio                               |
| P-562-E        | Holding Support Plate (3)                                  |
| S-885-A        | Holding Support Plate Fastening Screw (6)                  |
| S-966-D        | Shutter Guard Holding Support (3)                          |
| <b>D-77</b>    | <b>SHUTTER GUARD (REAR) STERIO</b>                         |
| G-216-D        | Shutter Guard (Rear) Sterio                                |
| P-562-D        | Shutter Guard Holding Support Plate (3)                    |
| S-885-A        | Holding Support Plate Fastening Screw (6)                  |
| S-966-D        | Shutter Guard Holding Support (3)                          |
| <b>D-80</b>    | <b>SHUTTER SHAFT AND GEAR</b>                              |
| G-203-G        | Shutter Shaft Gear                                         |
| P-107-G        | Shutter Gear Pin                                           |
| S-1046-D       | Shutter Shaft                                              |
| <b>D-81</b>    | <b>BALL BEARING AND BUSHING (OLD STYLE) (OIL-CUP TYPE)</b> |
| <b>D-82</b>    | <b>SHUTTER LIFT ASSEMBLY</b>                               |
| L-171-E        | Shutter Lift Lever (Pivot)                                 |
| S-106-D        | Shutter Lift Link Retaining Screw                          |
| S-1003-D       | Pilot Light Shutter Lift Lever Stud                        |
| <b>D-85</b>    | <b>PILOT LAMP SOCKET AND SWITCH</b>                        |
| A-183-D        | Pilot Lamp Switch Adaptor                                  |
| N-196-D        | Brass Nut                                                  |
| S-964-D        | Contact Spring                                             |
| S-965-D        | Candalabra Socket Shell                                    |
| S-968-D        | Pilot Lamp Toggle Switch                                   |
| S-969-D        | Pilot Lamp Contact Screw                                   |
| S-970-D        | Pilot Lamp Cord Connecting Screw                           |
| S-971-D        | Lamp Socket Terminal Fastening Screw (2)                   |
| T-154-D        | Lamp Socket Terminal                                       |
| W-221-D        | Terminal Insulating Washer                                 |
| W-222-D        | Socket Insulating Washer                                   |
| <b>D-85-AA</b> | <b>PILOT LAMP, SOCKET, SWITCH AND CABLE COMPLETE</b>       |
| D-85           | Pilot Lamp Socket and Switch                               |
| B-316-D        | Pilot Lamp Cable Bushing                                   |
| C-366-D        | Pilot Lamp Cable Clamp (Plated)                            |
| C-367-D        | Pilot Lamp Flexible Conduit                                |
| C-368-D        | Pilot Lamp Cable Clamp (Galvanized)                        |
| C-369-D        | Pilot Lamp Cord                                            |
| G-240-D        | Lamp Base and Socket Guard                                 |
| L-170-D        | Pilot Lamp                                                 |
| N-197-D        | Steel Nut                                                  |
| S-971-D        | Pilot Lamp Guard Fastening Screw (2)                       |
| S-973-D        | Pilot Lamp Cable Clamp Fastening Screw                     |



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                   |
|-------------|-----------------------------------------------|
| <b>D-86</b> | <b>SPOT SIGHT BOX COMPLETE</b>                |
| D-67        | Spot Sight Box Only                           |
| G-220-D     | Spot Sight Glass                              |
| P-462-D     | Cooling Plate                                 |
| S-101-C     | Spot Sight Glass Retaining Screw              |
| S-248-A     | Spot Sight Cooling Plate Fastening Screw (3)  |
| S-962-D     | Spot Sight Glass Tension Spring               |
| S-987-D     | Light Seal and Shield Fastening Screw (4)     |
| S-999-D     | Light Seal                                    |
| S-1030-D    | Pilot Light Shield                            |
| <b>D-87</b> | <b>SHUTTER GUARD BRACKET</b>                  |
| B-288-D     | Door Opening Stop Bushing                     |
| C-347-D     | Film Gate Opening Rod Collar                  |
| C-377-D     | Shutter Guard Spacing Collar (3)              |
| D-138-D     | Framing Gear Friction Disc                    |
| F-168-D     | Framing Gear Flange                           |
| F-172-D     | Shutter Guard Support Frame                   |
| G-25        | Lock Nut and Screw                            |
| G-243-D     | Framing Gear                                  |
| K-137-D     | Framing Gear Handle Knob (2)                  |
| K-141-D     | Cover Holding Support Rod Knob (3)            |
| L-162-D     | Film Trap Door Opening Lever                  |
| L-177-D     | Film Gate Lever                               |
| R-240-D     | Framing Gear Friction Ring                    |
| R-255-D     | Cover Holding Support Rod (3)                 |
| R-261-D     | Framing Gear Handle Rod                       |
| R-264-D     | Film Gate Opening Rod                         |
| S-863-A     | Friction Disc Retaining Screw (2)             |
| S-884-D     | Door Opening Lever Stop Screw                 |
| S-886-D     | Door Opening Stop Screw                       |
| S-893-D     | Framing Gear Friction Ring Screw              |
| S-897-C     | Film Gate Lever Screw (6)                     |
| S-902-D     | Cover Holding Support Rod Fastening Screw (3) |
| S-978-D     | Framing Gear Friction Device Spring           |
| W-223-D     | Framing Gear Friction Device Washer (2)       |
| <b>D-89</b> | <b>TWO WING REAR SHUTTER FOR NO. 2 LENS</b>   |
| B-332-D     | Shutter Fan Blade (2)                         |
| SC-94-D     | Shutter Fan Blade Screw (6)                   |
| S-1045-D    | Shutter                                       |
| <b>D-90</b> | <b>REAR SHUTTER ATTACHMENT</b>                |
| <b>D-91</b> | <b>FRAMING CAM GEAR</b>                       |
| G-222-D     | Framing Cam Gear                              |
| S-1005-D    | Framing Cam Gear Set Screw (3)                |
| S-1011-D    | Rear Shutter Attachment Stop Stud             |
| <b>D-92</b> | <b>REAR SHUTTER BRACKET STUD</b>              |
| N-201-D     | Rear Shutter Bracket Knurled Nut              |
| N-202-D     | Rear Shutter Bracket Cap Nut                  |
| S-997-D     | Rear Shutter Bracket Stud                     |



## PART NO.

## DESCRIPTION

**D-93****LEFT BACK COVER AND SHUTTER ADJUSTING GEAR**

C-346-D Shutter Adjusting Gear Rod Collar  
 S-371-D Left Back Cover  
 G-206-D Shutter Adjusting Gear (small)  
 K-139-D Shutter Adjusting Gear Knob  
 R-245-D Shutter Adjusting Gear Rod  
 S-885-A Shutter Adjusting Gear Screw

**D-94****SHUTTER ADJUSTING SPIDER**

G-224-D Shutter Adjusting Gear  
 S-125-B Shutter Adjusting Gear Screw

**D-95****SHUTTER SPIDER**

S-1016-D Shutter Spider \*  
 S-1026-D Shutter Spider Clamp Screw (2)

**D-96****TWO WING REAR SHUTTER FOR NO. 1 LENS**

B-332-D Shutter Fan Blade (2)  
 SC-94-D Shutter Fan Blade Screw (6)  
 S-1015-D Shutter

**D-97****TWO WING REAR SHUTTER AND SPIDER FOR NO. 1 LENS**

D-96 Shutter Blade  
 D-95 Shutter Spider  
 S-192-D Shutter Fastening Screw (5)

**D-99****TWO WING REAR SHUTTER AND SPIDER FOR NO. 2 LENS**

D-89 Shutter Blade  
 D-95 Shutter Spider  
 S-192-D Shutter Fastening Screw (5)

**DD-1****BALL BEARING BUSHING****DD-5****GREASE TUBE ASSEMBLY****DD-4****SPOT SIGHT BOX MOUNT COMPLETE**

P-543-D Spot Sight Box Seating Plate  
 R-274-D Spot Sight Box Guide Rail (2)  
 S-248-A Spot Sight Box Mount Screw (Short) (2)  
 S-987-D Seating Plate Fastening Screw (4)  
 S-1134-D Upper Retaining Strip  
 S-1135-D Lower Retaining Strip  
 S-1136-D Spot Sight Box Retaining Spring (3)  
 S-1137-D Spot Sight Box Retaining Spring Screw (6)  
 S-1138-D Spot Sight Box Mount Screw (Long) (2)  
 S-1139-D Spot Sight Box Stop Screw (2)

**DD-6****REAR SHUTTER BEARING & HOUSING ASSEMBLY (NEW STYLE)**

B-466-D Rear Shutter Grease Sealed Ball Bearing  
 H-251-D Ball Bearing Housing  
 G-28 Shutter Shaft Clamp  
 W-208-G Shutter Ball Bearing Thrust Washer (Formica)

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.         | DESCRIPTION                                                                       |
|------------------|-----------------------------------------------------------------------------------|
| <b>DD-7</b>      | <b>REAR SHUTTER BRACKET AND OIL TUBE</b>                                          |
| B-325-D          | Rear Shutter Bracket *                                                            |
| C-120-B          | Oil Tube Clamp                                                                    |
| C-316-G          | Oil Cup                                                                           |
| P-541-D          | Bracket Flange Locating Pin                                                       |
| S-106-D          | Oil Tube Screw                                                                    |
| T-159-D          | Oil Tube                                                                          |
| <b>DD-8-N.S.</b> | <b>REAR SHUTTER GREASE-SEALED BALL BEARING ASSEMBLY (NEW STYLE)</b>               |
| DD-6             | Rear Shutter Bearing and Housing Assembly (N.S.)                                  |
| F-174-D          | Bracket Flange                                                                    |
| P-466-D          | Bracket Flange Dowel Pins (2)                                                     |
| P-541-D          | Bracket Flange Locating Pin                                                       |
| S-1039-D         | Bracket Fastening Screw (Short) (2)                                               |
| S-1129-D         | Ball Bearing Housing Fastening Screw (Long) (2)                                   |
| <b>DD-8</b>      | <b>REAR SHUTTER SELF-ALIGNING GREASE-TUBE TYPE BALL RACE ASSEMBLY (OLD STYLE)</b> |
| B-355-D          | Ball Bearing                                                                      |
| C-405-D          | Ball Bearing Dust Cap                                                             |
| C-408-D          | Grease Tube Clamp                                                                 |
| DD-1             | Ball Bearing Bushing                                                              |
| DD-5             | Grease Tube Assembly                                                              |
| F-174-D          | Shutter Bracket Flange (Includes 2 P-466-D)                                       |
| H-217-D          | Ball Bearing Housing                                                              |
| N-211-D          | Ball Bearing Lock Nut                                                             |
| P-466-D          | Dowel Pin (2)                                                                     |
| P-541-D          | Flange Locating Pin                                                               |
| S-248-A          | Grease Cup Bracket Screw (2)                                                      |
| S-1039-D         | Shutter Guard Support Frame Attach Screw (Short) (2)                              |
| S-1129-D         | Ball Bearing Housing Screw (Long) (2)                                             |
| W-208-G          | Spacing Washer (Formica)                                                          |
| W-253-D          | Ball Bearing Washer (Felt)                                                        |
| W-254-D          | Ball Bearing Bushing Washer                                                       |
| <b>DD-9</b>      | <b>UPPER LEFT DOOR HINGE AND PIN (NEW STYLE)</b>                                  |
| <b>DD-11</b>     | <b>UPPER LEFT DOOR AND KNOB (NEW STYLE)</b>                                       |
| D-144-D          | Upper Left Door                                                                   |
| DD-9             | Upper Left Door Hinge                                                             |
| K-106-D          | Upper Left Door Knob                                                              |
| S-178-D          | Knob Screw (2)                                                                    |
| S-192-D          | Hinge Screw (4)                                                                   |
| <b>DD-12</b>     | <b>LOWER LEFT DOOR (NEW STYLE)</b>                                                |
| B-439-D          | Lower Left Door Bracket                                                           |
| D-143-D          | Lower Left Door                                                                   |
| S-180-D          | Lower Left Door Locking Screw (Short)                                             |
| S-192-D          | Bracket Mounting Screw (3)                                                        |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.     | DESCRIPTION                                            |
|--------------|--------------------------------------------------------|
| <b>DD-23</b> | <b>REAR SHUTTER GUARD LIGHT CAP</b>                    |
| C-316-G      | Rear Shutter Bracket Oil Cup                           |
| F-166-D      | Shutter Guard Support Frame (Sterio)                   |
| F-169-D      | Rear Shutter Bracket Flange (Old Style)                |
| H-210-R      | Fire Shield Hood 2"                                    |
| H-214-R      | Fire Shield Hood 1"                                    |
| R-273-D      | Film Gate Opening Rod (Long) (Sterio)                  |
| S-106-D      | Pilot Light Holder Fastening Screw (2)                 |
| S-905-D      | Right Door Lock Spring Fastening Screw (3)             |
| S-1004-D     | Shutter Bracket Flange Adjusting Screw (2)             |
| S-1012-D     | Bracket Flange Fastening Screw (Old Style) (4)         |
| S-1020-D     | Film Trap Fastening Screw (Lower)                      |
| W-231-D      | Shutter Fan Blade Screw Washer                         |
| <b>KD-1</b>  | <b>LOWER RIGHT DOOR AND HINGE ASSEMBLY (NEW STYLE)</b> |
| D-157-C      | Lower Right Door (New Style)                           |
| KD-2         | Lower Right Door Hinge Assembly                        |
| S-192-D      | Door Hinge Fastening Screw (To D-157-C NS) (2)         |
| S-898-E      | Door Hinge Fastening Screw (To C-286-C) (2)            |
| C-151-D      | Left Door Cover (Front Shutter)                        |
| C-152-D      | Left Front Cover                                       |
| C-365-D      | Right Door Glass Clamp                                 |
| G-124-D      | Right Door Glass                                       |
| K-6145-D     | Shutter Shaft Indicator Knob                           |
| P-144-D      | Left Door Lock Pin                                     |
| P-153-B      | Left Door Lock Spring Taper Pin                        |
| P-341-D      | Cover Linkage Locking Pin                              |
| P-382-D      | Right Back Cover Lock Pin (Old Style)                  |
| R-162-D      | Right Back Cover Stripper Roller                       |
| S-106-D      | Right Door Glass Clamp Screw                           |
| S-122-C      | Cover Screw                                            |
| S-178-D      | Right Back Cover Lock Pin Screw (Old Style)            |
| S-180-D      | Lower Left Door Retaining Screw                        |
| S-181-D      | Left Door Stop Link Screw                              |
| S-192-D      | Right And Left Door Hinge Screw                        |
| S-246-D      | Right Door Knob Fastening Screw                        |
| S-338-D      | Left Door Lock Spring                                  |
| S-508-D      | Old Style Stripper (For Single Bearing Movement)       |
| S-771-D      | Right Back Cover Stripper Roller Screw                 |
| S-787-D      | Left Front Cover Screw                                 |
| S-1152-D     | Handle Shaft Oil Shield                                |
| W-127-D      | Lower Sprocket (Old Style)                             |
| W-141-D      | Upper Sprocket (Old Style)                             |
| W-145-D      | Upper Sprocket (Hardened)                              |
| W-146-D      | Lower Sprocket (Hardened)                              |



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                                                            |
|-------------|--------------------------------------------------------------------------------------------------------|
| <b>"E"</b>  | <b>FILM TRAP, GATE &amp; HOLDER ASSEMBLY COMPLETE<br/>(FIXED APERTURE TYPE) (FOR FRONT SHUTTER)</b>    |
| E-2         | Film Trap Door Holder and Stud                                                                         |
| E-6         | Automatic Fire Shutter and Lift Link                                                                   |
| E-10        | Double Tension Gate Complete (Old Style)                                                               |
| E-14        | Lateral Guide Rollers and Shaft                                                                        |
| E-40        | Film Trap Asbestos Heat Shield (For Front Shutter)                                                     |
| E-83        | Film Trap and Bushing Assembly (Fixed Aperture)                                                        |
| P-359-E     | Lateral Guide Roller Shaft Pivot (2)                                                                   |
| P-377-E     | Thumb Plate                                                                                            |
| P-529-E     | Aperture Plate (Fixed Type)                                                                            |
| S-309-E     | Film Trap Shoe (2)                                                                                     |
| S-327-E     | Film Trap Holder Spring                                                                                |
| S-432-E     | Film Trap Shoe Fastening Screw (6)                                                                     |
| S-787-E     | Thumb Plate Screw                                                                                      |
| T-101-E     | Film Trap Door Thimble                                                                                 |
| <b>"EE"</b> | <b>FILM TRAP, GATE &amp; HOLDER ASSEMBLY COMPLETE<br/>(SLIDE-IN APERTURE TYPE) (FOR FRONT SHUTTER)</b> |
| E-2         | Film Trap Door Holder & Stud                                                                           |
| E-6         | Automatic Fire Shutter and Lift Link                                                                   |
| E-10        | Double Tension Gate Complete (Old Style)                                                               |
| E-14        | Lateral Guide Rollers and Shaft                                                                        |
| E-40        | Film Trap Asbestos Heat Shield (For Front Shutter)                                                     |
| E-81        | Film Trap & Bushing Assembly (For Slide-In Aperture)                                                   |
| P-359-E     | Lateral Guide Roller Shaft Pivot (2)                                                                   |
| P-377-E     | Thumb Plate                                                                                            |
| P-445-E     | Aperture Retaining Plate (For Slide-In Aperture)                                                       |
| P-529-E     | Aperture Plate (Slide-In Type)                                                                         |
| S-309-E     | Film Trap Shoe (2)                                                                                     |
| S-327-E     | Film Trap Holder Spring                                                                                |
| S-432-E     | Film Trap Shoe Fastening Spring (6)                                                                    |
| S-787-E     | Thumb Plate Screw                                                                                      |
| T-101-E     | Film Trap Door Thimble                                                                                 |
| <b>E-2</b>  | <b>FILM TRAP DOOR HOLDER AND STUD</b>                                                                  |
| H-119-E     | Film Trap Door Holder *                                                                                |
| P-119-E     | Film Trap Door Holder Pin (2)                                                                          |
| P-545-E     | Film Trap Door Holder Stud Retaining Pin                                                               |
| S-367-E     | Film Trap Door Holder Stud                                                                             |
| W-148-E     | Film Trap Door Holder Stud Distance Washer                                                             |
| <b>E-3</b>  | <b>INTERMITTENT FILM GUIDE</b>                                                                         |
| C-127-E     | Film Guide Distance Collar (4)                                                                         |
| G-125-E     | Film Guide (Inside) (2)                                                                                |
| G-126-E     | Film Guide (Outside) (2)                                                                               |
| S-665-E     | Film Guide Stud (2)                                                                                    |
| S-1511-E    | Film Guide Stud Screw (4)                                                                              |
| <b>E-6</b>  | <b>AUTOMATIC FIRE SHUTTER LIFT LINK</b>                                                                |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                                |
|-------------|----------------------------------------------------------------------------|
| <b>E-10</b> | <b>DOUBLE TENSION GATE COMPLETE (OLD STYLE)</b>                            |
| D-145-E     | Film Trap Door                                                             |
| E-3         | Film Guide                                                                 |
| H-118-E     | Guide Holder                                                               |
| P-100-E     | Film Trap Door Pad                                                         |
| P-325-E     | Film Protector                                                             |
| S-130-E     | Guide Holder and Pad Spring Screws (8)                                     |
| S-132-E     | Film Guide Spring Screw                                                    |
| S-192-D     | Film Protector Screw (2)                                                   |
| S-326-E     | Film Guide Spring                                                          |
| S-328-E     | Film Trap Door Pad Spring                                                  |
| S-580-E     | Double Tension Shoe (upper) (2)                                            |
| S-581-E     | Double Tension Shoe Spring                                                 |
| <b>E-14</b> | <b>LATERAL GUIDE ROLLER AND SHAFT</b>                                      |
| C-129-E     | Lateral Guide Roller Shaft Collar                                          |
| E-15        | Lateral Guide Roller Shaft and Washer                                      |
| R-214-E     | Guide Roller (2)                                                           |
| S-762-E     | Guide Roller Spring                                                        |
| S-763-E     | Guide Roller Shaft Collar Screw                                            |
| <b>E-15</b> | <b>LATERAL GUIDE ROLLER SHAFT AND WASHER</b>                               |
| <b>E-19</b> | <b>FILM TRAP DOOR LOCK (OLD STYLE) (FOR FRONT SHUTTER MECHANISMS ONLY)</b> |
| N-172-E     | Door Lock Thumb Piece Nut                                                  |
| P-372-E     | Door Lock Thumb Piece *                                                    |
| P-379-E     | Door Lock Pawl *                                                           |
| P-380-E     | Door Lock Pawl Pivot                                                       |
| S-442-G     | Door Lock Thumb Piece Stud Set Screw                                       |
| S-736-E     | Door Lock Thumb Piece Stud                                                 |
| S-777-E     | Door Lock Pawl Spring                                                      |
| S-778-E     | Door Lock Pawl Spring Retain Screw                                         |
| <b>E-35</b> | <b>DOOR LOCK (OLD STYLE)</b>                                               |
| P-380-E     | Film Trap Door Lock Pawl Pivot                                             |
| P-406-E     | Door Locking and Opening Device Plunger                                    |
| P-482-E     | Plunger Core Pin                                                           |
| S-851-E     | Door Locking and Opening Device Spring                                     |
| S-857-E     | Door Opening Trigger Support                                               |
| S-881-E     | Door Locking and Opening Device Fastening Screw                            |
| S-898-E     | Film Trap Bushing Retaining Screw                                          |
| T-137-E     | Door Trigger                                                               |
| <b>E-40</b> | <b>FILM TRAP ASBESTOS HEAT SHIELD (FOR FRONT SHUTTER)</b>                  |
| C-406-E     | Heat Shield Fastening Screw Spacer Collar (2)                              |
| C-407-E     | Heat Shield Spacer Collar (4)                                              |
| N-212-E     | Heat Shield Spacer Screw Nut (4)                                           |
| S-1092-E    | Heat Shield (Back)                                                         |
| S-1093-E    | Heat Shield (Front)                                                        |
| S-1140-E    | Heat Shield Spacer Screw (4)                                               |
| S-1141-E    | Heat Shield Fastening Screw (2)                                            |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                                                           |
|-------------|-------------------------------------------------------------------------------------------------------|
| <b>E-43</b> | <b>DOOR LOCKING AND OPENING DEVICE (NEW STYLE)</b>                                                    |
| P-380-E     | Door Lock Pawl Pivot                                                                                  |
| P-544-E     | Door Lock Plunger                                                                                     |
| S-898-E     | Bushing Retaining Screw                                                                               |
| S-1143-E    | Trigger Support                                                                                       |
| S-1144-E    | Plunger Spring                                                                                        |
| S-1145-E    | Fastening Screw                                                                                       |
| T-137-E     | Door Trigger                                                                                          |
| <b>E-44</b> | <b>FILM TRAP REMOVABLE GATE &amp; HOLDER ASSEMBLY COMPLETE (SLIDE-IN APERTURE) (FOR REAR SHUTTER)</b> |
| D-82        | Shutter Lift Assembly                                                                                 |
| E-2         | Film Trap Door Holder and Stud                                                                        |
| E-6         | Automatic Fire Shutter and Lift Link                                                                  |
| E-14        | Lateral Guide Rollers and Shaft                                                                       |
| E-43        | Door Locking and Opening Device                                                                       |
| E-46        | Removable Film Trap Gate & Bracket Complete                                                           |
| E-81        | Film Trap & Bushing Assembly (For Slide-In Aperture)                                                  |
| P-359-E     | Lateral Guide Roller Shaft Pivot (2)                                                                  |
| P-445-E     | Aperture Retaining Plate (For Slide-In Aperture)                                                      |
| P-529-E     | Aperture Plate (Slide-In Type)                                                                        |
| S-309-E     | Film Trap Shoe (2)                                                                                    |
| S-327-E     | Film Trap Holder Spring                                                                               |
| S-432-E     | Film Trap Shoe Fastening Screw (6)                                                                    |
| T-101-E     | Film Trap Door Thimble                                                                                |
| <b>E-45</b> | <b>REMOVABLE GATE LOCATING BRACKET AND STUD (INCLUDES S-1157-E SCREW AND S-1159-E SCREW)</b>          |
| <b>E-46</b> | <b>REMOVABLE FILM TRAP GATE AND BRACKET COMPLETE (NEW STYLE)</b>                                      |
| E-45        | Locating Bracket and Stud                                                                             |
| E-49        | Removable Film Trap Gate Complete                                                                     |
| K-150-E     | Removable Door Clamping Knob                                                                          |
| S-1157-E    | Support Bracket Screw (Long)                                                                          |
| S-1159-E    | Support Bracket Screw (Short)                                                                         |
| <b>E-49</b> | <b>REMOVABLE FILM TRAP GATE (NEW STYLE)</b>                                                           |
| D-148-E     | Film Gate Plate                                                                                       |
| E-3         | Film Guide                                                                                            |
| H-118-E     | Film Guide Holder                                                                                     |
| P-100-E     | Film Gate Pad                                                                                         |
| P-552-E     | Film Gate Protector                                                                                   |
| RP-24       | Film Gate Protector Screws (3)                                                                        |
| S-130-E     | Film Guide Holder and Pad Spring Screws (8)                                                           |
| S-132-E     | Film Guide Spring Screw                                                                               |
| S-326-E     | Film Guide Retaining Spring                                                                           |
| S-328-E     | Film Pad Tension Spring                                                                               |
| S-580-E     | Tension Shoe (Upper) (2)                                                                              |
| S-581-E     | Tension Shoe Spring (Upper)                                                                           |



# ORDER BY PART NUMBER

## PART NO.

## DESCRIPTION

### **E-68 FILM TRAP, REMOVABLE GATE AND HOLDER ASSEMBLY COMPLETE (FIXED APERTURE) (FOR REAR SHUTTER)**

D-82 Shutter Lift Assembly  
 E-2 Film Trap Door Holder and Stud  
 E-6 Automatic Fire Shutter and Lift Link  
 E-14 Lateral Guide Rollers and Shaft  
 E-43 Door Locking & Opening Device  
 E-46 Removable Film Trap Gate & Bracket Complete  
 E-83 Film Trap and Bushing Assembly (Fixed Aperture)  
 P-359-E Lateral Guide Roller Shaft Pivot (2)  
 P-527-E Aperture Plate  
 S-309-E Film Trap Shoe (2)  
 S-327-E Film Trap Holder Spring  
 S-432-E Film Trap Shoe Fastening Screw (6)  
 T-101-E Film Trap Door Thimble

### **E-81 FILM TRAP AND BUSHING ASSEMBLY (SLIDE-IN-APERTURE)**

B-297-E Film Trap Bushing  
 L-185-E Fire Shutter Lift Lever  
 S-100-E Fire Shutter Lift Lever Pivot Screw  
 S-898-E Film Trap Bushing Screw (2)  
 S-1147-E Fire Shutter Lift Link Screw  
 S-1148-E Fire Shutter Stop Screw  
 S-1149-E Fire Shutter Lift Lever Stop Screw  
 T-172-E Film Trap

### **E-83 FILM TRAP AND BUSHING ASSEMBLY (FIXED APERTURE)**

E-81 Film Trap and Bushing  
 S-434-E Fixed Aperture Holding Screw (2)  
 S-1361-E Spacing Plate for Aperture

P-320-E Film Gate Protector (For Old Style Single Tension Gate)  
 P-359-E Lateral Guide Roller Shaft Pivot  
 P-377-E Thumb Plate (For Front Shutter)  
 P-445-E Retaining Plate (For Slide-In-Aperture)  
 P-527-E Aperture Plate (Fixed Type) (Round Corner)  
 P-529-E Aperture Plate (Slide-In-Type) (Round Corner)  
 P-671-E Aperture Plate (Fixed Type) (Square Corner)  
 P-672-E Aperture Plate (Slide-In-Type) (Square Corner)  
 S-177-E Collar Set Screw  
 S-309-E Film Trap Shoe  
 S-310-E Film Gate Shoe (Left) (For Single Tension Gate)  
 S-311-E Film Gate Shoe (Right) (For Single Tension Gate)  
 S-327-E Film Trap Holder Spring  
 S-432-E Film Trap Shoe Fastening Screw  
 S-787-D Thumb Plate Screw  
 T-101-E Film Trap Door Thimble

**Undersize Aperture Plates can be furnished**

**Blank Apertures can be furnished for special effects**



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                                          |
|-------------|--------------------------------------------------------------------------------------|
| <b>G-1</b>  | <b>INTERMEDIATE SHAFT AND GEAR</b>                                                   |
| C-192-G     | Intermediate Shaft Retaining Collar                                                  |
| G-12        | Intermediate Gear (Formica) and Plate                                                |
| G-134-G     | Intermediate Gear (Steel) (Small Outside)                                            |
| G-135-G     | Intermediate Bevel Gear (Inside) (Includes W-306-G)                                  |
| S-145-G     | Retaining Washer Screw                                                               |
| S-442-G     | Retaining Collar Set Screw                                                           |
| S-1032-G    | Intermediate Shaft                                                                   |
| W-140-G     | Intermediate Gear Retain Washer                                                      |
| W-306-G     | Intermediate Gear Distance Washer                                                    |
| <b>G-3</b>  | <b>FRAMING SLIDE ARM AND ROLLER</b>                                                  |
| G-7         | Framing Slide Arm and Shoe *                                                         |
| P-127-G     | Framing Slide Arm Roller Pin                                                         |
| R-128-G     | Framing Slide Arm Roller                                                             |
| <b>G-4</b>  | <b>FRAMING SLIDE AND BLOCK</b>                                                       |
| B-106-G     | Framing Slide Lever Block                                                            |
| P-128-G     | Framing Slide Lever Pin                                                              |
| S-321-G     | Framing Slide                                                                        |
| <b>G-5</b>  | <b>BEVEL GEAR AND SHAFT</b>                                                          |
| C-193-G     | Bevel Gear Drive Shaft Collar                                                        |
| G-115-G     | Bevel Gear                                                                           |
| S-436-G     | Collar Set Screw                                                                     |
| S-1082-G    | Bevel Gear Drive Shaft                                                               |
| <b>G-6</b>  | <b>SHUTTER GEAR BRACKET COMPLETE<br/>(SPECIFY WHETHER FOR FRONT OR REAR SHUTTER)</b> |
| B-197-G     | Shutter Gear Bracket and Oil Cups (Includes 2 C-316-G)                               |
| C-193-G     | Shutter Shaft Collar                                                                 |
| G-4         | Framing Slide and Block                                                              |
| G-5         | Bevel Gear and Shaft                                                                 |
| G-116-G     | Shutter Driving Gear with Broached Hole                                              |
| G-248-G     | Shutter Spiral Gear (Formica)                                                        |
| R-120-G     | Framing Slide Guide Rod                                                              |
| S-141-A     | Framing Slide Set Screw                                                              |
| S-436-G     | Shutter Shaft Collar Set Screw                                                       |
| S-437-G     | Shutter Spiral Gear Set Screw                                                        |
| S-781-G     | Shutter Shaft (For Front Shutter)                                                    |
| S-1164-G    | Shutter Shaft (For Rear Shutter)                                                     |
| W-105-B     | Spiral Driving Gear Shaft Washer                                                     |
| <b>G-12</b> | <b>INTERMEDIATE GEAR (FORMICA) AND PLATE</b>                                         |
| G-181-G     | Intermediate Gear (Formica) *                                                        |
| P-334-G     | Intermediate Gear Plate *                                                            |
| S-705-G     | Intermediate Gear Screw                                                              |
| <b>G-13</b> | <b>DOUBLE BEVEL GEAR (FORMICA) (INCLUDES P-368-G)</b>                                |
| <b>G-14</b> | <b>CHAIN TAKEUP MAIN DRIVING GEAR</b>                                                |
| G-119-G     | Chain Takeup Main Driving *                                                          |
| S-760-G     | 21 Tooth Main Driving Gear Sprocket *                                                |
| S-790-G     | Gear and Sprocket Fastening Screw (3)                                                |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                               |
|-------------|-----------------------------------------------------------|
| <b>G-15</b> | <b>DOUBLE BEVEL GEAR AND VERTICAL SHAFT</b>               |
| G-13        | Double Bevel Gear (Formica) (Includes P-368-G)            |
| P-368-G     | Double Bevel Gear Taper Pin                               |
| S-550-G     | Vertical Shaft                                            |
| <b>G-18</b> | <b>FRAMING MECHANISM COMPLETE (FOR FRONT SHUTTER)</b>     |
| B-264-G     | Framing Mechanism Support Bracket                         |
| F-152-G     | Framing Lever Gear Friction Flange                        |
| G-19        | Driving Shaft Gear Assembly                               |
| G-20        | Framing Lever and Gear Assembly                           |
| H-196-G     | Framing Mechanism Handle                                  |
| K-100-N     | Framing Mechanism Knob                                    |
| N-177-G     | Framing Lever Gear Friction Adjusting Nut (2)             |
| S-122-C     | Framing Handle and Knob Fastening Screw (5)               |
| S-442-G     | Framing Lever Pivot Stud Set Screw                        |
| S-773-G     | Framing Lever Pivot Stud                                  |
| W-196-G     | Framing Lever Gear Washer                                 |
| <b>G-19</b> | <b>FRAMING MECHANISM DRIVING SHAFT AND GEAR</b>           |
| C-313-G     | Driving Shaft Collar *                                    |
| G-197-G     | Driving Shaft Gear *                                      |
| P-107-G     | Pin for Collar and Gear (2)                               |
| S-774-G     | Driving Shaft *                                           |
| <b>G-20</b> | <b>FRAMING LEVER AND GEAR</b>                             |
| G-196-G     | Framing Lever Gear *                                      |
| L-157-G     | Framing Lever *                                           |
| P-119-E     | Framing Lever Gear Pin                                    |
| <b>G-25</b> | <b>LOCK NUT AND SCREW</b>                                 |
| N-198-G     | Friction Device Lock Nut                                  |
| S-989-G     | Lock Nut Set Screw                                        |
| G-28        | Shutter Shaft Clamp                                       |
| C-344-G     | Clamp Collar *                                            |
| S-257-G     | Shutter Shaft Clamp Screw                                 |
| <b>G-35</b> | <b>LOWER SPROCKET SHAFT AND GEAR</b>                      |
| G-111-G     | Lower Sprocket Gear (Formica)                             |
| S-1031-G    | Lower Sprocket Shaft                                      |
| W-114-G     | Lower Sprocket Shaft Washer                               |
| <b>G-44</b> | <b>OIL TUBE ASSEMBLY (SHUTTER BRACKET TO TOP PLATE)</b>   |
| <b>G-45</b> | <b>SHUTTER GEAR BRACKET OIL TUBE, OIL CUP, AND GASKET</b> |
| G-44        | Oil Tube Assembly (Bracket to Top Plate)                  |
| G-211-G     | Oil Tube Flange Gasket                                    |
| GA-107      | Oil Tube Cup (For Top Plate)                              |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.         | DESCRIPTION                                         |
|------------------|-----------------------------------------------------|
| <b>"G" PARTS</b> |                                                     |
| A-118-G          | Picture Framing Handle Arm (Old Style)              |
| B-262-G          | Vertical Shaft Bearing                              |
| G-111-G          | Lower Sprocket Gear (Steel)                         |
| G-112-G          | Main Drive Gear                                     |
| G-138-G          | Vertical Shaft Top Bevel Gear                       |
| G-139-G          | Upper Sprocket Shaft Gear (Formica)                 |
| G-147-G          | Shutter Spiral Gear (Steel)                         |
| G-248-G          | Shutter Spiral Gear (Formica)                       |
| G-215-G          | Main Drive Gear for RCA                             |
| G-308-G          | Main Drive Gear (New Style)                         |
| H-120-G          | Lower Governor Link Holder                          |
| H-121-G          | Upper Governor Link Holder                          |
| L-104-G          | Framing Slide Lever                                 |
| L-107-G          | Picture Framing Lever                               |
| L-112-G          | Governor Weight Link                                |
| L-114-G          | Picture Framing Connecting Link                     |
| L-115-G          | Picture Framing Link                                |
| N-119-G          | Picture Framing Lever Pivot Screw Nut               |
| P-169-G          | Shutter Gear Bracket Dowel Pin                      |
| S-100-E          | Governor Weight Link Screw (Long)                   |
| S-142-G          | Picture Framing Lever Pivot Screw                   |
| S-144-G          | Picture Framing Link Screw                          |
| S-145-G          | Framing Slide Lever Stud Spring Retaining Screw     |
| S-151-D          | Governor Link Holder Screw (Short)                  |
| S-209-G          | Main Driving Gear Retaining Screw                   |
| S-222-G          | Picture Framing Link Screw                          |
| S-223-G          | Framing Slide Lever Stud Set Screw                  |
| S-257-G          | Shutter Gear Bracket Screw                          |
| S-330-G          | Framing Slide Lever Spring                          |
| S-341-G          | Picture Framing Handle Friction Spring (Old Style)  |
| S-357-G          | Governor Weight Stop                                |
| S-369-G          | Framing Slide Lever Stud                            |
| S-437-G          | Upper Governor Link Holder Set Screw                |
| S-447-G          | Shutter Shaft, Old Style 3/8" diameter              |
| S-574-G          | Shutter Shaft, For Old Style Bracket 5/16" diameter |
| S-781-G          | Shutter Shaft (For Front Shutter) (Regular)         |
| S-781-G          | Shutter Shaft (Extra Long) (For Long Lenses)        |
| S-1033-G         | Top Sprocket Shaft                                  |
| W-106-G          | Framing Handle Friction Washer                      |
| W-112-G          | Framing Slide Lever Retain Spring Washer            |
| W-124-G          | Vertical Shaft Washer (thick)                       |
| W-125-G          | Vertical Shaft Washer (thin)                        |
| W-321-G          | Main Drive Gear Distance Washer                     |



## PART NO.

## DESCRIPTION

**SUPER TYPE PARTS****A-11****HANDLE SHAFT AND COLLAR**

C-126-A

Main Drive Gear Clutch

C-189-A

Handle Clutch Collar

P-115-A

Handle Shaft Pin (2)

S-909-A

Handle Shaft \*

**A-16****INTERMITTENT CASE OIL TUBE**

F-165-A

Oil Tube Fastening Flange \*

T-158-A

Oil Tube \*

**A-18****MAIN DRIVE & LOWER SPROCKET SHAFT OIL TUBE**

F-165-A

Oil Tube Fastening Flange \*

T-143-A

Oil Tube \*

**A-19****INTERMEDIATE VERTICAL SHAFT OIL TUBE**

F-165-A

Oil Tube Fastening Flange \*

T-191-A

Oil Tube \*

**A-20****VERTICAL SHAFT (UPPER END) OIL TUBE**

F-165-A

Oil Tube Fastening Flange \*

T-157-G

Oil Tube \*

**A-21****UPPER SPROCKET SHAFT OIL TUBE**

F-165-A

Oil Tube Fastening Flange \*

T-150-A

Oil Tube \*

A-167-A

Lower Pad Roller Arm (with Internal Spring) (includes S-852-C and P-417-C)

A-168-C

Upper Pad Roller Arm (with Internal Spring) (includes S-852-C and P-417-C)

B-314-G

Shutter Gear Bracket

**BBB****SUPER TYPE INTERMITTENT MOVEMENT COMPLETE****C-16****UPPER PAD ROLLER STUD AND KNOB**

K-144-C

Upper Pad Roller Stud Knob \*

S-941-C

Upper Pad Roller Stud \*

**C-20****UPPER PAD ROLLER ARM COMPLETE**

A-168-C

Upper Pad Roller Arm

C-16

Upper Pad Roller Stud and Knob

N-166-C

Upper Pad Roller Arm Nut

P-102-C

Pad Roller

P-417-C

Upper Pad Roller Arm Plunger

S-248-A

Upper Pad Roller Stud Screw

S-706-C

Upper Pad Roller Arm Screw

S-852-C

Upper Pad Roller Arm Spring

S-869-C

Upper Pad Roller Arm Plunger Retain Screw

C-375-BB

Intermittent Case

C-378-BB

Intermediate Shaft Retaining Collar

D-140-D

Upper Non-Operating Side Door

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO.    | DESCRIPTION                                                       |
|-------------|-------------------------------------------------------------------|
| <b>E-40</b> | <b>LATERAL GUIDE ROLLER AND SHAFT ASSEMBLY</b>                    |
| C-129-E     | Lateral Guide Roller Shaft Collar                                 |
| E-15        | Lateral Guide Roller Shaft & Washer Assembly                      |
| R-246-E     | Lateral Guide Roller (2)                                          |
| S-762-E     | Lateral Guide Roller Spring                                       |
| S-763-E     | Lateral Guide Roller Collar Screw                                 |
| <b>E-48</b> | <b>FILM GATE REMOVABLE DOOR AND BRACKET</b>                       |
| D-148-E     | Removable Door                                                    |
| E-3         | Intermittent Film Guide Assembly                                  |
| E-45        | Removable Door Locating Bracket and Stud Assembly                 |
| H-118-E     | Removable Door Film Guide Holder                                  |
| K-150-E     | Removable Door Clamping Knob (2)                                  |
| P-100-E     | Removable Door Pad                                                |
| P-553-E     | Removable Door Protector                                          |
| RP-24       | Removable Door Protector Fastening Screw (3)                      |
| S-130-E     | Removable Door Pad Spring & Film Guide Holder Fastening Screw (8) |
| S-132-E     | Intermittent Film Guide Retaining Spring Screw                    |
| S-326-E     | Intermittent Film Guide Retaining Spring                          |
| S-328-E     | Removable Door Pad Spring                                         |
| S-580-E     | Removable Door Double Tension Shoe (2)                            |
| S-581-E     | Removable Door Double Tension Shoe Spring                         |
| S-1157-E    | Removable Door Support Bracket Screw (Long)                       |
| S-1159-E    | Removable Door Support Bracket Screw (Short)                      |
| <b>G-24</b> | <b>VERTICAL SHAFT AND DOUBLE BEVEL GEAR</b>                       |
| G-13        | Double Bevel Gear with Taper Pin                                  |
| P-368-G     | Double Bevel Gear Taper Pin                                       |
| S-870-G     | Vertical Shaft                                                    |
| <b>G-30</b> | <b>SHUTTER GEAR BRACKET WITH STRAIGHT BEVEL GEAR</b>              |
| B-314-G     | Shutter Gear Bracket                                              |
| C-193-G     | Shutter Gear Shaft Collar                                         |
| G-4         | Framing Slide Assembly                                            |
| G-5         | Bevel Gear, Shaft and Collar Assembly                             |
| G-116-G     | Spiral Driving Gear (Broached Hole)                               |
| G-248-G     | Shutter Spiral Gear (Formica)                                     |
| R-120-G     | Framing Slide Guide Rod                                           |
| S-141-G     | Framing Slide Set Screw                                           |
| S-436-G     | Shutter Gear Shaft Collar Fastening Screw                         |
| S-437-G     | Shutter Spiral Gear Fastening Screw                               |
| S-871-G     | Shutter Gear Shaft                                                |
| W-105-B     | Shutter Driving Bevel Gear Thrust Washer                          |
| <b>G-32</b> | <b>SHUTTER GEAR BRACKET OIL TUBE &amp; FLANGE (FRONT END)</b>     |
| F-165-A     | Oil Tube Fastening Flange *                                       |
| T-147-G     | Oil Tube *                                                        |
| <b>G-33</b> | <b>BACK SHUTTER BRACKET OIL TUBE</b>                              |
| F-165-A     | Oil Tube Fastening Flange *                                       |
| T-149-A     | Oil Tube *                                                        |

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

## PART NO.

## DESCRIPTION

### **G-34 INTERMEDIATE GEAR SHAFT & STRAIGHT BEVEL GEAR**

C-378-G Intermediate Shaft  
 G-12 Intermediate Gear & Plate Assembly  
 G-134-G Intermediate (Steel) Gear  
 G-135-G Intermediate Bevel Gear  
 S-125-B Intermediate Shaft Retaining Collar Set Screw  
 S-145-G Intermediate Gear Washer Retaining Screw  
 S-1032-G Intermediate Shaft  
 W-140-G Intermediate Gear Retaining Washer  
 W-306-G Intermediate Bevel Gear Washer

### **G-39 SHUTTER GEAR BRACKET OIL TUBE**

F-304-A Oil Tube Fastening Flange \*  
 T-164-G Oil Tube \*

### **G-44 SHUTTER BRACKET OIL TUBE (REAR)**

F-176-G Oil Tube Fastening Flange \*  
 T-175-G Oil Tube \*

### **G-45 SHUTTER BRACKET REAR OIL TUBE ASSEMBLY**

BP-128 Pilot Lamp Wire Clamp  
 G-44 Shutter Bracket Rear Oil Tube  
 G-211-G Oil Tube Gasket  
 GA-107 Oil Tube Oil Cup  
 S-932-G Oil Tube Flange Fastening Screw

G-211-G Oil Tube & Flange Gasket  
 P-553-E Removable Type Film Gate Protector  
 R-246-E Lateral Guide Roller  
 S-870-G Vertical Shaft  
 S-871-G Shutter Bracket Shaft  
 S-900-E Film Trap Shoe Retaining Screw  
 S-957-D Shutter Guide Spacer  
 S-958-C Lens Slide Guide Pin Screw  
 S-1036-E Film Trap Shoe (Right) (For Slide-In-Aperture)  
 S-1037-E Film Trap Shoe (Left) (For Slide-In-Aperture)  
 S-1142-E Film Trap Shoe (Vertical Aperture Type)  
 S-1153-D Handle Shaft Oil Shield

\*Parts Not Sold Separately



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| A-1      | 7.80  | A-186-R  | 7.90  | B-248-BB | 1.95  |
| A-2      | 1.80  | A-187-R  | 6.00  | B-254-BB | 2.05  |
| A-4      | 6.25  | A-188-R  | 6.00  | B-262-G  | 1.00  |
| A-5      | .40   | B-1      | 12.50 | B-267-L  | 45.00 |
| A-6      | .40   | B-4      | 7.00  | B-288-D  | .10   |
| A-7      | 8.35  | B-8      | 8.80  | B-297-E  | 3.40  |
| A-8      | 1.30  | B-9      | 20.40 | B-314-G  | 8.65  |
| A-9      | 7.20  | B-11     | 11.65 | B-316-D  | .10   |
| A-11     | 11.95 | B-12     | 25.40 | B-321-R  | 7.90  |
| A-16     | .90   | B-14     | 9.05  | B-323-BB | 2.35  |
| A-20     | .65   | B-15     | 3.25  | B-332-D  | .25   |
| A-24     | 7.05  | B-16     | 7.50  | B-342-A  | 1.45  |
| A-104-C  | .85   | B-32     | 2.20  | B-355-D  | 2.90  |
| A-107-L  | 2.05  | B-106-G  | .25   | B-439-D  | .85   |
| A-116-L  | 9.70  | B-110-S  | .35   | B-466-D  | 3.00  |
| A-118-G  | 2.30  | B-120-M  | 2.60  | B-482-BB | 2.40  |
| A-120-L  | 8.10  | B-121-P  | 2.55  | B-484-BB | 4.40  |
| A-131-A  | 1.00  | B-124-L  | 1.60  | BB-21    | 13.25 |
| A-134-W  | 3.55  | B-127-A  | 3.00  | BB-22    | 19.45 |
| A-135-W  | 4.30  | B-147-U  | 1.45  | BB-26    | 15.85 |
| A-136-C  | 1.50  | B-189-L  | 12.50 | BB-27    | 3.30  |
| A-137-C  | 1.90  | B-195-W  | 3.80  | BB-28    | 5.80  |
| A-141-W  | 4.50  | B-197-G  | 7.00  | BB-30    | 3.70  |
| A-142-U  | 11.05 | B-198-A  | 9.45  | BB-31    | .15   |
| A-167-C  | 2.80  | B-223-L  | 16.90 | BB-32    | 2.20  |
| A-168-C  | 2.30  | B-236-L  | .25   | BB-33    | 17.65 |
| A-183-D  | .70   | B-246-BB | 3.60  | BB-34    | 44.35 |
| A-184-R  | 6.00  | B-247-BB | 4.20  | BB-38    | 7.50  |
| A-185-R  | 6.00  |          |       |          |       |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| BB-39    | 1.60  | C-181-U  | 4.70  | C-369-D  | .30   |
| BB-40    | 13.50 | C-182-W  | 5.40  | C-371-D  | 3.50  |
| BB-42    | 9.75  | C-183-U  | 4.75  | C-375-BB | 15.00 |
| BB-52    | 20.85 | C-184-W  | 4.95  | C-377-D  | .45   |
| C-2½     | 2.95  | C-189-A  | 1.35  | C-378-G  | 1.50  |
| C-3½     | 4.40  | C-192-G  | .50   | C-382-A  | .65   |
| C-4      | 1.60  | C-193-G  | .60   | C-405-D  | .70   |
| C-5½     | 7.00  | C-206-M  | .55   | C-406-E  | .10   |
| C-8      | 6.50  | C-226-U  | .15   | C-407-E  | .10   |
| C-9      | .90   | C-249-L  | 18.90 | C-408-D  | .65   |
| C-11     | 2.00  | C-282-W  | .35   | C-483-BB | 1.00  |
| C-12     | .45   | C-285-D  | 2.00  | D-1      | 5.95  |
| C-14     | 1.60  | C-286-C  | 2.65  | D-2      | 1.50  |
| C-16     | .45   | C-287-U  | 9.70  | D-3      | 1.50  |
| C-21     | 6.45  | C-288-U  | 7.40  | D-4      | 4.50  |
| C-25     | 3.15  | C-289-W  | 9.00  | D-5      | 6.50  |
| C-38     | 1.15  | C-290-W  | 6.30  | D-6      | .50   |
| C-53     | 4.20  | C-293-BB | .20   | D-7      | .80   |
| C-62     | 35.00 | C-294-BB | .20   | D-9      | 4.75  |
| C-105-L  | 8.10  | C-295-BB | .60   | D-11     | 6.00  |
| C-120-B  | .20   | C-316-G  | .10   | D-12     | 3.25  |
| C-126-A  | 1.60  | C-346-D  | 1.35  | D-13     | 2.65  |
| C-127-E  | .10   | C-347-D  | 1.25  | D-14     | 6.30  |
| C-128-M  | .35   | C-354-A  | 1.60  | D-16     | 4.50  |
| C-129-E  | .25   | C-365-D  | .10   | D-17     | 1.15  |
| C-151-D  | 3.00  | C-366-D  | .45   | D-18     | .70   |
| C-152-D  | 2.30  | C-367-D  | .45   | D-19     | .45   |
| C-157-C  | 1.40  | C-368-D  | .10   | D-22     | 1.60  |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO.  | PRICE | PART NO. | PRICE |
|----------|-------|-----------|-------|----------|-------|
| D-23     | 5.40  | D-99      | 7.00  | E-10     | 15.00 |
| D-27     | 1.80  | D-105-D   | 2.00  | E-14     | 2.75  |
| D-33     | 1.60  | D-108-D   | 3.75  | E-15     | .45   |
| D-34     | 2.25  | D-121-W   | 1.35  | E-19     | 6.50  |
| D-49     | 5.60  | D-122-W   | .75   | E-30     | 3.50  |
| D-50     | 7.35  | D-128-D   | 3.25  | E-35     | 4.05  |
| D-65     | 9.75  | D-130-BB  | .35   | E-40     | 3.50  |
| D-66     | 3.85  | D-138-D   | .70   | E-43     | 4.05  |
| D-67     | 5.65  | D-143-D   | 2.45  | E-44     | 58.00 |
| D-74     | 12.60 | D-144-D   | 4.05  | E-45     | 6.35  |
| D-75     | 7.20  | D-145-E   | 9.75  | E-46     | 20.00 |
| D-76     | 10.00 | D-148-E   | 5.50  | E-48     | 21.00 |
| D-77     | 5.00  | DD-1      | 2.70  | E-49     | 14.30 |
| D-80     | 4.00  | DD-4      | 5.60  | E-68     | 58.00 |
| D-81     | 3.00  | DD-5      | .70   | E-81     | 14.40 |
| D-82     | 1.25  | DD-6      | 6.80  | E-83     | 14.40 |
| D-85     | 2.95  | DD-7      | 13.95 | E-100-C  | .90   |
| D-85-AA  | 5.50  | DD-8 N.S. | 11.25 | E-101-C  | 1.10  |
| D-86     | 11.25 | DD-8 O.S. | 15.20 | E-112-R  | 3.50  |
| D-87     | 44.55 | DD-9      | .80   | E-113-R  | 4.50  |
| D-89     | 3.50  | DD-11     | 6.50  | E-114-R  | 6.75  |
| D-91     | 4.70  | DD-12     | 4.00  | E-115-R  | 4.50  |
| D-92     | 1.30  | DD-23     | 2.05  | E-152-G  | .70   |
| D-93     | 11.25 | "E"       | 52.50 | F-168-D  | 3.40  |
| D-94     | 4.75  | "EE"      | 52.50 | F-169-D  | 4.00  |
| D-95     | 3.50  | E-2       | 6.30  | F-172-D  | 9.00  |
| D-96     | 3.50  | E-3       | 2.15  | F-174-D  | 3.40  |
| D-97     | 7.00  | E-6       | .55   | G-1      | 14.00 |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| G-3      | 2.50  | G-121-A  | .10   | G-224-D  | 4.05  |
| G-4      | 7.25  | G-124-D  | 1.20  | G-225-BB | .10   |
| G-5      | 6.15  | G-125-E  | .20   | G-226-BB | .10   |
| G-6      | 32.65 | G-126-E  | .40   | G-228-A  | 2.05  |
| G-12     | 3.00  | G-131-U  | .20   | G-240-D  | .45   |
| G-13     | 6.45  | G-134-G  | 1.50  | G-241-BB | .10   |
| G-14     | 15.95 | G-135-G  | 5.00  | G-243-D  | 2.95  |
| G-15     | 7.90  | G-138-G  | 1.90  | G-248-G  | 2.50  |
| G-18     | 18.50 | G-139-G  | 3.40  | G-308-G  | 6.00  |
| G-19     | 4.30  | G-147-G  | 2.50  | GA-107   | .10   |
| G-20     | 3.80  | G-148-B  | 2.65  | H-118-E  | 1.00  |
| G-24     | 8.25  | G-180-R  | .40   | H-120-G  | 1.60  |
| G-25     | 1.30  | G-185-BB | 2.55  | H-121-G  | 1.60  |
| G-28     | 1.35  | G-186-BB | 1.50  | H-124-W  | 2.90  |
| G-30     | 34.90 | G-187-BB | 1.65  | H-130-C  | 3.05  |
| G-32     | .70   | G-188-BB | .10   | H-143-U  | 1.35  |
| G-34     | 16.90 | G-189-BB | .60   | H-148-L  | .90   |
| G-35     | 3.25  | G-195-BB | .60   | H-149-A  | 4.60  |
| G-40     | 32.65 | G-203-D  | 2.05  | H-196-G  | 3.40  |
| G-44     | .45   | G-206-D  | 2.70  | H-210-R  | 1.60  |
| G-45     | .85   | G-211-G  | .10   | H-214-R  | 1.60  |
| G-105-B  | 1.80  | G-215-G  | 6.00  | H-217-D  | 1.80  |
| G-111-G  | 1.25  | G-216-G  | 4.05  | H-251-D  | 1.80  |
| G-112-G  | 6.00  | G-217-D  | 4.05  | K-100-N  | .45   |
| G-114-M  | 1.15  | G-218-D  | 4.05  | K-106-D  | .70   |
| G-115-G  | 2.65  | G-219-D  | 4.05  | K-120-A  | 1.15  |
| G-116-G  | 1.50  | G-220-D  | .40   | K-130-BB | .55   |
| G-118-B  | 1.60  | G-222-D  | 4.30  | K-131-A  | .85   |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| K-132-D  | .60   | L-130-A  | .10   | N-197-D  | .10   |
| K-136-A  | .65   | L-151-U  | .20   | N-198-D  | 1.15  |
| K-137-D  | .75   | L-161-C  | 2.70  | N-201-D  | .25   |
| K-139-D  | .60   | L-162-D  | .70   | N-202-D  | .45   |
| K-141-D  | .55   | L-170-D  | .35   | N-204-BB | .25   |
| K-149-C  | .55   | L-171-E  | .35   | N-211-D  | .80   |
| K-150-E  | .35   | L-177-D  | 2.25  | N-212-E  | .10   |
| K-6145-D | .90   | L-185-E  | .20   | "P"      | 6.00  |
| KD-1     | 2.00  | "M"      | 8.00  | "PP"     | 7.00  |
| L-1      | 1.15  | "MM"     | 9.00  | P-1      | 3.75  |
| L-2      | 1.15  | M-1      | 2.50  | P-2      | .65   |
| L-3      | 6.30  | M-2      | 4.05  | P-3      | .90   |
| L-4      | 11.70 | M-3      | 1.15  | P-100-E  | 1.00  |
| L-5      | 27.00 | M-5      | 2.25  | P-102-C  | 1.15  |
| L-9      | 37.50 | M-6      | 1.70  | P-106-A  | .10   |
| L-12     | 67.00 | MA-107   | .10   | P-107-G  | .10   |
| L-13     | 20.70 | N-108-M  | .25   | P-113-F  | .10   |
| L-104-G  | 1.15  | N-115-C  | .30   | P-115-A  | .10   |
| L-105-D  | 1.35  | N-117-S  | .15   | P-119-E  | .10   |
| L-107-G  | 2.45  | N-118-A  | .20   | P-121-C  | .10   |
| L-108-P  | .50   | N-119-G  | .10   | P-124-A  | .10   |
| L-110-C  | .10   | N-123-A  | .50   | P-127-G  | .10   |
| L-111-C  | .65   | N-132-U  | .10   | P-128-G  | .10   |
| L-112-D  | .10   | N-135-W  | .10   | P-144-D  | .25   |
| L-113-D  | .25   | N-166-C  | .25   | P-153-B  | .10   |
| L-114-G  | 1.30  | N-172-E  | .55   | P-159-P  | .10   |
| L-115-G  | 1.60  | N-177-G  | .70   | P-160-M  | .10   |
| L-117-L  | 2.50  | N-196-D  | .10   | P-167-A  | .10   |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| P-169-G  | .10   | P-406-E  | .25   | R-43     | 11.75 |
| P-188-A  | .10   | P-417-C  | .20   | R-44     | 9.50  |
| P-189-A  | 1.65  | P-445-E  | .35   | R-45     | 11.00 |
| P-190-X  | 2.25  | P-462-E  | 1.35  | R-46     | 12.90 |
| P-196-A  | .55   | P-466-D  | .10   | R-47     | 9.50  |
| P-197-L  | .45   | P-482-E  | .10   | R-52     | .70   |
| P-207-D  | 2.45  | P-527-E  | .35   | R-120-G  | .20   |
| P-211-M  | .10   | P-529-E  | .40   | R-128-G  | .15   |
| P-234-U  | .10   | P-541-D  | .20   | R-133-A  | 2.40  |
| P-235-W  | .20   | P-543-D  | 1.45  | R-150-A  | .10   |
| P-236-U  | .30   | P-544-E  | .35   | R-160-C  | .85   |
| P-237-U  | .45   | P-545-E  | .10   | R-161-C  | .85   |
| P-256-L  | .60   | P-552-E  | 1.65  | R-162-D  | .45   |
| P-279-B  | .45   | P-553-E  | 1.75  | R-178-A  | .35   |
| P-289-C  | .10   | P-562-E  | .20   | R-214-E  | 1.00  |
| P-320-E  | 1.80  | P-671-E  | .60   | R-227-C  | 1.00  |
| P-325-E  | .65   | P-672-E  | .65   | R-240-D  | 1.80  |
| P-331-X  | 2.25  | Q-101-L  | 4.50  | R-245-D  | 1.30  |
| P-341-D  | .10   | R-15     | 1.80  | R-246-E  | 1.25  |
| P-347-BB | .10   | R-32     | 16.25 | R-255-D  | .90   |
| P-350-BB | .10   | R-33     | 16.25 | R-261-D  | 1.65  |
| P-353-BB | .10   | R-34     | 11.40 | R-264-D  | 1.15  |
| P-359-E  | .10   | R-36     | 15.75 | R-274-D  | .45   |
| P-360-BB | .30   | R-37     | 11.00 | RP-24    | .10   |
| P-368-G  | .10   | R-38     | 12.75 | RP-140   | .10   |
| P-377-E  | .55   | R-39     | 12.75 | S-100-E  | .10   |
| P-380-E  | .25   | R-40     | 2.25  | S-101-C  | .10   |
| P-382-D  | .65   | R-42     | 14.00 | S-102-E  | .10   |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| S-105-R  | .70   | S-178-D  | .10   | S-309-E  | 1.25  |
| S-106-D  | .10   | S-180-D  | .35   | S-310-E  | .45   |
| S-109-L  | .10   | S-181-D  | .10   | S-311-E  | .45   |
| S-115-A  | .10   | S-185-D  | .10   | S-315-P  | .10   |
| S-118-L  | .10   | S-187-W  | .10   | S-321-G  | 6.75  |
| S-122-C  | .10   | S-189-W  | .15   | S-322-A  | .75   |
| S-124-D  | .45   | S-192-D  | .10   | S-323-A  | 1.60  |
| S-125-B  | .10   | S-193-C  | .75   | S-326-E  | .10   |
| S-130-E  | .10   | S-194-C  | .35   | S-327-E  | .10   |
| S-132-E  | .10   | S-209-G  | .45   | S-328-E  | .10   |
| S-133-C  | .10   | S-217-G  | .45   | S-329-C  | .10   |
| S-137-C  | .20   | S-218-L  | .10   | S-330-G  | .10   |
| S-138-E  | .10   | S-222-G  | .10   | S-331-W  | .10   |
| S-141-A  | .10   | S-223-G  | .10   | S-332-P  | .10   |
| S-142-G  | 1.60  | S-229-L  | .45   | S-337-E  | .10   |
| S-143-A  | .10   | S-230-L  | .10   | S-338-D  | .10   |
| S-144-G  | .10   | S-231-A  | .10   | S-340-A  | .10   |
| S-145-G  | .10   | S-233-U  | .10   | S-341-G  | .15   |
| S-148-G  | .10   | S-246-D  | .10   | S-342-A  | .10   |
| S-150-C  | .10   | S-248-A  | .10   | S-343-A  | .10   |
| S-151-D  | .10   | S-252-A  | .45   | S-345-M  | .10   |
| S-157-B  | .10   | S-253-A  | .20   | S-353-A  | .10   |
| S-161-A  | .10   | S-257-G  | .10   | S-357-G  | .30   |
| S-162-E  | .10   | S-270-L  | .10   | S-367-E  | .70   |
| S-165-C  | .10   | S-278-A  | .10   | S-369-G  | .60   |
| S-170-R  | .50   | S-283-A  | .10   | S-370-P  | .20   |
| S-172-L  | .10   | S-295-M  | .75   | S-375-L  | .90   |
| S-177-E  | .10   | S-300-C  | 3.00  | S-386-A  | .10   |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO. | PRICE |
|----------|-------|----------|-------|----------|-------|
| S-387-L  | 2.85  | S-575-X  | 1.50  | S-733-W  | .10   |
| S-388-L  | 8.85  | S-580-E  | .25   | S-736-E  | .45   |
| S-427-Q  | .10   | S-581-E  | .10   | S-750-BB | 4.90  |
| S-432-E  | .10   | S-634L   | 19.80 | S-756-A  | .30   |
| S-434E   | .10   | S-665-E  | .15   | S-757-BB | .15   |
| S-436-G  | .10   | S-670-L  | 1.35  | S-762-E  | .10   |
| S-437-G  | .10   | S-671-L  | 1.90  | S-763-E  | .10   |
| S-438-M  | .10   | S-672-L  | 2.65  | S-765-BB | .10   |
| S-442-G  | .10   | S-673-L  | 3.05  | S-771-D  | .10   |
| S-447-G  | 2.70  | S-674-L  | 3.70  | S-773-G  | 1.15  |
| S-454-B  | 1.80  | S-675-L  | 4.50  | S-775-C  | .25   |
| S-485-C  | .10   | S-692-B  | .10   | S-776-C  | .10   |
| S-486-E  | 2.50  | S-693-B  | .25   | S-777-E  | .10   |
| S-487E   | 2.50  | S-698-E  | .10   | S-778-E  | .10   |
| S-493-D  | .10   | S-701-L  | 16.20 | S-781-G  | 1.90  |
| S-494A   | .20   | S-702-U  | 1.35  | S-787-D  | .10   |
| S-508-D  | .35   | S-703-W  | 1.60  | S-851-E  | .10   |
| S-514-C  | .15   | S-705-G  | .10   | S-852-C  | .10   |
| S-520-L  | .75   | S-706-C  | .15   | S-863-A  | .10   |
| S-550-G  | 1.50  | S-716-E  | .10   | S-866-C  | .10   |
| S-551-B  | 7.50  | S-721-U  | .10   | S-870-G  | 1.45  |
| S-567-C  | .90   | S-724-BB | .10   | S-871-G  | 1.85  |
| S-569-A  | .10   | S-725-BB | .10   | S-873-C  | .10   |
| S-570-A  | .10   | S-726-BB | 1.65  | S-874-C  | .30   |
| S-572-C  | .50   | S-728-BB | .10   | S-881-E  | .45   |
| S-573-C  | .50   | S-729-BB | .10   | S-884-D  | .25   |
| S-573½-C | .50   | S-730-BB | 9.20  | S-885-D  | .10   |
| S-574-G  | 1.90  | S-731-BB | .40   | S-886-D  | .10   |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO. | PRICE | PART NO.  | PRICE |
|----------|-------|----------|-------|-----------|-------|
| S-893-D  | .10   | S-1011-D | .15   | S-1141-E  | .10   |
| S-897-D  | .10   | S-1012-D | .10   | S-1142-E  | 4.50  |
| S-898-E  | .10   | S-1015-D | 1.60  | S-1143-E  | 1.25  |
| S-900-E  | .10   | S-1020-D | .15   | S-1144-E  | .10   |
| S-902-D  | .10   | S-1026-D | .10   | S-1145-E  | .15   |
| S-905-D  | .10   | S-1030-D | .20   | S-1147-E  | .10   |
| S-922-U  | .10   | S-1031-G | 2.25  | S-1148-E  | .10   |
| S-951-BB | 11.00 | S-1032-G | 2.50  | S-1149-E  | .10   |
| S-957-D  | .20   | S-1033-G | 1.35  | S-1152-D  | .90   |
| S-958-C  | .10   | S-1036-E | 3.00  | S-1153-D  | 1.05  |
| S-962-D  | .20   | S-1037-E | 3.00  | S-1157-E  | .10   |
| S-964-D  | .10   | S-1039-D | .10   | S-1159-E  | .10   |
| S-965-D  | .10   | S-1045-D | 1.60  | S-1164-G  | 1.50  |
| S-966-D  | .55   | S-1046-D | 2.50  | S-1361-E  | .40   |
| S-968-D  | .75   | S-1048-A | .10   | S-1511-E  | .10   |
| S-969-D  | .10   | S-1069-D | .10   | SC-309-BB | .10   |
| S-970-D  | .10   | S-1082-G | 3.00  | T-101-E   | .25   |
| S-971-D  | .10   | S-1092-E | 1.50  | T-106-B   | .25   |
| S-972-D  | .10   | S-1093-E | 1.50  | T-107-B   | .20   |
| S-973-D  | .10   | S-1129-D | .10   | T-137-E   | 1.25  |
| S-978-D  | .10   | S-1133-D | .10   | T-154-D   | .10   |
| S-987-D  | .10   | S-1134-D | 1.10  | T-159-D   | .25   |
| S-989-D  | .15   | S-1135-D | .70   | T-171-E   | 14.40 |
| S-997-D  | .45   | S-1136-D | .10   | T-172-E   | 14.40 |
| S-999-D  | .10   | S-1137-D | .10   | U-1       | .70   |
| S-1003-D | .80   | S-1138-D | .10   | U-3       | 2.00  |
| S-1004-D | .15   | S-1139-D | .10   | U-4       | .50   |
| S-1005-D | .10   | S-1140-E | .10   | W-1       | 6.50  |



# ORDER BY PART NUMBER

| PART NO. | PRICE | PART NO.         | PRICE |
|----------|-------|------------------|-------|
| W-5      | 2.70  | W-148-E          | .55   |
| W-6      | 2.10  | W-152-B          | 6.05  |
| W-7      | 2.95  | W-160-C          | .10   |
| W-27     | 2.50  | W-163-W          | .10   |
| W-40     | 12.30 | W-191-BB         | 3.25  |
| W-105-B  | .40   | W-196-G          | 1.60  |
| W-108-P  | .10   | W-197-L          | .10   |
| W-109-L  | .10   | W-208-G (Steel)  | .65   |
| W-112-G  | .10   | W-208-G(Formica) | .10   |
| W-113-L  | .10   | W-221-D          | .25   |
| W-114-G  | .40   | W-222-D          | .10   |
| W-116-S  | .10   | W-223-D          | .45   |
| W-118-A  | .10   | W-227-BB         | .10   |
| W-122-B  | .35   | W-228-BB         | .45   |
| W-124-G  | .20   | W-231-D          | .10   |
| W-125-G  | .20   | W-232-BB         | .10   |
| W-127-D  | 4.30  | W-235-A          | 1.95  |
| W-129-P  | 1.15  | W-253-D          | .10   |
| W-131-B  | 4.95  | W-254-D          | .45   |
| W-140-G  | .15   | W-306-G          | .40   |
| W-141-D  | 2.45  | W-321-G          | .40   |
| W-145-D  | 2.25  | WA-12-BB         | .10   |
| W-146-D  | 2.25  |                  |       |



THE LIBRARY

1902



THE LIBRARY  
OF THE  
UNIVERSITY OF CALIFORNIA  
AT BERKELEY



THE UNIVERSITY OF CHICAGO

LIBRARY

1921

1921

1921

1921