

PARTS LIST

FOR



PROJECTOR MECHANISM



**INTERNATIONAL PROJECTOR
CORPORATION**

88 - 96 GOLD STREET - - NEW YORK CITY

Printed in U. S. A. - Copyrighted By International Projector Corporation 1940

NATIONAL THEATRE SUPPLY COMPANY

• BRANCHES •

EASTERN DISTRICT

ALBANY

1039 BROADWAY
Phone: 5-1479

BALTIMORE

417 ST. PAUL PLACE
Phone: Vernon 8266

BOSTON

40 PIEDMONT STREET
Phone: Liberty 3294

BUFFALO

500 PEARL STREET
Phone: Washington 1736

NEW HAVEN

122 MEADOW STREET
Phone: 5-7371

NEW YORK

356 W. 44th STREET
Phone: Circle 5-6900

PHILADELPHIA

1225 VINE STREET
Phone: Spruce 6156

SOUTHERN DISTRICT

ATLANTA

187 WALTON STREET, N.W.
Phone: Jackson 4075

CHARLOTTE

304 S. CHURCH STREET
Phone: 7753

DALLAS

300 S. HARWOOD STREET
Phone: 7-2135

MEMPHIS

400 S. SECOND STREET
Phone: 8-5358

NEW ORLEANS

220 S. LIBERTY STREET
Phone: Raymond 4455

OKLAHOMA CITY

700 W. GRAND AVENUE
Phone: 3-9703

WESTERN DISTRICT

DENVER

2111 CHAMPA STREET
Phone: Tabor 0201

LOS ANGELES

1961 S. VERMONT AVENUE
Phone: Republic 4193

SALT LAKE CITY

248 E. FIRST SOUTH STREET
Phone: Wasatch 5959

SAN FRANCISCO

255 GOLDEN GATE AVENUE
Phone: Market 4171

SEATTLE

2400 FIRST AVENUE
Phone: Main 4910

CENTRAL DISTRICT

CHICAGO

1325 S. WABASH AVENUE
Phone: Calumet 7678

CINCINNATI

1637 CENTRAL PARKWAY
Phone: Main 6581

CLEVELAND

2128 PAYNE AVENUE
Phone: Prospect 4613

DES MOINES

1115 HIGH STREET
Phone: 4-2322

DETROIT

2312 CASS AVENUE
Phone: Cadillac 2447

INDIANAPOLIS

436 N. ILLINOIS STREET
Phone: Lincoln 5758

KANSAS CITY

223 W. 18th STREET
Phone: Harrison 3256

MILWAUKEE

1027 N. 8th STREET
Phone: Marquette 7333

MINNEAPOLIS

56 GLENWOOD AVENUE
Phone: Main 8273

PITTSBURGH

1721 BOULEVARD OF THE ALLIES
Phone: Grant 4630

ST. LOUIS

3212 OLIVE STREET
Phone: Jefferson 8494

SIMPLEX PROGRESS AND SIMPLEX PRECISION

In the past two years the International Projector Corporation has made remarkable advances in the design and manufacture of *Simplex* Projectors and Parts. Vast sums have been spent to increase ease of operation, wearing qualities of the mechanism and entertainment value of the picture. Realizing that audiences are more keenly aware of the differences between good and bad projection, theatre owners are more exacting than ever before and we have again anticipated the requirements of progressive exhibitors by many outstanding changes and improvements.

The new spiral bevel gears insure smoother operation, greatly reduce the noise level and are a tremendous stride forward in mechanism design and construction. Intermittent sprockets are hardened and then ground, which insures a definitely longer life and a far more accurate sprocket. The new shockproof gear has a Thiokol insert which permits the gear to take up the irregularities due to the action of the intermittent movement. These are only a few of the important improvements which have been incorporated in our later equipments and are the result of the work which is being constantly carried on by our research department and engineering staff.

Every *Simplex* part is made to meet definite practical requirements which improve projection and lower maintenance charges. Many vital parts are made to a ten-thousandth part of an inch - scientific accuracy that assures a rocksteady picture. *Simplex* precision is extremely important to prevent unsteadiness at the aperture, which is magnified hundreds of times on the screen. This "jump" or "sidesway" becomes annoyingly noticeable to patrons and can be prevented by installing new *Simplex* Projectors or by repairing or replacing with *Genuine Simplex Parts*. Hold regular patrons and get new ones with *Simplex* Projection which improves entertainment and box-office value of the picture. Better Projection Pays. Neglect is poor economy. Repair - replace with *Genuine Simplex Parts*.


Simplex




HOME OF SIMPLEX EQUIPMENT


Oldest and largest factory in the world devoted to the manufacture of standard professional motion picture projectors. Here have been originated and perfected methods and standards which for over thirty years have given us an international leadership in the motion picture field. A thoroughly progressive spirit enables us to give theatre owners the highest possible value at the lowest possible cost. No other firm has facilities that are at all comparable to ours for the economical and efficient manufacture of motion picture equipment and parts.

Simplex service supplements *Simplex* quality. Exhibitors know they can rely upon *Simplex* Distributors for satisfactory installation of *Simplex* equipment, advice and help when emergencies arise and prompt delivery of genuine *Simplex* parts when needed. *GENUINE SIMPLEX PARTS* always give the greatest value and are absolutely essential to get the best results with *SIMPLEX PROJECTORS*.


















D-99 ASSEMBLY













D-64 ASSEMBLY














BB-27 ASSEMBLY









ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
A-11	HANDLE SHAFT AND COLLARS	
C-126-A	Main Drive Gear Clutch	
C-354-A	Handle Clutch Collar	
P-115-A	Handle Shaft Pin	(2)
P-649-A	Handle Shaft Plug	(2)
S-909-A	Handle Shaft	*
A-16	INTERMITTENT CASE OIL TUBE	
F-165-A	Oil Tube Fastening Flange	*
T-158-A	Oil Tube	*
A-17	SHUTTER ADJUSTING ROD	
C-355-A	Shutter Adjusting Rod Collar	
P-430-A	Shutter Adjusting Rod Pin	
R-242-A	Shutter Adjusting Rod	
A-18	MAIN DRIVE AND LOWER SPROCKET SHAFT OIL TUBE	
F-165-A	Oil Tube Fastening Flange	*
T-143-A	Oil Tube	*
A-19	INTERMEDIATE VERTICAL SHAFT OIL TUBE	
F-165-A	Oil Tube Fastening Flange	*
T-191-A	Oil Tube	*
A-20	VERTICAL SHAFT (UPPER END) OIL TUBE	
F-165-A	Oil Tube Fastening Flange	*
T-157-G	Oil Tube	*
A-21	UPPER SPROCKET SHAFT OIL TUBE	
F-165-A	Oil Tube Fastening Flange	*
T-150-A	Oil Tube	*
A-27	FRAMING CAM AND PINS	
C-336-A	Framing Cam	*
P-125-A	Framing Cam Pin	*
A-137-C	Lower Pad Roller Arm	
A-168-C	Upper Pad Roller Arm	
A-192-BB	Intermittent Case Cover and Arm	
A-215-C	Takeup Sprocket Pad Roller Arm	
B-106-G	Framing Slide Lever Block	
B-246-BB	Flywheel Shaft Bearing	
B-250-BB	Outer Bearing Oil Cup Ball	
B-260-C	Upper Magazine Roller Holder Block Right (Mass.)	
B-288-D	Door Opening Stop Bushing	
B-293-A	Mechanism Base	
B-296-C	Upper Magazine Roller Holder Block Left (Mass.)	
* Parts Not Sold Separately		

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
B-297-E	Film Trap Bushing
B-314-G	Shutter Gear Bracket
B-316-D	Pilot Lamp Cable Bushing
B-323-BB	Star Wheel Shaft Inner Bearing
B-332-D	Shutter Blade (2)
B-341-D	Shutter Adjustable Blade
B-357-G	Back Shutter Bracket
B-437-D	Shutter Adjusting Blade for DD-67
B-438-D	Front Shutter Main Blade for DD-67
B-440-D	Front Shutter Guard Bracket
B-465-D	Rear Shutter Blade for DD-67
B-466-D	Back Shutter Bracket Ball Bearing
B-481-D	Spot Sight Box
B-482-BB	Star Wheel Shaft Outer Bearing
B-484-BB	Cam Shaft Bearing
B-485-D	Pilot Lamp Box
B-486-D	Pilot Lamp Bushing
BB-27	FLYWHEEL SHAFT AND GEAR
G-187-BB	Flywheel Shaft Gear
S-726-BB	Flywheel Shaft
BB-28	FLYWHEEL AND GEAR
G-185-BB	Flywheel Gear
W-191-BB	Flywheel
BB-30	FLYWHEEL LOCK NUT COMPLETE
K-130-BB	Flywheel Lock Key
N-171-BB	Flywheel Lock Nut *
S-725-BB	Flywheel Lock Nut Screw
BB-31	OUTER STAR WHEEL SHAFT BEARING OIL CUP
B-250-BB	Outer Bearing Oil Cup Ball
C-296-BB	Outer Bearing Oil Cup
S-734-BB	Outer Bearing Oil Cup Spring

* Parts Not Sold Separately

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
BB-34	INTERMITTENT CASE COVER AND ARM ASSEMBLED
A-192-BB	Case Cover and Bearing Arm
B-323-BB	Star Wheel Shaft Inner Bearing
B-482-BB	Star Wheel Shaft Outer Bearing
BB-31	Outer Star Wheel Shaft Bearing Oil Cup
BB-42	Intermittent Sprocket (Hardened)
C-295-BB	Star Wheel Shaft Collar
G-225-BB	Oil Sight Cork Gasket (2)
G-226-BB	Oil Sight (2)
N-204-BB	Oil Sight Nut (2)
P-350-BB	Intermittent Sprocket Pin (2)
P-353-BB	Case Retaining Clamp Pivot Pin (2)
S-177-BB	Star Wheel Shaft Collar Set Screw (2)
S-432-E	Intermittent Sprocket Stripper Screw (2)
S-724-BB	Star Wheel Shaft Bearing Screw (6)
S-731-BB	Intermittent Sprocket Stripper
S-951-BB	Star Wheel and Shaft
BB-38	INTERMITTENT CAM COMPLETE
BB-39	Cam Shaft Lock Nut
C-301-BB	Intermittent Cam *
G-186-BB	Intermittent Cam Gear
P-673-BB	Intermittent Cam Pin
BB-39	CAM SHAFT LOCK NUT
N-206-BB	Cam Shaft Lock Nut *
N-207-BB	Cam Shaft Nut *
S-1024-BB	Cam Shaft Lock Nut Screw (2)
BB-42	INTERMITTENT SPROCKET AND PINS
P-350-BB	Intermittent Sprocket Pin (2)
R-281-BB	Intermittent Sprocket Ring (2) *
S-1201-BB	Intermittent Sprocket *
BBB	INTERMITTENT MOVEMENT COMPLETE
BP-128	Pilot Lamp Wire Clamp
BP-244	Pilot Light Cable Wire Safety Bushing
C-9	GOVERNOR LIFT LEVER LINK
L-110-C	Governor Lift Lever Link
L-111-C	Governor Lift Lever Connecting Link
S-101-C	Governor Lift Lever Connecting Link Pivot Screw
C-12	LOWER PAD ROLLER STUD AND KNOB
K-127-C	Lower Pad Roller Stud Knob
S-676-C	Lower Pad Roller Stud
* Parts Not Sold Separately	

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
C-15	UPPER MAGAZINE ROLLER HOLDER (MASS. REQUIREMENTS)
B-260-C	Upper Magazine Roller Holder Block, Right
B-296-C	Upper Magazine Roller Holder Block, Left
P-374-C	Upper Magazine Roller Holder Front Plate, Right
P-426-C	Upper Magazine Roller Holder Front Plate, Left
P-427-C	Upper Magazine Roller Holder Back plate
R-227-C	Upper Magazine Roller (4)
S-192-D	Side Plate Fastening Screw (Short) (2)
S-776-D	Side Plate Fastening Screw (Long) (10)
C-16	UPPER PAD ROLLER STUD AND KNOB
K-144-C	Upper Pad Roller Stud Knob
S-941-C	Upper Pad Roller Stud
C-17	UPPER MAGAZINE ROLLER HOLDER
H-206-C	Upper Magazine Roller Holder
R-160-C	Small Magazine Roller (2)
R-161-C	Large Magazine Roller
S-485-C	Magazine Roller Screw (6)
C-20	UPPER PAD ROLLER ARM COMPLETE
A-168-C	Upper Pad Roller Arm
C-16	Upper Pad Roller Stud and Knob
N-166-C	Upper Pad Roller Arm Nut
P-102-C	Pad Roller
P-417-C	Upper Pad Roller Arm Plunger
S-248-A	Upper Pad Roller Stud Screw
S-706-C	Upper Pad Roller Arm Screw
S-852-C	Upper Pad Roller Arm Spring
S-869-C	Upper Pad Roller Arm Plunger Retain Screw
C-21	LOWER PAD ROLLER ARM COMPLETE
A-137-C	Lower Pad Roller Arm
C-12	Lower Pad Roller Stud and Knob (2)
N-166-C	Lower Pad Roller Arm Nut
P-102-C	Pad Roller (2)
S-248-A	Pad Roller Stud Screw (2)
S-706-C	Pad Roller Arm Screw
C-25	FILM TRAP DOOR TRIP LEVER
L-161-C	Film Trap Door Trip Lever
S-866-C	Film Trap Door Trip Lever Spring
S-873-C	Trip Lever Spring Fastening Screw (2)
C-26	LENS SLIDE ASSEMBLY
F-156-C	Lens Slide Flange
P-405-C	Lens Slide Guide Pin (3)
P-415-C	Lens Slide Plate
S-854-C	Lens Slide Spring (3)
S-958-C	Lens Slide Guide Pin Screw (3)
S-1013-C	Lens Slide

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
C-43	LENS CARRIER ASSEMBLY
C-44	Lens Carrier Adjusting Screw
C-45	Lens Clamp Screw and Knob (2)
C-415-C	Back Lens Carrier
C-416-C	Front Lens Carrier
K-136-C	Lens Carrier Adjusting Knob
LA-501	Screw (3)
N-192-C	Lens Carrier Friction Stud Nut (2)
N-194-C	Adjustable Flange Lock Nut (2)
P-404-C	Lens Carrier Pivot
P-418-A	Lens Carrier Support Dowel Pin (2)
R-247-C	Lens Carrier Tie Rod
R-279-C	Lens Carrier Upper Guide Rod
S-860-C	Lens Carrier Set Screw (5)
S-861-C	Lens Carrier Support Friction Stud
S-885-A	Lens Carrier Knob Fastening Screw
S-1169-C	Lens Carrier Support
S-1438-C	Lens Slide Flange Spacer
T-176-C	Lens Carrier Stop Tube
C-44	LENS CARRIER ADJUSTING SCREW
C-343-C	Lens Carrier Adjusting Stop Collar
P-107-G	Stop Collar Taper Pin
S-1166-C	Lens Carrier Adjusting Screw
C-45	LENS CLAMP SCREW AND KNOB (2)
K-140-C	Lens Clamp Screw Knob (2)
P-430-A	Lens Clamp Screw Knob Taper Pin (2)
S-1170-C	Lens Clamp Screw (2)
C-59	LOWER PAD ROLLER ARM STUD
S-1391-C	Lower Pad Roller Arm Stud Screw
S-1392-C	Lower Pad Roller Arm Stud
C-126-A	Main Drive Gear Clutch
C-127-E	Intermittent Film Guide Distance Collar (4)
C-129-E	Lateral Guide Roller Shaft Collar
C-193-G	Spiral Driving Gear Shaft Set Collar (2)
C-294-BB	Case Retaining Clamp (2)
C-295-BB	Star Wheel Shaft Collar
C-296-BB	Outer Bearing Oil Cup
C-339-D	Right Rear Cover
C-340-D	Front Cover
C-341-D	Right Cover
C-342-D	Left Back Cover
C-343-C	Lens Carrier Adjusting Stop Collar
C-344-G	Shutter Shaft Clamp Collar
C-345-G	Shutter Shaft Collar
C-346-D	Right Rear Cover Collar

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
C-347-D	Film Gate Opening Rod Collar
C-354-A	Handle Clutch Collar
C-355-A	Shutter Adjusting Rod Collar
C-360-G	Oil Tube Fastening Clip
C-365-D	Right Door Glass Clamp (4)
C-366-D	Pilot Lamp Cable Clamp (Plated)
C-368-D	Pilot Lamp Cable Clamp (Galvanized)
C-375-BB	Intermittent Case
C-378-G	Intermediate Shaft Retaining Collar
C-381-G	Framing Slide Lever Spacing Collar
C-383-D	Oil Tube Clamp
C-402-D	Shutter Guard Support Frame Oil Tube Clamp
C-415-C	Back Lens Carrier
C-416-C	Front Lens Carrier
C-417-D	Rear Shutter Guard Light Cap
C-418-D	Rear Shutter Guard Light Cap Ball Catch (2)
C-467-E	Lock Pawl Pivot Clamp
C-472-C	Back Lens Carrier
C-479-E	Glass Retaining Clip
C-483-BB	Cam Shaft Bearing Clamp
C-495-D	Pilot Lamp Box Cover
CW-1	11/32" O.D. x 1/4" I.D. Flexible Conduit
D-2	GOVERNOR LIFT LEVER ASSEMBLY
L-105-D	Governor Lift Lever
S-493-D	Governor Lift Lever Screw
D-3	GOVERNOR WEIGHTS AND LINKS
L-112-D	Governor Weight Link (2)
S-100-E	Governor Weight Link Screw (2)
W-126-D	Governor Weight (2) *
D-56	OPERATING SIDE DOOR HINGE
P-411-D	Door Hinge Plate (2) *
P-457-D	Door Hinge Pin (Large) *
D-57	UPPER NON-OPERATING SIDE DOOR HINGE
P-411-D	Door Hinge Plate *
P-412-D	Door Hinge Plate *
P-457-D	Door Hinge Pin (Large) *
D-58	LOWER NON-OPERATING SIDE DOOR HINGE (OLD STYLE)
P-413-D	Door Hinge Plate (2) *
P-458-D	Door Hinge Pin (Small) *
* Parts Not Sold Separately	

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
D-59	RIGHT DOOR LOCK SPRING AND BUTTON	
B-301-D	Right Door Lock Button	*
S-865-D	Right Door Lock Spring	*
D-64	SPOT SIGHT BOX ASSEMBLY	
D-67	Spot Sight Box Only	
G-220-D	Spot Sight Glass	
L-186-E	Shutter Lift Lever	
P-462-D	Cooling Plate	
S-101-C	Spot Sight Glass Retaining Screw	
S-151-C	Governor Link Holder Screw	
S-248-A	Cooling Plate Fastening Screw	(3)
S-961-D	Light Seal	
S-962-D	Spot Sight Glass Tension Spring	
S-987-D	Light Seal Fastening Screw	(4)
S-1030-D	Pilot Light Shield	
D-67	SPOT SIGHT BOX ONLY	
B-481-D	Box (Regular and Super)	
S-278-A	Upper Rear Friction Spring Screw	
S-1401-D	Shutter Lift Lever Support (Super)	
D-68	SHUTTER GUARD BRACKET COMPLETE	
B-288-D	Door Opening Stop Bushing	
C-347-D	Film Gate Opening Rod Collar	
C-402-D	Shutter Guard Support Frame Oil Tube Clamp	
D-138-D	Framing Gear Friction Disc	
F-168-D	Framing Gear Flange	
F-172-D	Shutter Guard Support Frame	
G-25	Lock Nut and Screw	
G-204-D	Framing Gear	
K-137-D	Framing Gear Handle Knob	(2)
L-162-D	Film Trap Door Opening Lever	
L-177-D	Film Gate Lever	
R-240-D	Framing Gear Friction Ring	
R-255-D	Cover Holding Support Rod	(3)
R-257-D	Framing Gear Handle Rod	
R-264-D	Film Gate Opening Rod	
S-863-A	Framing Gear Friction Disc Retaining Screw	(2)
S-884-D	Door Opening Lever Stop Screw	
S-886-D	Door Opening Stop Screw	
S-893-D	Framing Gear Fastening Screw	
S-897-C	Framing Gear Friction Ring Screw	
S-902-D	Shutter Guard Rod Fastening Screw	(3)
S-978-D	Friction Device Spring	
S-987-D	Oil Tube Clamp Fastening Screw	
T-170-D	Support Frame Oil Tube	
W-223-D	Friction Device Washer	(2)
* Parts Not Sold Separately		

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
D-69	RIGHT REAR COVER COMPLETE (DRUM)	
C-339-D	Right Rear Cover	
C-346-D	Right Rear Cover Collar	
G-206-D	Shutter Adjusting Gear (Small)	
K-139-D	Shutter Knob	
R-162-D	Right Rear Cover Stripper Roller	
R-245-D	Shutter Adjusting Rod	
S-185-D	Operating Side Door Lock Stop Screw	
S-771-D	Stripper Roller Screw	(2)
S-885-A	Shutter Adjusting Gear Screw	(3)
D-70	TOP PLATE ASSEMBLY	
L-163-D	Upper Non-Operating Side Door Stop Link	
P-408-D	Top Plate	
P-437-D	Upper Sprocket Shaft Oil Tube Fastening Plate	
P-438-D	Upper Sprocket Shaft Oil Tube Packing	
S-106-D	Stereo Slide Stop Screw	
S-181-D	Upper Non-Operating Side Door Stop Link Screw	
S-931-D	Oil Tube Fastening Plate Screw	(2)
D-71	OPERATING SIDE DOOR	
C-365-D	Operating Side Door Glass Clamp	(4)
D-56	Operating Side Door Hinge	
D-135-D	Operating Side Door	
G-207-D	Operating Side Door Glass	
K-132-D	Operating Side Door Knob	
S-192-D	Operating Side Door Glass Clamp Screw	(4)
S-248-A	Operating Side Door Knob Fastening Screw	(2)
S-893-D	Operating Side Door Hinge Fastening Screw	(4)
D-72	UPPER NON-OPERATING SIDE DOOR	
D-57	Upper Non-Operating Side Door Hinge	
D-140-D	Upper Non-Operating Side Door	
K-106-D	Upper Non-Operating Side Door Knob	
P-144-D	Door Lock Pin	
P-153-B	Door Lock Plunger Pin	
S-178-D	Door Knob Screw	(2)
S-338-D	Door Lock Pin Spring	
S-893-D	Door Hinge Fastening Screw	(4)
D-74	SHUTTER GUARD (FRONT)	
DD-4	Spot Sight Box Mount Assembly	
G-219-D	Shutter Guard (Front)	
P-562-D	Shutter Guard Holding Support Plate	(3)
S-885-A	Support Plate Fastening Screw	(6)
S-966-D	Shutter Guard Holding Support	(3)

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
D-75	SHUTTER GUARD (REAR)	
G-218-D	Shutter Guard (Rear)	
P-562-D	Shutter Guard Holding Support Plate	(3)
S-885-A	Support Plate Fastening Screw	(6)
S-966-D	Shutter Guard Holding Support	(3)
D-76	SHUTTER GUARD (FRONT) STEREO	
DD-4	Spot Sight Box Mount Assembly	
G-217-D	Shutter Guard (Front) Stereo	
P-562-D	Holding Support Plate (3)	
S-885-A	Holding Support Plate Fastening Screw	(6)
S-966-D	Shutter Guard Holding Support	(3)
D-77	SHUTTER GUARD (REAR) STEREO	
G-216-D	Shutter Guard (Rear) Stereo	
P-562-D	Shutter Guard Holding Support Plate	(3)
S-885-A	Holding Support Plate Fastening Screw	(6)
S-966-D	Shutter Guard Holding Support	(3)
D-89	TWO WING ADJUSTABLE SHUTTER	
B-332-D	Shutter Blade	(2)
B-341-D	Shutter Adjustable Blade	
S-106-D	Shutter Blade Screw	(6)
S-192-D	Shutter Fastening Screw	(2)
S-1045-D	Shutter	
W-231-D	Shutter Blade Screw Washer	(6)
D-95	SHUTTER SPIDER	X
S-1016-D	Shutter Spider	
S-1026-D	Shutter Spider Clamp Screw	(2)
D-99	TWO WING ADJUSTABLE SHUTTER AND SPIDER	
D-89	Two Wing Adjustable Shutter	
D-95	Shutter Spider	
S-192-D	Shutter Fastening Screw	(5)
D-130-BB	Oil Deflector	
D-135-D	Operating Side Door	
D-138-D	Framing Gear Friction Disc	
D-139-D	Lower Left Door	
D-140-D	Upper Non-Operating Side Door	
D-145-E	Film Trap Door	
D-148-E	Removable Door	
DD-5	BACK SHUTTER GREASE TUBE AND CUP	
C-331-D	Back Shutter Grease Cup	*
T-174-D	Back Shutter Grease Tube	*
* Parts Not Sold Separately		

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
DD-6	BACK SHUTTER BRACKET SELF ALIGNING BALL BEARING
B-466-D	Back Shutter Bracket Ball Bearing
G-28	Shutter Shaft Clamp
H-251-D	Back Shutter Bracket Ball Bearing Housing
S-1130-D	Shutter Guard Support Frame Fastening Screw (2)
S-1131-D	Back Shutter Bracket Ball Bearing Housing Fastening Screw (2)
W-208-G	Thrust Washer
DD-23	REAR SHUTTER GUARD LIGHT CAP
C-417-D	Rear Shutter Guard Light Cap
C-418-D	Rear Shutter Guard Light Cap Ball Catch (2)
DD-58	REAR SHUTTER GUARD LIGHT CAP
DD-59	FRONT SHUTTER UPPER MOUNTING PLATE AND STUD
P-679-D	Front Shutter Upper Mounting Plate
S-1399-D	Front Shutter Guard Stud (2)
DD-60	FRONT SHUTTER LOWER MOUNTING PLATE AND STUD
P-680-D	Front Shutter Lower Mounting Plate
S-1399-D	Front Shutter Guard Stud (2)
DD-61	SHUTTER SPIDER AND CLAMP SCREW
S-1026-D	Shutter Spider Clamp Screw (2)
S-1453-D	Shutter Spider
DD-62	REAR SHUTTER (FOR DD-67)
B-332-D	Shutter Fan Blade (2)
B-437-D	Shutter Adjusting Blade
B-465-D	Rear Shutter Blade
RP-16	Nut (2)
RP-17	Screw (2)
S-132-E	Screw (6)
W-231-D	Washer (12)
DD-63	FRONT SHUTTER (FOR DD-67)
B-437-D	Front Shutter Adjusting Blade
B-438-D	Front Shutter Main Blade
DD-61	Shutter Spider and Clamp Screws
RP-16	Nut (2)
RP-17	Screw (2)
S-192-D	Screw (5)

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
DD-67	DOUBLE SHUTTER ATTACHMENT	
B-440-D	Front Shutter Guard Bracket	(6)
C-479-E	Fire Shield Hood Glass Retaining Clip	(3)
D-168-W	Decalcomania	*
DD-58	Rear Shutter Guard Light Cap	
DD-59	Front Shutter Upper Mounting Plate and Stud	
DD-60	Front Shutter Lower Mounting Plate and Stud	
DD-62	Rear Shutter	
DD-63	Front Shutter	
DD-70	Accessory Kit	
G-288-D	Front Shutter Guard (Front)	
G-289-D	Front Shutter Guard (Rear)	
G-292-E	Fire Shield Hood Glass	
H-246-E	Fire Shield Hood Glass Holder	
N-245-D	Front Shutter Guard Stud Nut	(4)
P-562-D	Shutter Guard Holding Support Plate	(6)
P-660-D	Front Shutter Guard Strap Plate	(2)
P-663-E	Fire Shield Hood Plate	
R-299-D	Front Shutter Guard Support Rod	(3)
R-303-E	Fire Shield Hood Glass Holder Retainer	
RP-22	Screw	(4)
RP-98	Screw	(4)
RP-132	Screw	(3)
S-132-E	Screw	(3)
S-257-G	Screw	(4)
S-885-A	Screw	(15)
S-989-G	Lock Nut Set Screw	(6)
S-1400-D	Front Shutter Guard Support	
S-1422-D	Front Shutter Guard Strip	
S-1430-E	Fire Shield Hood Slide Pressure Spring	(2)
S-1441-D	Front Shutter Guard Strap Screw	(2)
S-1454-D	Front Shutter Mounting Plate Fastening Screw	(2)
W-298-D	Front Shutter Guard Stud Washer	(4)
DD-70	ACCESSORY KIT FOR DD-67	
H-242-R	Shutter Aligning Rod Holder	
I-114-R	Movement Indicator	
K-168-C	Lens Carrier Adjusting Knob	
R-301-R	Shutter Aligning Rod	
S-1404-R	Aligning Rod Holding Screw	
S-1491-C	Lens Carrier Adjusting Knob Screw	
W-317-D	Washer	(4)
WD-162	Instruction Sheet	

* Parts Not Sold Separately

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
DD-73	PILOT LAMP ASSEMBLY
B-316-D	Pilot Lamp Cable Bushing
B-485-D	Pilot Lamp Box
B-486-D	Pilot Lamp Bushing
BP-244	Pilot Lamp Cable Wire Safety Bushing
C-366-D	Pilot Lamp Cable Clamp (Plated)
C-368-D	Pilot Lamp Cable Clamp (Galvanized)
C-495-D	Pilot Lamp Box Cover
CW-1	11/32" O.D. x 1/4" I.D. Flexible Conduit (4 feet)
EW-187	#18 Rockbestos Type A.F. Asbestos Fixture Wire (4 feet 7 inches)
N-197-D	Pilot Lamp Cable Clamp Nut (Steel)
N-259-D	Pilot Lamp Nut
N-260-D	Nut
S-973-D	Pilot Lamp Cable Clamp Fastening Screw
S-1069-D	Pilot Lamp Cable Clamp Screw
S-1372-D	Heat Plate Fastening Screw
S-1502-D	Pilot Lamp Switch
S-1503-D	Pilot Lamp Socket
S-1504-D	Pilot Lamp Shield
S-1505-D	Pilot Lamp Fastening Screw (2)
W-319-D	Pilot Lamp Washer
E-2	FILM TRAP DOOR HOLDER
H-119-E	Film Trap Door Holder *
P-119-E	Film Trap Door Holder Pin (2)
P-545-E	Film Trap Door Holder Stud Retaining Pin
S-367-E	Film Trap Door Holder Stud
W-148-E	Film Trap Door Holder Stud Distance Washer
E-3	INTERMITTENT FILM GUIDE ASSEMBLY
C-127-E	Intermittent Film Guide Distance Collar (4)
G-125-E	Intermittent Film Guide (Inside) (2)
G-126-E	Intermittent Film Guide (Outside) (2)
S-665-E	Intermittent Film Guide Stud (2)
S-1511-E	Intermittent Film Guide Stud Screw (4)
E-15	LATERAL GUIDE ROLLER SHAFT AND WASHER
S-764-E	Lateral Guide Roller Shaft *
W-198-E	Lateral Guide Roller Spring Retain Washer *
E-28	AUTOMATIC FIRE SHUTTER
L-165-E	Automatic Fire Shutter Lift Link *
L-169-E	Automatic Fire Shutter Lift Lever
P-441-E	Automatic Fire Shutter Front Plate *
P-460-E	Automatic Fire Shutter Back Plate *
P-461-E	Automatic Fire Shutter Side Plate *
R-254-E	Automatic Fire Shutter Lift Link Rivet *
* Parts Not Sold Separately	

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
E-30	LATERAL GUIDE ROLLER AND SHAFT ASSEMBLY
C-129-E	Lateral Guide Roller Shaft Collar
E-15	Lateral Guide Roller Shaft and Washer Assembly
R-246-E	Lateral Guide Roller (2)
S-762-E	Lateral Guide Roller Spring
S-763-E	Lateral Guide Roller Shaft Collar Screw
E-36	SUPER SIMPLEX FILM TRAP COMPLETE (SLIP-IN APERTURE TYPE)
E-2	Film Trap Door Holder
E-28	Automatic Fire Shutter
E-30	Lateral Guide Roller and Shaft Assembly
E-48	Film Trap Removable Door and Bracket
E-80	Film Trap (Slip-in Type)
L-169-E	Automatic Fire Shutter Lift Lever
L-171-E	Shutter Lift Lever (Pilot)
P-359-E	Lateral Guide Roller Pivot (2)
P-380-E	Film Trap Door Lock Pawl Pivot
P-445-E	Aperture Plate Sliding Shim
P-544-E	Film Trap Door Lock Plunger
P-672-E	Aperture Plate (Slip-in Type) Square Corners
S-278-A	Lower Pad Roller Arm Spring Fastening Screw (2)
S-327-E	Film Trap Door Holder Spring
S-771-D	Right Rear Cover Stripper Roller Screw
S-898-E	Film Trap Bushing Fastening Screw
S-900-E	Film Trap Shoe Retaining Screw (6)
S-935-E	Automatic Fire Shutter Lift Link Screw
S-959-E	Automatic Fire Shutter Upper Stop Screw
S-960-E	Automatic Fire Shutter Lower Stop Screw
S-1036-E	Film Trap Right Shoe (Slip-in Aperture Type)
S-1037-E	Film Trap Left Shoe (Slip-in Aperture Type)
S-1143-E	Film Trap Door Lock Trigger Support
S-1144-E	Film Trap Door Lock Plunger Spring
S-1145-E	Film Trap Door Lock Fastening Screw
S-1401-D	Shutter Lift Lever Support
T-101-E	Film Trap Door Holder Thimble
T-137-E	Film Trap Door Lock Trigger
E-38	DOUBLE TENSION GATE (SUBSTITUTE FOR E-48)
D-145-E	Film Trap Door
E-3	Intermittent Film Guide Assembly
E-82	Film Trap Door Film Guide Holder
P-100-E	Film Trap Door Pad
P-436-E	Film Trap Door Protector
S-130-E	Film Trap Door Film Guide Holder Fastening Screw (4)
S-132-E	Intermittent Film Guide Retaining Spring Screw
S-192-D	Film Trap Door Protector Fastening Screw (2)
S-326-E	Intermittent Film Guide Retaining Spring
S-328-E	Film Trap Door Pad Spring
S-580-E	Film Trap Door Double Tension Shoe (2)
S-581-E	Film Trap Door Double Tension Shoe Spring

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
E-45	REMOVABLE DOOR LOCATING BRACKET AND STUD
B-368-E	Removable Door Locating Bracket *
CA-180	Removable Door Support Stud Fastening Pin (2) *
S-1158-E	Removable Door Support Stud (2) *
E-48	FILM TRAP REMOVABLE DOOR AND BRACKET
D-148-E	Removable Door
E-3	Intermittent Film Guide Assembly
E-45	Removable Door Locating Bracket and Stud Assembly
E-82	Removable Door Film Guide Holder
K-150-E	Removable Door Clamping Knob (2)
P-100-E	Removable Door Pad
P-553-E	Removable Door Protector
RP-24	Removable Door Protector Fastening Screw (3)
S-130-E	Removable Door Pad Spring Fastening Screw (4)
S-132-E	Intermittent Film Guide Retaining Spring Screw
S-326-E	Intermittent Film Guide Retaining Spring
S-328-E	Removable Door Pad Spring
S-580-E	Removable Door Double Tension Shoe (2)
S-581-E	Removable Door Double Tension Shoe Spring
S-1157-E	Removable Door Support Bracket Screw (long)
S-1159-E	Removable Door Support Bracket Screw (short)
E-51	AUTOMATIC FIRE SHUTTER LIFT LEVER AND BUSHING
B-381-E	Automatic Fire Shutter Lift Lever Bushing (For Pilot Light) *
L-186-E	Automatic Fire Shutter Lift Lever (For Pilot Light) *

* Parts Not Sold Separately

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
E-54	SUPER SIMPLEX FILM TRAP COMPLETE (FIXED APERTURE TYPE)
E-2	Film Trap Door Holder
E-28	Automatic Fire Shutter
E-30	Lateral Guide Roller and Shaft Assembly
E-48	Film Trap Removable Door and Bracket
E-80	Film Trap (Slip-in Type)
L-169-E	Automatic Fire Shutter Lift Lever
P-359-E	Lateral Guide Roller Pivot (2)
P-380-E	Film Trap Door Lock Pawl Pivot
P-544-E	Film Trap Door Lock Plunger
P-671-E	Aperture Plate (Square Corners)
S-192-D	Film Trap Door Protector Fastening Screw (2)
S-278-A	Lower Pad Roller Arm Spring Fastening Screw (2)
S-327-E	Film Trap Door Holder Spring
S-434-E	Aperture Plate Fastening Screw (2)
S-771-D	Right Rear Cover Stripper Roller Screw
S-898-E	Film Trap Door Lock Pawl Pivot Lock Screw
S-900-E	Film Trap Shoe Retaining Screw (6)
S-935-E	Automatic Fire Shutter Lift Link Screw
S-959-E	Automatic Fire Shutter Upper Stop Screw
S-960-E	Automatic Fire Shutter Lower Stop Screw
S-1036-E	Film Trap Right Shoe (Slip-in Aperture Type)
S-1037-E	Film Trap Left Shoe (Slip-in Aperture Type)
S-1143-E	Film Trap Door Lock Trigger Support
S-1144-E	Film Trap Door Lock Plunger Spring
S-1145-E	Film Trap Door Lock Fastening Screw
S-1361-E	Aperture Spacing Plate
S-1401-D	Shutter Lift Lever Support
T-101-E	Film Trap Door Holder Thimble
T-137-E	Film Trap Door Lock Trigger
E-75	AIR DEFLECTOR AND APERTURE COOLING UNIT
C-479-E	Glass Retaining Clip (3)
DD-58	Rear Shutter Light Cap Assembly (Cut out)
G-292-E	Air Deflector Glass
H-246-E	Air Deflector Glass Holder
P-663-E	Air Deflector Plate
R-303-E	Air Deflector Glass Holder Retainer
RP-22	Air Deflector Plate Screw (4)
RP-98	Air Deflector Slide Pressure Spring Screw (4)
RP-132	Screw
S-132-E	Air Deflector Glass Retaining Clip Screw (3)
S-1430-E	Air Deflector Slide Pressure Spring (2)
E-80	FILM TRAP (SLIP-IN TYPE)
B-297-E	Film Trap Bushing
S-898-E	Film Trap Bushing Fastening Screw (2)
T-161-E	Film Trap (Slip-in Type)

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
E-82	FILM GUIDE HOLDER ASSEMBLY	
H-118-E	Removable Door Film Guide Holder	
RP-77	Removable Door Film Guide Holder Stud Nut	(4)
S-1487-E	Removable Door Film Guide Holder Stud	(4) *
EA-116	Exciter Lamp Contact Lug	
EW-187	Rockbestos Fixture Wire	
F-156-C	Lens Slide Flange	
F-162-A	Main Frame	
F-168-D	Framing Gear Flange	
F-172-D	Shutter Guard Support Frame	
G-3	FRAMING SLIDE ARM	
G-7	Framing Slide Arm and Shoe	
P-127-G	Framing Slide Arm and Roller Pin	
R-128-G	Framing Slide Arm Roller	
G-4	FRAMING SLIDE	
B-106-G	Framing Slide Lever Block	
P-128-G	Framing Slide Lever Pin	
S-321-G	Framing Slide	
G-5	BEVEL GEAR AND SHAFT	
C-193-G	Bevel Gear Drive Shaft Collar	
G-115-G	Bevel Gear	
S 436-G	Collar Set Screw	
S-1082-G	Bevel Gear Drive Shaft	
G-7	FRAMING ARM AND SHOE ASSEMBLY	
A-110-G	Framing Slide Arm	*
S 312 G	Framing Slide Arm Shoe	*
G-12	INTERMEDIATE GEAR (FORMICA) AND PLATE	
G-181-G	Intermediate Gear (Formica)	*
P-334-G	Intermediate Gear Plate	*
S-705-G	Intermediate Gear Screw	(3) *
G-24	VERTICAL SHAFT AND DOUBLE BEVEL GEAR	
G-61	Double Bevel Gear with Taper Pin	
P-368-G	Double Bevel Gear Taper Pin	
S-870-G	Vertical Shaft (Taper Pin Type)	
G-25	LOCK NUT AND SCREW	
N-198-G	Friction Device Lock Nut	
S-989-G	Friction Device Lock Nut Set Screw	
* Parts Not Sold Separately		

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
G-27	SHUTTER SHAFT AND GEAR
C-345-G	Shutter Shaft Collar
G-203-G	Shutter Gear
P-107-G	Shutter Shaft Collar Pin
P-182-G	Shutter Gear Pin
S-934-G	Shutter Shaft
G-28	SHUTTER SHAFT CLAMP
C-344-G	Shutter Shaft Clamp Collar
S-257-G	Shutter Shaft Clamp Collar Screw
G-30	SHUTTER GEAR BRACKET WITH STRAIGHT BEVEL GEAR
B-314-G	Shutter Gear Bracket
C-193-G	Spiral Driving Gear Shaft Set Collar (2)
G-4	Framing Slide
G-115-G	Shutter Driving Bevel Gear
G-116-G	Spiral Driving Gear (Broached Hole)
G-248-G	Shutter Spiral Gear (Formica)
R-120-G	Framing Slide Guide Rod
S-141-A	Focusing Slide Set Screw
S-436-G	Spiral Driving Gear Shaft Set Collar Fastening Screw (2)
S-437-G	Shutter Spiral Gear Fastening Screw
S-871-G	Shutter Gear Shaft
S-1082-G	Spiral Driving Gear Shaft
W-105-B	Shutter Driving Bevel Gear Thrust Washer
G-32	SHUTTER GEAR BRACKET OIL TUBE AND FLANGE (FRONT END)
F-165-A	Oil Tube Fastening Flange *
T-147-G	Oil Tube *
G-33	BACK SHUTTER BRACKET OIL TUBE
F-165-A	Oil Tube Fastening Flange *
T-149-A	Oil Tube *
G-34	INTERMEDIATE GEAR SHAFT AND STRAIGHT BEVEL GEAR
C-378-G	Intermediate Shaft Retaining Collar
G-134-G	Intermediate Gear (Steel)
G-135-G	Intermediate Bevel Gear
G-181-G	Intermediate Gear (Formica) *
P-334-G	Intermediate Gear Plate *
S-125-B	Intermediate Shaft Retaining Collar Set Screw
S-145-G	Intermediate Gear Washer Retaining Screw
S-705-G	Intermediate Gear Screw (3)
S-1032-G	Intermediate Shaft
W-140-G	Intermediate Gear Retaining Washer
W-306-G	Intermediate Bevel Gear Washer
* Parts Not Sold Separately	

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
G-35	LOWER SPROCKET SHAFT AND GEAR	
G-111-G	Lower Sprocket Shaft	
S-1031-G	Lower Sprocket Shaft	
W-114-G	Lower Sprocket Shaft Washer	
G-37	BACK SHUTTER BRACKET	
B-357-G	Back Shutter Bracket	
P-466-G	Shutter Guard Support Frame Dowel Pin	(2)
G-39	SHUTTER GEAR BRACKET OIL TUBE	
F-165-A	Oil Tube Fastening Flange	*
T-164-G	Oil Tube	*
G-44	SHUTTER BRACKET OIL TUBE (REAR)	
F-176-G	Oil Tube Fastening Glange	*
T-175-G	Oil Tube	*
G-45	SHUTTER BRACKET REAR OIL TUBE ASSEMBLY	
BP-128	Pilot Lamp Wire Clamp	
G-44	Shutter Bracket Rear Oil Tube	
G-211-G	Oil Tube Gasket	
GA-107	Oil Tube	
S-932-G	Oil Tube Flange Fastening Screw	
G-65	SPIRAL DOUBLE BEVEL GEAR AND SHAFT ASSEMBLY	
G-87	Double Spiral Bevel Gear and Clamp	
S-870-G	Vertical Shaft	
G-73	SPIRAL BEVEL GEAR AND SHAFT	
C-193-G	Drive Shaft Collar	
G-278-G	Spiral Bevel Gear	
S-436-G	Collar Set Screw	
S-1082-G	Spiral Bevel Gear Drive Shaft	
G-74	INTERMEDIATE GEAR, SHAFT AND SPIRAL BEVEL GEAR	
C-378-G	Intermediate Shaft Retaining Collar	
G-12	Intermediate Gear and Plate	
G-134-G	Intermediate Gear (Steel) (Outside)	
G-279-G	Intermediate Spiral Bevel Gear	
S-145-G	Intermediate Gear Washer Retaining Screw	
S-442-G	Intermediate Shaft Collar Set Screw	
S-1032-G	Intermediate Shaft	
W-140-G	Intermediate Gear Retaining Washer	
* Parts Not Sold Separately		

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
G-78	SHUTTER GEAR BRACKET WITH SPIRAL BEVEL GEAR
B-314-G	Shutter Gear Bracket
C-193-G	Spiral Driving Gear Shaft Set Collar (2)
G-4	Framing Slide
G-116-G	Spiral Driving Gear (Broached Hole)
G-248-G	Shutter Spiral Gear (Formica)
G-278-G	Shutter Driving Spiral Bevel Gear
R-120-G	Framing Slide Guide Rod
S-436-G	Spiral Drive Gear Shaft Collar Screw (2)
S-871-G	Shutter Gear Shaft
S-1082-G	Shutter Driving Gear Shaft
S-1248-G	Shutter Spiral Gear Headless Set Screw
W-105-G	Shutter Driving Gear Thrust Washer
W-276-G	Shutter Spiral Gear Washer
G-87	DOUBLE SPIRAL BEVEL GEAR AND CLAMP
C-490-G	Double Spiral Bevel Gear Hub Clamp Collar *
FP-119	Lock Washer (3) *
G-298-G	Vertical Shaft Driving Spiral Bevel Gear *
G-299-G	Vertical Shaft Driven Spiral Bevel Gear *
P-687-G	Double Spiral Bevel Gear Dowel Pin *
S-1048-A	Screw to hold Driving and Driven Gears (3) *
S-1447-G	Clamp Collar Screw (3)
S-1479-G	Double Spiral Bevel Gear Shim .026" *
G-111-G	Lower Sprocket Shaft Gear
G-112-G	Main Drive Gear
G-115-G	Shutter Driving Bevel Gear
G-116-G	Spiral Driving Gear (Broached Hole)
G-125-E	Intermittent Film Guide (Inside) (2)
G-126-E	Intermittent Film Guide (Outside) (2)
G-134-G	Intermediate Gear (Steel)
G-135-G	Intermediate Bevel Gear
G-138-G	Vertical Shaft Top Straight Bevel Gear
G-139-G	Upper Sprocket Shaft Straight Bevel Gear
G-185-BB	Flywheel Gear
G-186-BB	Intermittent Cam Gear
G-187-BB	Flywheel Shaft Gear
G-188-BB	Oil Gasket
G-202-G	Shutter Adjusting Slide Gib
G-204-D	Framing Gear
G-205-A	Shutter Adjusting Gear (Large)
G-206-D	Shutter Adjusting Gear (Small)
G-207-D	Operating Side Door Glass
G-211-G	Oil Tube Gasket (4)
G-215-G	Main Drive Gear (4 Star Sound Type)
G-216-D	Shutter Guard (Rear) (Stereo)
G-217-D	Shutter Guard (Front) (Stereo)

* Parts Not Sold Separately

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
G-218-D	Shutter Guard (Rear)
G-219-D	Shutter Guard (Front)
G-220-D	Spot Sight Glass
G-225-BB	Oil Sight Cork Gasket (2)
G-226-BB	Oil Sight (2)
G-248-G	Shutter Spiral Gear (Formica)
G-278-G	Shutter Driving Spiral Bevel Gear
G-279-G	Intermediate Spiral Bevel Gear
G-282-G	Upper Sprocket Shaft Spiral Bevel Gear
G-283-G	Top Sprocket Shaft Driving Spiral Bevel Gear
G-288-D	Front Shutter Guard (Front, for DD-67)
G-289-D	Front Shutter Guard (Rear, for DD-67)
G-292-E	Air Deflector Glass
GA-107	Oil Cup
H-120-G	Governor Lower Link Holder
H-121-G	Governor Upper Link Holder
H-206-C	Upper Magazine Roller Holder
H-242-R	Shutter Aligning Rod Holder
H-243-D	Fire Shield Hood
H-246-E	Air Deflector Glass Holder
H-251-D	Back Shutter Bracket Ball Bearing Housing
I-114-R	Intermittent Movement Indicator
K-106-D	Upper Non-Operating Side Door Knob
K-127-C	Lower Pad Roller Stud Knob
K-130-BB	Flywheel Lock Key
K-132-D	Right Door Knob
K-136-C	Lens Carrier Adjusting Knob
K-137-D	Framing Gear Handle Knob (2)
K-139-D	Shutter Knob
K-140-C	Lens Clamp Screw Knob (2)
K-141-D	Shutter Cover Holding Rod Knob (3)
K-144-C	Upper Pad Roller Stud Knob
K-145-D	Shutter Shaft Knob
K-150-E	Removable Door Clamping Knob (2)
K-168-C	Lens Carrier Adjusting Knob
L-105-D	Governor Lift Lever
L-110-C	Governor Lift Lever Link
L-111-C	Governor Lift Lever Connecting Link
L-112-D	Governor Weight Links (2)
L-136-G	Framing Slide Lever
L-161-C	Film Trap Door Trip Lever
L-162-D	Film Trap Door Opening Lever
L-163-D	Upper Non-Operating Side Door Stop Link

ORDER BY PART NUMBER

PART NO.	DESCRIPTION	
L-169-E	Automatic Fire Shutter Lift Lever	
L-171-E	Shutter Lift Lever Pilot	
L-177-D	Film Gate Lever	
L-186-E	Shutter Lift Lever	
LA-501	Screw	(3)
N-166-C	Upper Pad Roller Arm Nut	
N-192-C	Lens Carrier Friction Stud Nut	(2)
N-194-C	Adjustable Flange Lock Nut	(2)
N-197-D	Pilot Lamp Cable Clamp Nut (Steel)	
N-198-G	Friction Device Lock Nut	
N-204-BB	Oil Sight Nut	(2)
N-245-D	Front Shutter Guard Stud Nut	(4)
N-259-D	Pilot Lamp Nut	
N-260-D	Nut	
OA-139	Lock Washers for 50 Cycle Bodine	
P-100-E	Film Trap Door Pad	
P-102-C	Pad Roller	
P-107-G	Stop Collar Taper Pin	
P-115-A	Handle Shaft Pin	(2)
P-119-E	Film Trap Door Holder Pin	(2)
P-121-C	Film Trap Locating Pin	
P-127-G	Framing Slide Arm and Roller Pin	
P-128-G	Framing Slide Lever Pin	
P-144-D	Door Lock Pin	
P-153-B	Door Lock Plunger Pin	
P-169-G	Shutter Gear Bracket Dowel Pin	(2)
P-182-G	Shutter Gear Pin	
P-289-C	Roller Arm Stop Pin	(2)
P-350-BB	Intermittent Sprocket Pin	(2)
P-353-BB	Case Retaining Clamp Pivot Pin	(2)
P-359-E	Lateral Guide Roller Pivot	(2)
P-368-G	Double Bevel Gear Taper Pin	
P-374-C	Upper Magazine Roller Holder Front Plate, Right (Mass.)	
P-380-E	Film Trap Door Lock Pawl Pivot	
P-404-C	Lens Carrier Pivot	
P-405-C	Lens Slide Guide Pin	(3)
P-408-D	Top Plate	
P-409-G	Back Shutter Bracket Dowel Pin	(2)
P-410-A	Framing Cam Pin	(2)
P-414-G	Back Shutter Bracket Distance Piece	
P-415-C	Lens Slide Plate	
P-417-C	Upper Pad Roller Arm Plunger	
P-418-A	Lens Carrier Support Dowel Pin	(2)
P-419-G	Shutter Adjusting Slide Spring Pin	

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
P-422-G	Framing Slide Lever Spring Pin
P-426-C	Upper Magazine Roller Holder Front Plate, Left (Mass.)
P-427-C	Upper Magazine Roller Holder Back Plate (Mass.)
P-430-A	Shutter Adjusting Rod Pin
P-436-E	Film Trap Door Protector
P-437-D	Upper Sprocket Shaft Oil Tube Fastening Plate
P-438-D	Upper Sprocket Shaft Oil Tube Packing
P-445-E	Aperture Plate Sliding Shim
P-459-D	Super Simplex Name Plate
P-462-D	Cooling Plate
P-466-G	Shutter Guard Support Frame Dowel Pin (2)
P-543-D	Spot Sight Box Seating Plate
P-544-E	Film Trap Door Lock Plunger
P-545-E	Film Trap Door Holder Stud Retaining Pin
P-553-E	Removable Door Protector
P-554-G	Main Drive Gear Retaining Screw Spring Pawl
P-562-D	Shutter Guard Holding Support Plate (3)
P-649-A	Handle Shaft Plug (2)
P-660-D	Front Shutter Guard Strap Plate (2)
P-663-E	Air Deflector Plate
P-671-E	Aperture Plate (Square Corner) (Stationary Type)
P-672-E	Aperture Plate (Slip-in Type, Square Corners)
P-673-BB	Intermittent Cam Pin
P-677-BB	Intermittent Case Oil Regulating Plug
P-679-D	Front Shutter Upper Mounting Plate
P-680-D	Front Shutter Lower Mounting Plate
P-709-G	Shockproof Intermediate Gear Plate
R-120-G	Framing Slide Guide Rod
R-128-G	Framing Slide Arm Roller
R-133-A	Framing Cam Ring
R-160-C	Small Magazine Roller (2)
R-161-C	Large Magazine Roller
R-162-D	Right Rear Cover Stripper Roller
R-227-C	Upper Magazine Roller (Mass.) (4)
R-240-D	Framing Gear Friction Ring
R-242-A	Shutter Adjusting Rod
R-245-D	Shutter Adjusting Rod
R-246-E	Lateral Guide Roller (2)
R-247-C	Lens Carrier Tie Rod
R-255-D	Cover Holding Support Rod (3)
R-257-D	Framing Gear Handle Rod
R-264-D	Film Gate Opening Rod
R-274-D	Spot Sight Box Guide Rail (2)
R-279-C	Lens Carrier Upper Guide Rod
R-299-D	Front Shutter Guard Support Rod (3)
R-300-C	Lens Carrier Tie Rod
R-301-R	Shutter Aligning Rod
R-303-E	Air Deflector Glass Holder Retainer

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
RP-16	Nut
RP-17	Screw
RP-22	Screw
RP-24	Screw
RP-33	Screw
RP-77	Removable Door Film Guide Holder Stud Nut (4)
RP-98	Screw
RP-99	Nut
RP-132	Screw
RP-190	Washer
S-100-E	Governor Weight Link Screw (2)
S-101-C	Governor Lift Lever Connecting Link Pivot Screw
S-106-D	Stereo Slide Stop Screw
S-115-A	Centre Frame Screw (4)
S-118-L	Condenser Holder Tube Bushing Screw
S-122-C	Cover Screw (6)
S-125-B	Intermediate Shaft Retaining Collar Set Screw
S-130-E	Film Trap Door Film Guide Holder Fastening Screw (8)
S-132-E	Intermittent Film Guide Retaining Spring Screw
S-139-C	Focusing Rack Stop Screw
S-141-A	Focusing Slide Set Screw
S-143-A	Framing Cam Adjusting Ring Screw
S-145-G	Intermediate Gear Washer Retaining Screw
S-150-C	Governor Lift Lever Pivot Screw
S-151-D	Governor Link Holder Screw (4)
S-165-C	Fastening Screw
S-177-E	Star Wheel Shaft Collar Set Screw (2)
S-178-D	Door Knob Screw (2)
S-180-D	Left Door Lower Lock Screw
S-181-D	Upper Non-Operating Side Door Stop Link Screw
S-185-D	Operating Side Door Lock Stop Screw
S-192-E	Lower Reel Case Cover Knob Screw (2)
S-231-A	Rear Condenser Guide Rod Retaining Screw (3)
S-248-A	Upper Pad Roller Stud Screw
S-257-G	Screw
S-278-A	Upper Rear Friction Spring Screw (2)
S-321-G	Framing Slide
S-326-E	Intermittent Film Guide Retaining Spring
S-327-E	Film Trap Door Holder Spring
S-328-E	Film Trap Door Pad Spring
S-338-D	Door Lock Pin Spring
S-357-G	Governor Weight Stop
S-367-E	Film Trap Door Holder Stud
S-432-E	Intermittent Sprocket Stripper Screw (2)
S-434-E	Aperture Plate Fastening Screw (2)
S-436-G	Spiral Driving Gear Shaft Set Collar Fastening Screw (2)
S-437-G	Shutter Spiral Gear Fastening Screw
S-442-G	Intermediate Shaft Retaining Collar Set Screw
S-485-C	Magazine Roller Screw (6)

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
S-493-D	Governor Lift Lever Screw
S-514-C	Fire Shutter Lifting Stud
S-567-C	Pad Roller Arm Stud
S-569-C	Lower Pad Roller Arm Spring
S-573-C	Upper and Lower Sprocket Stripper Stud
S-580-E	Film Trap Door Double Tension Shoe (2)
S-581-E	Film Trap Door Double Tension Shoe Spring
S-665-E	Intermittent Film Guide Stud (2)
S-676-C	Lower Pad Roller Stud
S-705-G	Intermediate Gear Screw (3)
S-706-C	Upper Pad Roller Arm Screw
S-724-BB	Star Wheel Shaft Bearing Screw (6)
S-725-BB	Flywheel Lock Nut Screw
S-726-BB	Flywheel Shaft
S-728-BB	Case Clamp Screw (2)
S-729-BB	Case Cover Screw (4)
S-731-BB	Intermittent Sprocket Stripper
S-734-BB	Outer Bearing Oil Cup Spring
S-762-E	Lateral Guide Roller Spring
S-763-E	Lateral Guide Roller Shaft Collar Screw
S-765-BB	Oil Deflector Screw (2)
S-771-D	Stripper Roller Screw (2)
S-776-D	Side Plate Fastening Screw (Long) (10)
S-852-C	Upper Pad Roller Arm Spring
S-854-C	Lens Slide Spring (3)
S-856-A	Shutter Adjusting Slide
S-858-G	Shutter Adjusting Slide Spring
S-860-C	Lens Carrier Set Screw (5)
S-861-C	Lens Carrier Support Friction Stud
S-863-A	Friction Disc Retaining Screw (2)
S-866-C	Film Trap Door Trip Lever Spring
S-867-C	Upper Stripper
S-869-C	Upper Pad Roller Arm Plunger Retain Screw
S-870-G	Vertical Shaft
S-871-G	Shutter Gear Shaft
S-872-D	Screw
S-873-C	Trip Lever Spring Fastening Screw (2)
S-874-C	Film Trap Door Trip Lever Screw
S-877-C	Lens Carrier Support Fastening Screw (2)
S-878-D	Magazine Fastening Screw (2)
S-880-A	Screw
S-882-G	Back Bracket Fastening Screw (4)
S-883-D	Screw
S-884-D	Door Opening Lever Stop Screw
S-885-A	Screw
S-886-D	Door Opening Stop Screw
S-893-D	Framing Gear Fastening Screw
S-897-C	Knob Fastening Screw (2)
S-898-E	Film Trap Bushing Fastening Screw
S-899-G	Framing Slide Lever Stud
S-900-E	Film Trap Shoe Retaining Screw (6)

ORDER BY PART NUMBER


PART NO.	DESCRIPTION	
S-902-D	Shutter Guard Rod Fastening Screw	(3)
S-904-D	Light Shield Hood Fastening Screw	(2)
S-905-D	Screw	(3)
S-906-D	Driving Handle Retaining Screw	
S-931-D	Oil Tube Fastening Plate Screw	(2)
S-932-G	Oil Tube Flange Fastening Screw	(2)
S-934-G	Shutter Shaft	
S-935-E	Automatic Fire Shutter Lift Link Screw	
S-941-C	Upper Pad Roller Stud	
S-951-BB	Star Wheel and Shaft	
S-957-D	Lens Carrier Support Spacer	(6)
S-958-C	Lens Slide Guide Pin Screw	(3)
S-959-E	Automatic Fire Shutter Upper Stop Screw	
S-960-E	Automatic Fire Shutter Lower Stop Screw	
S-961-D	Light Seal	
S-962-D	Spot Sight Glass Tension Spring	
S-966-D	Shutter Guard Holding Support	(3)
S-973-D	Pilot Lamp Cable Clamp Fastening Screw	
S-978-D	Friction Device Spring	
S-987-D	Light Seal Fastening Screw	(4)
S-989-G	Friction Device Lock Nut Set Screw	
S-1000-G	Screw	
S-1013-C	Lens Slide	
S-1016-D	Shutter Spider	
S-1024-BB	Cam Shaft Lock Nut Screw	(2)
S-1026-D	Shutter Spider Clamp Screw	(2)
S-1030-D	Pilot Light Shield	
S-1031-G	Lower Sprocket Shaft	
S-1032-G	Intermediate Shaft	
S-1033-G	Top Sprocket Shaft	
S-1036-E	Film Trap Right Shoe (Slip-in Aperture Type)	
S-1037-E	Film Trap Left Shoe (Slip-in Aperture Type)	
S-1042-A	Oil Plug Screw	(2)
S-1045-D	Shutter	
S-1069-D	Pilot Lamp Cable Clamp Screw	
S-1082-G	Spiral Driving Gear Shaft	
S-1130-D	Pilot Light Shield	(2)
S-1131-D	Back Shutter Bracket Ball Bearing Housing Fastening Screw	(2)
S-1134-D	Upper Retaining Strip	
S-1135-D	Lower Retaining Strip	
S-1136-D	Retaining Spring	(3)
S-1137-D	Retaining Spring Screw	(6)
S-1138-D	Spot Sight Box Mount Assembly Screw (Long)	(2)
S-1139-D	Spot Sight Box Stop Screw	(2)
S-1142-E	Film Trap Shoe (Vertical Aperture Type)	(2)
S-1143-E	Film Trap Door Lock Trigger Support	
S-1144-E	Film Trap Door Lock Plunger Spring	
S-1145-E	Film Trap Door Lock Fastening Screw	
S-1146-A	Oil Hole Cap Screw	
S-1153-D	Handle Shaft Oil Shield	

ORDER BY PART NUMBER




PART NO.	DESCRIPTION
S-1157-E	Removable Door Support Bracket Screw (Long)
S-1159-E	Removable Door Support Bracket Screw (Short)
S-1160-G	Main Drive Pulley Retaining Screw
S-1166-C	Lens Carrier Adjusting Screw
S-1169-C	Lens Carrier Support
S-1170-C	Lens Clamp Screw (2)
S-1248-G	Shutter Spiral Gear Headless Set Screw
S-1361-E	Aperture Spacing Plate
S-1372-D	Heat Plate Fastening Screw
S-1391-C	Lower Pad Roller Arm Stud Screw
S-1392-C	Lower Pad Roller Arm Stud
S-1399-D	Front Shutter Guard Stud (4)
S-1400-D	Front Shutter Guard Support
S-1401-D	Shutter Lift Lever Support
S-1404-R	Aligning Rod Holder Screw
S-1422-D	Front Shutter Guard Strap
S-1430-E	Fire Shield Hood Slide Pressure Spring (2)
S-1438-C	Lens Slide Flange Spacer
S-1441-D	Front Shutter Guard Strap Screw (2)
S-1447-G	Clamp Collar Screw (3)
S-1452-C	Lens Carrier Support Friction Screw
S-1453-D	Shutter Spider
S-1454-D	Front Shutter Mounting Plate Fastening Screw (2)
S-1481-D	Name Plate Screw
S-1491-C	Lens Carrier Adjusting Knob Screw
S-1502-D	Pilot Lamp Switch
S-1503-D	Pilot Lamp Socket
S-1504-D	Pilot Lamp Shield
S-1505-D	Pilot Lamp Fastening Screw (2)
S-1511-E	Intermittent Film Guide Stud Screw (4)
T-101-E	Film Trap Door Holder Thimble
T-137-E	Film Trap Door Lock Trigger
T-161-E	Film Trap (Slip-in Type)
T-170-D	Support Frame Oil Tube
T-176-C	Lens Carrier Stop Tube
W-105-B	Shutter Driving Bevel Gear Thrust Washer
W-114-G	Lower Sprocket Shaft Washer
W-124-G	Vertical Shaft Washer
W-125-G	Vertical Shaft Washer #2
W-126-D	Governor Weight (2)
W-140-G	Intermediate Gear Retaining Washer
W-145-D	Upper Feed Sprocket
W-146-D	Lower Takeup Sprocket
W-148-E	Film Trap Door Holder Stud Distance Washer
W-160-C	Washer
W-191-BB	Flywheel
W-208-G	Thrust Washer (2)
W-223-D	Friction Device Washer (2)

ORDER BY PART NUMBER


PART NO.	DESCRIPTION
W-226-A	Octagon "P" Wick 2-1/2"
W-227-BB	Oil Retain Washer (2)
W-231-D	Shutter Blade Screw Washer (8)
W-250-G	Shutter Shaft Friction Washer
W-276-G	Shutter Spiral Gear Washer
W-298-D	Front Shutter Guard Stud Washer (4)
W-306-G	Intermediate Bevel Gear Washer
W-308-C	Focusing Shaft Spring Washer (3)
W-311-C	Friction Screw Lock Washer
W-317-D	Washer
W-319-D	Pilot Lamp Washer



G-92



G-94



G-93

SIMPLEX SHOCKPROOF INTERMEDIATE GEAR

ORDER BY PART NUMBER

PART NO.	DESCRIPTION
G-92	SHOCKPROOF INTERMEDIATE GEAR AND PLATE
G-307-G	Shockproof Intermediate Gear *
P-709-G	Intermediate Gear Plate *
S-705-G	Intermediate Gear Screw (3)*
G-93	SHOCKPROOF INTERMEDIATE GEAR AND SHAFT WITH STRAIGHT BEVEL GEAR
C-378-G	Intermediate Shaft Retain Collar
G-92	Intermediate Gear and Plate
G-134-G	Intermediate Gear (Small) (Outside)
G-135-G	Intermediate Straight Bevel Gear
S-125-G	Intermediate Shaft Collar Screw
S-145-G	Intermediate Gear Washer Retain Screw
S-1032-G	Intermediate Shaft
W-140-G	Intermediate Gear Retain Washer
W-306-G	Intermediate Gear Washer
G-94	SHOCKPROOF INTERMEDIATE GEAR AND SHAFT WITH SPIRAL BEVEL GEAR
C-378-G	Intermediate Shaft Retain Collar
G-92	Intermediate Gear and Plate
G-134-G	Intermediate Gear (Small) (Outside)
G-279-G	Intermediate Spiral Bevel Gear
S-145-G	Intermediate Gear Washer Retaining Screw
S-442-G	Intermediate Shaft Collar Screw
S-1032-G	Intermediate Shaft
W-140-G	Intermediate Gear Retain Washer
W-306-G	Intermediate Gear Washer

* Parts Not Sold Separately

ORDER BY PART NUMBER.

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
A-11	5.60	B-437-D	.85	C-21	3.15
A-16	.30	B-438-D	.85	C-25	1.60
A-17	.80	B-440-D	.25	C-26	4.65
A-18	.45	B-465-D	.75	C-43	20.60
A-19	.35	B-466-D	1.55	C-44	1.65
A-20	.35	B-481-D	1.90	C-45	1.30
A-21	.30	B-482-BB	.95	C-59	2.00
A-27	5.90	B-484-BB	2.55	C-126-A	.60
A-137-C	1.20	B-485-D	.70	C-127-E	.05
A-168-C	1.20	B-486-D	.05	C-129-E	.15
A-192-BB	6.10	BB-27	1.95	C-193-G	.30
A-215-C	1.10	BB-28	3.80	C-294-BB	.05
B-106-G	.10	BB-30	2.70	C-295-BB	.30
B-246-BB	1.90	BB-31	.05	C-296-BB	.05
B-250-BB	.05	BB-34	19.70	C-339-D	1.60
B-260-C	1.45	BB-38	5.25	C-340-D	5.35
B-288-D	.05	BB-39	.70	C-341-D	.55
B-293-A	5.75	BB-42	4.90	C-342-D	2.65
B-296-C	1.15	BP-128	.10	C-343-C	.30
B-297-E	2.00	BP-244	.05	C-344-G	.20
B-314-G	4.65	C-9	.75	C-345-G	.25
B-316-D	.05	C-12	.35	C-346-D	.35
B-323-BB	1.25	C-15	11.05	C-347-D	.35
B-332-D	.15	C-16	.45	C-354-A	.65
B-341-D	.45	C-17	4.20	C-355-A	.20
B-357-G	6.90	C-20	3.65	C-360-G	.25

ORDER BY PART NUMBER

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
C-365-D	.05	D-68	16.50	DD-61	2.15
C-366-D	.10	D-69	4.55	DD-62	3.00
C-368-D	.05	D-70	3.00	DD-63	1.95
C-375-BB	8.60	D-71	4.65	DD-70	7.65
C-378-G	.45	D-72	3.85	DD-73	4.15
C-381-G	.25	D-74	6.15	E-2	4.30
C-383-D	.10	D-75	2.90	E-3	1.55
C-402-D	.05	D-76	5.65	E-15	.35
C-415-C	3.40	D-77	3.50	E-28	.75
C-416-C	3.00	D-89	2.20	E-30	2.05
C-417-D	.65	D-95	2.45	E-36	41.35
C-418-D	.05	D-99	5.05	E-38	8.20
C-467-E	.10	D-130-BB	.25	E-45	3.10
C-472-C	3.20	D-135-D	2.65	E-48	11.30
C-479-E	.05	D-138-D	.20	E-51	.75
C-483-BB	.35	D-139-D	2.00	E-54	41.80
C-495-D	.10	D-140-D	1.90	E-75	9.50
CW-1	.05	D-145-E	1.85	E-80	10.45
D-2	.90	D-147-A	.05	E-82	.90
D-3	1.05	D-148-E	1.95	EA-116	.05
D-56	.35	DD-5	.40	EW-187	.05
D-57	.35	DD-6	6.25	F-156-C	.90
D-58	.75	DD-23	.70	F-162-A	65.00
D-59	.40	DD-58	1.00	F-168-D	1.45
D-64	3.95	DD-59	1.55	F-172-D	5.10
D-67	2.30	DD-60	1.40	G-3	1.40

ORDER BY PART NUMBER

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
G-4	2.75	G-112-G	4.00	G-226-BB	.05
G-5	3.15	G-115-G	1.85	G-248-G	1.70
G-7	1.25	G-116-G	1.00	G-278-G	1.75
G-12	2.20	G-125-E	.15	G-279-G	4.35
G-24	4.90	G-126-E	.20	G-282-G	1.75
G-25	.85	G-134-G	.90	G-283-G	1.10
G-27	3.45	G-135-G	3.60	G-288-D	1.90
G-28	.60	G-138-G	1.00	G-289-D	2.00
G-30	15.65	G-139-G	1.85	G-292-E	.90
G-32	.35	G-185-BB	1.50	GA-107	.05
G-33	.35	G-186-BB	.75	H-120-G	1.05
G-34	10.40	G-187-BB	.85	H-121-G	1.00
G-35	2.45	G-188-BB	.05	H-206-C	1.90
G-37	7.30	G-202-G	.25	H-242-R	5.05
G-39	.50	G-204-D	.95	H-243-R	1.90
G-44	.45	G-205-A	1.55	H-246-E	.80
G-45	.65	G-206-D	1.10	H-251-D	1.10
G-65	7.25	G-207-D	.60	I-114-R	.10
G-73	4.00	G-211-G	.05	K-106-D	.60
G-74	10.40	G-215-G	4.00	K-127-C	.10
G-78	15.65	G-216-D	2.30	K-130-BB	.30
G-87	5.85	G-217-D	2.20	K-132-D	.35
G-92	5.00	G-218-D	2.05	K-136-C	.15
G-93	13.20	G-219-D	1.85	K-137-D	.25
G-94	13.20	G-220-D	.10	K-139-D	.15
G-111-G	.90	G-225-BB	.05	K-140-C	.50

ORDER BY PART NUMBER

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
K-141-D	.25	N-260-D	.05	P-141-G	.65
K-144-C	.15	OA-139	.05	P-415-C	.15
K-145-D	1.05	P-100-E	.75	P-417-C	.10
K-150-E	.20	P-102-C	.85	P-418-A	.05
K-168-C	.45	P-107-G	.05	P-419-G	.10
L-105-D	.85	P-115-A	.10	P-422-G	.10
L-110-C	.05	P-119-E	.05	P-426-C	.75
L-111-C	.35	P-121-C	.05	P-427-C	.25
L-112-D	.05	P-127-G	.05	P-430-A	.05
L-136-G	1.85	P-128-G	.05	P-436-E	1.20
L-161-C	1.50	P-144-D	.15	P-437-D	.10
L-162-D	.30	P-153-B	.05	P-438-D	.05
L-163-D	.15	P-169-G	.05	P-445-E	.25
L-169-E	.15	P-182-G	.05	P-459-D	.15
L-171-E	.25	P-289-C	.05	P-462-D	.45
L-177-D	1.00	P-350-BB	.05	P-466-G	.05
L-186-E	.15	P-353-BB	.05	P-543-D	.90
LA-501	.05	P-359-E	.05	P-544-E	.15
N-166-C	.05	P-368-G	.05	P-545-E	.05
N-192-C	.30	P-374-C	.70	P-553-E	1.20
N-194-C	.05	P-380-E	.10	P-554-G	.15
N-197-D	.05	P-404-C	.80	P-562-D	.05
N-198-G	.20	P-405-C	.35	P-649-A	.05
N-204-BB	.15	P-408-D	2.25	P-660-D	.10
N-245-D	.05	P-409-G	.05	P-663-E	.95
N-259-D	.05	P-410-A	.05	P-671-E	.45

ORDER BY PART NUMBER

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
P-672-E	.35	R-303-E	1.00	S-165-C	.05
P-673-BB	.45	RP-16	.05	S-177-E	.05
P-677-BB	.10	RP-17	.05	S-178-D	.05
P-679-D	1.05	RP-22	.05	S-180-D	.15
P-680-D	1.00	RP-24	.05	S-181-D	.05
P-709-G	.60	RP-33	.05	S-185-D	.05
R-120-G	.10	RP-77	.05	S-192-E	.05
R-128-G	.05	RP-98	.05	S-231-A	.05
R-133-A	2.30	RP-99	.05	S-248-A	.05
R-160-C	.60	RP-132	.05	S-257-G	.05
R-161-C	.60	RP-190	.05	S-278-A	.05
R-162-D	.25	S-100-E	.05	S-321-G	2.55
R-227-C	.75	S-101-C	.05	S-326-E	.05
R-240-D	.80	S-106-D	.05	S-327-E	.05
R-242-A	.20	S-115-A	.05	S-328-E	.05
R-245-D	.65	S-118-L	.05	S-338-D	.05
R-246-E	.80	S-122-C	.05	S-357-G	.20
R-247-C	.40	S-125-B	.05	S-367-E	.55
R-255-D	.50	S-130-E	.05	S-432-E	.05
R-257-D	1.40	S-132-E	.05	S-434-E	.05
R-264-D	.90	S-139-C	.05	S-436-G	.05
R-274-D	.30	S-141-A	.05	S-437-G	.05
R-279-C	.30	S-143-A	.05	S-422-G	.05
R-299-D	.50	S-145-G	.05	S-485-C	.05
R-300-C	.45	S-150-C	.05	S-493-D	.05
R-301-R	1.50	S-151-D	.05	S-514-C	.20

ORDER BY PART NUMBER

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
S-567-C	.40	S-861-C	.10	S-906-D	.15
S-569-A	.05	S-863-A	.05	S-931-D	.05
S-573-C	.35	S-866-C	.05	S-932-G	.05
S-580-E	.20	S-867-C	.15	S-934-G	1.95
S-581-E	.05	S-869-C	.05	S-935-E	.05
S-665-E	.20	S-870-G	.40	S-941-C	.15
S-676-C	.10	S-871-G	1.40	S-951-BB	7.55
S-705-G	.05	S-872-D	.05	S-957-D	.10
S-706-C	.15	S-873-C	.05	S-958-C	.05
S-724-BB	.05	S-874-C	.15	S-959-E	.05
S-725-BB	.05	S-877-C	.05	S-960-E	.05
S-726-BB	.95	S-878-D	.30	S-961-D	.10
S-728-BB	.05	S-880-A	.20	S-962-D	.05
S-729-BB	.05	S-882-G	.10	S-966-D	.15
S-731-BB	.30	S-883-D	.05	S-973-D	.05
S-734-BB	.05	S-884-D	.05	S-978-D	.10
S-762-E	.05	S-885-A	.05	S-987-D	.05
S-763-E	.05	S-886-D	.10	S-989-G	.05
S-765-BB	.05	S-893-D	.05	S-1000-G	.05
S-771-D	.05	S-897-C	.10	S-1013-C	1.15
S-776-D	.10	S-898-E	.05	S-1016-D	.70
S-852-C	.05	S-899-G	.20	S-1024-BB	.05
S-854-C	.05	S-900-E	.05	S-1026-D	.05
S-856-A	.85	S-902-D	.05	S-1030-D	.10
S-858-G	.05	S-904-D	.05	S-1031-G	1.50
S-860-C	.10	S-905-D	.05	S-1032-G	1.85

ORDER BY PART NUMBER

PART NO.	PRICE	PART NO.	PRICE	PART NO.	PRICE
S-1033-G	.95	S-1248-G	.05	T-170-D	.15
S-1036-E	1.95	S-1361-E	.25	T-176-C	.10
S-1037-E	1.95	S-1372-D	.05	W-105-B	.15
S-1042-A	.05	S-1391-C	.15	W-114-G	.05
S-1045-D	1.00	S-1392-C	1.25	W-124-G	.10
S-1069	.05	S-1399-D	.10	W-125-G	.10
S-1082-G	1.90	S-1400-D	2.65	W-126-D	.40
S-1130-D	.10	S-1401-D	.55	W-140-G	.20
S-1131-D	.10	S-1404-R	.15	W-145-D	1.50
S-1134-D	.55	S-1422-D	.10	W-146-D	1.50
S-1135-D	.55	S-1430-E	.05	W-148-E	.20
S-1136-D	.05	S-1438-C	1.15	W-160-C	.05
S-1137-D	.05	S-1441-D	.05	W-191-BB	2.05
S-1138-D	.05	S-1447-G	.05	W-208-G	.05
S-1139-D	.05	S-1452-C	.35	W-223-D	.15
S-1142-E	2.75	S-1453-D	2.10	W-226-A	.05
S-1143-E	.95	S-1454-D	.10	W-227-BB	.05
S-1144-E	.05	S-1481-D	.05	W-231-D	.05
S-1145-E	.05	S-1491-C	.05	W-250-G	.05
S-1146-A	.05	S-1502-D	.25	W-276-G	.15
S-1153-D	.55	S-1503-D	.35	W-298-D	.05
S-1157-E	.05	S-1504-D	.05	W-306-G	.25
S-1159-E	.05	S-1505-D	.05	W-308-C	.05
S-1160-G	.90	S-1511-E	.05	W-311-C	.05
S-1166-C	1.10	T-101-E	.15	W-317-D	.05
S-1169	4.70	T-137-E	.45	W-319-D	.05
S-1170-C	.55	T-161-E	8.45		

Simplex
REG. U.S. PAT. OFF.

E.7 • SUPER • SI
PROJECTORS



Simplex
REG. U.S. PAT. OFF.

★★★★

Sound