

J. Frank Brockliss, Ltd.

TELEPHONES :

Glasgow :
Bell 1156.

Manchester :
Central 1876.

Leeds :
Leeds 24509.

Birmingham :
Midland 2490.

58 Great Marlborough Street,

LONDON, W. 1.

TELEphone : GERRARD 2911 - 2912 - 2913.
grams : "Stafilm, Wesdo, London."

BRANCHES :

181, Howard Street,
Glasgow.

3, The Parsonage,
Manchester.

67, Britannia House,
Wellington Street,
Leeds.

110 John Bright Street,
Birmingham.

SIMPLEX

PRINCIPAL SPARE PARTS PRICE LIST.

			£	s.	d.
A.1.		Handle Shaft and Collar ...	0	16	0
C.126.A.	Clutch :	Main Driving Gear Clutch ...	0	4	6
C.189.A.	Collar :	Handle Shaft Driving Collar ...	0	4	6
P.115.A.	Pin :	Handle Shaft Driving Collar Pin	0	0	9
S.287.A.	Shaft :	Handle Shaft	0	10	0
A.4.		Projecting Lens Holder and Slide	2	10	0
S.322.A.	Slide	Projecting Lens Holder Slide ...	0	6	0
S.342.A.	Spring :	Projecting Lens Holder Slide Guide Rod Spring ...	0	0	6
S.494.A.	Screw	Focussing Rack Retaining Screw	0	1	0
W.118.A.	Washer	Projecting Lens Holder Slide Washer	0	0	6
A.8.		Focussing Pinion Knob ...	0	7	6
R.178.A.	Rod :	Focussing Pinion Rod	0	0	10
A.24.		Projecting Lens Focussing Device	1	10	0
A.131.A.	Arm :	Focussing Rack Arm	0	6	0
G.121.A.	Gib	Focussing Slide Gib	0	1	0
P.189.A.	Pinion :	Focussing Pinion	0	10	6
S.118.L.	Screw	Motor Drive Pinion Set Screw	0	0	6
S.278.A.	Screw	Pad Roller Arm Tension Spring Fastening Screw	0	0	6
S.343.A.	Spring :	Rack Arm Friction Spring ...	0	0	6
S.569.A.	Spring :	Lower Sprocket Roller Arm Spring	0	0	9
S.570.A.	Spring :	Upper Sprocket Roller Arm Spring	0	0	9

			£	s.	d.
		"BB" DOUBLE BEARING INTERMITTENT MOVEMENT COMPLETE	25	0	0
BB.21.		Intermittent Case Assembly	7	10	0
C.293.BB.	Cup :	Intermittent Oil Cup ...	0	3	6
B.248.BB.	Bearing :	Star Wheel Shaft Inner Bearing	1	1	0
B.249.BB.	Bearing :	Star Wheel Shaft Outer Bearing	1	1	0
C.295.BB.	Collar :	Star Wheel Shaft Collar ...	0	3	0
P.353.BB.	Pivot	Case Retaining Clamp Pivot ...	0	0	6
S.177.E.	Screw :	Collar Set Screw ...	0	0	6
S.432.E.	Screw :	Stripper Screw ...	0	0	6
S.724.BB.	Screw	Bearing Screw ...	0	0	6
S.731.BB.	Stripper	Intermittent Film Stripper ...	0	6	0
BB.27.		Fly Wheel Shaft and Gear Complete	1	5	0
G.187.BB.	Gear	Fly Wheel Shaft Gear ...	0	10	6
S.726.BB.	Shaft	Fly Wheel Shaft ...	0	16	6
BB.28.		Fly Wheel and Gear Complete	4	5	0
G.185.BB.	Gear	Flywheel Gear ...	0	13	6
W.191.BB.	Wheel	Fly Wheel ...	3	12	6
BB.30.		Fly Wheel Lock Nut Complete (Includes BB.29)	1	1	0
K.130.BB.	Key :	Fly Wheel Lock Key ...	0	3	0
BB.31		Outer Bearing Oil Cup Complete	0	1	6
BB.32.		Taper Pin Ejector	0	12	0
B.254.BB.	Block	Intermittent Sprocket Taper Pin Stripper Block ...	0	10	0
S.757.BB.	Screw	Intermittent Sprocket Taper Pin Stripper Screw ...	0	2	0
S.750.BB.	Sprocket	Intermittent Sprocket ...	2	2	6
S.730.BB.	Shaft	Star Wheel and Shaft ...	2	2	6
BB.38.		Intermittent Cam Complete (Includes BB.39)	2	2	6
P.360.BB.	Pin :	Cam Pin ...	0	3	0
BB.39	Nut :	Cam Shaft Lock Nut ...	0	11	0
S.1024.BB.	Screw	Cam Retain Screw ...	0	0	6
BB.40.		Oil Tight Cover Assembly (Includes BB.31 and R.52)	5	0	0
A.192.BB.	Arm :	Case Cover and Bearing Arm...	4	10	0
G.225.BB.	Gasket :	Case Cover Glass Gasket ...	0	0	6
G.226.BB.	Glass :	Oil Sight Glass ...	0	1	0
W.204.BB.	Nut :	Oil Sight Nut ...	0	1	6
W.228.BB.	Washer	Oil Sight Washer ...	0	1	6
W.227.BB.	Washer	Oil Retain Washer ...	0	0	6
W.232.BB.	Washer :	Fly Wheel Gear Oil Retain Washer ...	0	0	6
B.246.BB.	Bearing	Fly Wheel Shaft Bearing ...	1	4	0
B.247.BB.	Bearing :	Cam Shaft Bearing ...	1	1	0
C.294.BB.	Clamp	Case Retaining Clamp ...	0	0	9
D.130.BB.	Deflector	Oil Deflector ...	0	3	0

			£	s.	d.
G.188.BB.	Gasket	Oil Gasket ...	0	0	9
S.728.BB.	Screw :	Case Clamp Screw ...	0	1	3
S.729.BB.	Screw	Case Cover Screw ...	0	1	3
S.765.BB.	Screw :	Oil Deflector Screw ...	0	0	6
G.241.BB.	Glass	Case Cover Glass, Old Style ...	0	0	9
C.4.		Film Trap Lever Assembly	0	10	6
S.102.E.	Screw :	Film Trap Door Lever Spring Screw ...	0	0	6
S.329.C.	Spring :	Film Trap Door Lever Spring	0	0	6
C.8.		Upper Magazine Roller Holder Assembly	1	17	6
H.130.C.	Holder	Upper Magazine Roller Holder	1	0	0
R.160.C.	Roller	Magazine Roller, Small...	0	4	0
R.161.C.	Roller :	Magazine Roller, Large ...	0	5	0
S.485.C.	Screw	Magazine Roller Screw ...	0	0	9
C.9.		Governor Lift Lever Link Assembly	0	5	6
C.12.		Pad Roller Stud and Arm Assembly ...	0	3	9
A.136.C.	Arm :	Upper Pad Roller Arm ...	0	12	0
A.137.C.	Arm :	Lower Pad Roller Arm ...	0	12	0
C.157.C.	Cover :	Right Cover ...	0	10	6
C.286.C.	Cover :	Right Front Cover ...	1	0	0
N.166.C.	Nut :	Pad Roller Arm Nut ...	0	0	9
P.102.C.	Roller :	Pad Roller ...	0	9	0
P.289.C.	Pin :	Roller Arm Stop Pin ...	0	0	6
S.122.C.	Screw	Cover Screw ...	0	0	6
S.133.C.	Screw :	Film Trap Screw ...	0	0	9
S.165.C.	Screw :	Right Cover Fastening Screw	0	0	6
S.248.A.	Screw :	Roller Holder Screw ...	0	0	6
S.514.C.	Stud.:	Automatic Fire Shutter Lifting Stud... ..	0	1	3
S.567.C.	Stud :	Pad Roller Arm Stud ...	0	2	3
S.572.C.	Stripper :	Upper and Lower Sprocket Film Stripper ...	0	2	0
S.573.C.	Stud	Upper and Lower Sprocket Film Stripper Stud ...	0	4	0
3.706.C.	Screw	Pad Roller Arm Screw ...	0	1	3
W.160.C.	Washer	Pad Roller Arm Washer ...	0	0	10
D.1.		Driving Arm Assembly ...	1	8	6
D.2.		Governor Lift Lever Assembly	0	6	9
L.105.D.	Lever :	Governor Lift Lever ...	0	6	0
S.493.D.	Screw :	Governor Lift Lever Screw ...	0	0	9
D.3.		Governor Weight and Links Assembly (set only)	0	12	0
L.112.D.	Link :	Governor Weight Link ...	0	0	6
S.100.E.	Screw	Governor Weight Screw ...	0	0	6
D.5.		Right Door and Knob (Includes D.4.)	1	12	6
K.132.D.	Knob :	Door Knob ...	0	3	0
S.178.D.	Screw :	Door Knob Screw ...	0	0	6

			£	s.	d.
D.6.		Right Door Lock Spring and Button Assembly ...	0	3	0
D.7.		Right Back Cover Hinge Assembly ...	0	3	6
D.9.		Right Back Cover (New Style) (Includes D.7.) ...	1	15	0
C.285.D.	Cover :	Right Back Cover ...	0	17	6
N.132.U.	Nut :	Spring Retain Nut ...	0	0	6
P.383.A.	Post :	Spring Post ...	0	2	0
R.162.D.	Roller	Stripper Roller ...	0	2	6
S.771.D.	Screw :	Stripper Roller Screw ...	0	0	9
D.11.		Upper Left Door and Knob Assembly (Includes D.10 and D.18) ...	1	15	0
K.106.D.	Knob	Left Door Knob ...	0	2	6
D.12.		Lower Left Door Assembly (Includes D.19) ...	1	0	0
D.13.		Shutter Spider Assembly ...	0	17	6
S.165.C.	Screw :	Shutter Spider Screw ...	0	0	6
D.14.		Three Wing Shutter and Spider Assembly (Includes D.13) ...	1	15	0
D.27.		Three Wing Opaque Shutter ...	1	0	0
D.15.		Stero Slide and Arm Assembly	1	9	0
D.16.		Top Plate and Stereo Slide Assembly (Includes D.15) ...	3	0	0
L.113.D.	Link :	Left Door Stop Link ...	0	2	0
P.207.D.	Plate	Top Plate ...	1	0	0
S.181.D.	Screw	Left Door Stop Link Screw ...	0	1	0
D.22.		Two Wing Opaque Shutter Regular ...	1	0	0
D.23.		Two Wing Shutter and Spider Assembly (Includes D.13 and D.22) ...	1	15	0
D.90.		REAR SHUTTER ATTACHMENT COMPLETE ...	30	0	0
L.170.D.	Lamp :	Pilot Lamp ...	0	2	3
S.968.D.	Switch	Pilot Lamp Toggle Switch ...	0	3	9
D.80.		Shutter Shaft Assembly ...	0	18	0
G.203.D.	Gear :	Shutter Gear ...	0	7	6
S.1046.D.	Shaft :	Rear Shutter Shaft ...	0	10	6
P.107.G.	Pin :	Rear Shutter Shaft Pin ...	0	0	6
D.82.		Shutter Lift Assembly ...	0	10	0
G.220.D.	Glass :	Spot Sight Glass ...	0	1	6
S.101.C.	Screw :	Glass Retaining Screw ...	0	0	6
S.248.A.	Screw :	Cooling Plate Fastening Screw	0	0	6
S.962.D.	Spring :	Glass Tension Spring ...	0	1	6
K.137.D.	Knob :	Framing Gear Handle Knob ...	0	5	6
S.897.C.	Screw	Knob Fastening Screw ...	0	0	9
D.89.		Two Wing Adjustable Shutter	1	7	0

			£	s.	d.
B.332.D.	Blade	Shutter Fan Blade ...	0	1	6
B.341.D.	Blade	Shutter Adjustable Blade ...	0	4	6
S.106.D.	Screw	Shutter Fan Blade Screw ...	0	0	6
S.192.D.	Screw :	Shutter Fastening Screw ...	0	0	6
S.1045.D.	Shutter :	Shutter ...	0	14	3
W.231.D.	Washer :	Shutter Fan Blade Screw Washer ...	0	0	6
K.139.D.	Knob :	Shutter Knob ...	0	3	0
D.95.		Shutter Spider ...	1	6	0
S.1026.D.	Screw :	Shutter Spider Clamp Screw ...	0	0	6
D.99.		Two Wing Adjustable Shutter and Spider (Includes D.89 and D.95) ...	2	12	6
DD.1.		Ball Bearing Bushing ...	0	15	0
DD.4.		Spot Sight Box Mount Assembly	1	10	0
DD.5.		Grease Tube Assembly ...	0	3	0
DD.8.	Self :	Self Aligning Ball Race Assembly (Includes DD.1 and DD.5) ...	4	5	0
B.355.D.	Bearing :	Ball Bearing ...	0	15	0
C.405.D.	Cap :	Ball Bearing Dust Cap ...	0	3	0
H.217.D.	Housing :	Ball Bearing Housing ...	0	18	0
N.211.D.	Nut :	Ball Bearing Lock Nut ...	0	6	0
S.1129.D.	Screw :	Ball Bearing Housing Screw, Long ...	0	0	6
W.208.G.	Washer :	Spacing Washer ...	0	3	0
W.253.D.	Washer :	Ball Bearing Washer ...	0	0	6
W.254.D.	Washer :	Ball Bearing Busher Washer ...	0	3	0
P.380.E.	Pivot :	Film Trap Door Lock Pawl Pivot	0	1	6
P.406.E.	Plunger :	Door Locking and Opening Device Plunger ...	0	1	6
P.482.E.	Pin :	Plunger Core Pin ...	0	0	6
S.851.E.	Spring	Door Locking and Opening Device Spring ...	0	0	6
S.857.E.	Support	Door Opening Trigger Support	0	4	6
S.881.E.	Screw :	Door Locking and Opening Device Fastening Screw ...	0	2	6
T.137.E.	Trigger :	Door Trigger ...	0	4	6
C.365.D.	Clamp	Right Door Glass Clamp ...	0	0	6
C.151.D.	Cover	Left Back Cover ...	0	10	6
C.152.D.	Cover :	Left Front Cover ...	0	12	6
G.124.D.	Glass :	Right Door Glass ...	0	8	6
S.180.D.	Screw	Lower Left Door Retain Screw	0	1	6
S.1152.D.	Shield :	Handle Shaft Oil Shield ...	0	10	6
W.145.D.	Sprocket :	Upper Sprocket ...	1	0	0
W.146.D.	Sprocket :	Lower Sprocket ...	1	0	0
E.2.		Door Holder Assembly ...	1	10	0
E.3.		Intermittent Film Guide Assembly ...	0	12	9
E.6.		Automatic Fire Shutter and Lift Link Assembly ...	0	3	0

			£	s.	d.
E.7.		Automatic Fire Shutter Lift Lever Assembly ...	0	3	0
E.10.		Double Tension Film Trap Door Assembly (Includes E.3. and D.145.E.)	4	10	0
D.145.E.		Double Tension Film Trap Door only	2	10	0
H.118.E.	Holder :	Guide Holder	0	4	6
P.100.E.	Pad :	Film Trap Door Pad	0	4	6
P.325.E.	Protector :	Film Protector	0	7	6
S.130.E.	Screw :	Film Guide Holder Screw	0	0	6
S.132.E.	Screw :	Film Guide Retaining Spring Screw	0	0	6
S.326.E.	Spring :	Film Guide Retaining Spring	0	0	6
S.328.E.	Spring :	Film Trap Door Pad Spring	0	1	3
S.580.E.	Shoe :	Double Tension Film Trap Door Shoe	0	1	6
S.581.E.	Spring :	Double Tension Film Trap Door Shoe Spring	0	1	6
S.698.E.	Screw :	Film Protector Screw	0	0	6
C.129.E.	Collar :	Lateral Guide Roller Shaft Collar	0	1	6
R.214.E.	Roller :	Lateral Guide Roller	0	5	0
S.763.E.	Screw :	Lateral Guide Roller Shaft Collar Screw	0	0	6
S.762.E.	Spring :	Guide Roller Spring	0	0	6
E.15.		Lateral Guide Roller Shaft and Washer (Includes 2-P-359-E.)	0	3	0
E.19.		Film Trap Door Lock	1	0	0
153	Wrench	Wrench	0	3	0
N.172.E.	Nut :	Thumb Piece Nut	0	3	0
P.372.E.	Piece :	Thumb Piece	0	6	0
P.379.E.	Pawl :	Lock Pawl	0	3	0
P.380.E.	Pivot :	Lock Nut Pivot	0	1	6
S.442.G.	Screw :	Stud Retain Screw	0	0	6
S.736.E.	Stud :	Thumb Piece Stud	0	3	0
S.777.E.	Spring :	Lock Pawl Spring	0	0	6
S.778.E.	Screw :	Lock Pawl Spring Retain Screw	0	0	6
P.359.E.	Pivot :	Guide Roller Pivot	0	0	6
S.309.E.	Shoe :	Film Trap Shoe	0	6	0
S.327.E.	Spring :	Door Holder Spring	0	0	9
S.432.E.	Screw :	Film Trap Shoe Screw	0	0	6
T.101.E.	Thimble :	Film Trap Door Thimble	0	0	9
P.445.E.	Piece :	Sliding Piece	0	4	6
P.529.E.	Plate :	Aperture Plate (Sliding Type)	0	4	6
T.171.E.	Trap :	Cast Iron Film Trap for Stationery Plate	3	0	0
T.172.E.	Trap :	Cast Iron Film Trap for Removable Plate	3	0	0

			£	s.	d.
G.1.		Intermediate Gear and Shaft (Includes G.12.)	4	15	0
C.192.G.	Collar :	Intermediate Shaft Gear Collar	0	5	0
G.134.G.	Gear :	Intermediate Gear No. 1.	0	10	6
G.135.G.	Gear :	Intermediate Bevel Gear	1	5	0
S.145.G.	Screw :	Intermediate Gear Washer Retain Screw	0	0	6
S.442.G.	Screw :	Intermediate Shaft Retain Collar Set Screw	0	0	6
S.1032.G.	Shaft :	Intermediate Shaft	0	12	0
W.140.G.	Washer :	Intermediate Gear Retain Washer	0	0	9
G.2.		Lower Sprocket Shaft and Gear	1	2	6
G.4.		Framing Slide Assembly	1	5	0
G.5.		Bevel Gear and Shaft	1	10	0
C.193.G.	Collar :	Bevel Gear Collar	0	2	3
G.115.G.	Gear :	Bevel Gear	0	15	0
S.436.G.	Screw :	Set Screw	0	0	6
S.1082.G.	Shaft :	Bevel Gear Drive Shaft	0	16	6
G.6.		Shutter Gear Bracket Assembly Complete (Includes G.4. and G.5.)	7	0	0
B.197.G.	Bracket :	Shutter Gear Bracket and Oil Cups	1	10	0
C.316.G.	Cup :	Oil Cup	0	0	10
G.116.G.	Gear :	Shutter Driving Gear with Broached Hole	0	12	0
G.147.G.	Gear :	Spiral Gear	0	12	6
R.120.G.	Rod :	Framing Slide Guide Rod	0	0	9
S.141.A.	Screw :	Framing Slide Set Screw	0	0	6
S.437.G.	Screw :	Bevel Gear Set Screw	0	0	6
S.781.G.	Shaft :	Shutter Shaft	0	10	6
W.105.B.	Washer	Spiral Driving Gear Shaft Washer	0	2	0
G.12.		Formica Intermediate Gear and Plate Assembly	1	5	0
S.705.G.	Screw :	Intermediate Gear Screw (3) each	0	0	6
G.13.		Formica Double Bevel Gear and Flanges	2	5	0
P.368.G.	Pin :	Bevel Gear Pin	0	1	3
G.15.		Formica Double Bevel Gear, Flanges and Vertical Shaft Assembly (Includes G.13)	2	15	0
S.550.G.	Shaft :	Vertical Shaft	0	12	6
G.112.G.	Gear :	Main Driving Gear	1	15	0
G.138.G.	Gear :	Bevel Gear No. 3.	0	10	6
G.139.G.	Gear :	Upper Sprocket Shaft Gear	0	17	6
G.215.G.	Gear :	Main Drive Gear for RCA sound Equipment	1	15	0
H.120.G.	Holder :	Governor Lower Link Holder	0	9	0

			£	s.	d.
H.121.G.	Holder :	Governor Upper Link Holder	0	7	6
S.151.D.	Screw	Governor Link Holder Screw	0	0	6
S.209.G.	Screw :	Main Driving Gear Retaining Screw	0	2	0
S.574.G.	Shaft :	Shutter Shaft, 5/16 in. diameter (Old type)	0	10	6
S.1033.G.	Shaft :	Top Sprocket Shaft	0	10	0
W.124.G.	Washer :	Vertical Shaft Washer No. 1	0	1	6
W.125.G.	Washer :	Vertical Shaft Washer No. 2	0	1	6
U.1.		Magazine Latch Assembly ...	0	3	0
U.3.		Upper Magazine Shaft Complete	0	10	6
L.151.U.	Lock :	Reel Lock	0	2	0
P.211.M.	Plunger :	Reel Lock Plunger	0	0	9
S.345.U.	Spring :	Reel Lock Plunger Spring ...	0	0	6
S.702.U.	Shaft :	Upper Reel Shaft	0	7	6
U.4.		Shaft Adjusting Nut Assembly	0	6	6
W.1.		Lower Magazine Roller Holder Assembly	1	10	0
H.124.W.	Holder :	Lower Magazine Roller Holder	0	10	6
R.160.C.	Roller :	Magazine Roller, Small... ..	0	4	0
R.161.C.	Roller :	Magazine Roller, Large	0	5	0
W.5.		Take-up Shaft and Collar	0	18	9
C.282.W.	Collar :	Take-up Shaft Collar	0	2	3
L.151.U.	Lock :	Magazine Reel Shaft Lock ...	0	1	6
P.160.M.	Pin :	Reel Shaft Collar Pin	0	0	6
P.211.E.	Plunger :	Reel Lock Plunger	0	0	9
S.733.W.	Screw :	Lower Magazine Shaft Collar Fastening Screw	0	0	6
S.345.W.	Spring :	Reel Lock Spring	0	0	6
S.703.W.	Shaft :	Take-up Shaft	0	8	0
W.6.		High Speed Take-up Pulley Assembly	0	12	6
B.195.W.	Bushing :	Take-up Shaft Bearing Bushing	0	15	0
D.121.W.	Disc :	Take-up Shaft Friction Disc ...	0	6	0
D.122.W.	Disc :	Take-up Shaft Floating Disc ...	0	6	0
G.131.U.	Glass	Magazine Door Wire Glass ...	0	1	6
K.132.D.	Knob :	Magazine Cover Knob	0	3	0
S.189.W.	Screw	Magazine Fastening Screw ...	0	1	6
S.223.G.	Screw :	Take-up Shaft Bearing Bushing Fastening Screw	0	0	6
S.442.G.	Screw :	Set Screw	0	0	6
S.733.W.	Screw :	Lower Magazine Collar Screw	0	0	6
W.163.W.	Washer	Take-up Leather Washer	0	1	3

PREVIOUS PRICES CANCELLED.

March 1936.